

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [COSYLAND](#) /

› [COSYLAND Foldable Toddler Kitchen Stool Helper Instruction Manual \(Model CS000183-6-US\)](#)

COSYLAND CS000183-6-US

COSYLAND Foldable Toddler Kitchen Stool Helper

Model: CS000183-6-US | Brand: COSYLAND

1. INTRODUCTION

The COSYLAND Foldable Toddler Kitchen Stool Helper is designed to safely elevate your child to counter height, allowing them to participate in kitchen activities, wash hands, or engage in other tasks alongside adults. Crafted from durable bamboo, this stool features an adjustable height, a foldable design for easy storage, and multiple safety enhancements to provide a secure and interactive experience for toddlers aged 18 months to 6 years.



Image 1: The COSYLAND Foldable Toddler Kitchen Stool Helper in its assembled and folded states.

2. SAFETY INFORMATION

Your child's safety is paramount. Please read and adhere to all safety guidelines before and during use.

- **Weight Capacity:** This stool is designed to support up to 300 lbs (approximately 136 kg).
- **Age Range:** Suitable for toddlers aged 18 months to 6 years.
- **Supervision:** Always supervise your child when they are using the stool. Never leave a child unattended.
- **Safety Net:** Utilize the multi-functional safety net to prevent accidental falls from the back of the stool. Ensure it is securely fastened.
- **Anti-Tip Design:** The stool features anti-tip feet for enhanced stability. Ensure the stool is placed on a flat, stable surface.
- **Non-Slip Strips:** Apply the provided non-slip strips to the steps for added traction.
- **Lockable Pull-Ring:** Ensure the pull-ring mechanism is securely locked when the stool is in use to prevent accidental folding.

Safe Usage Guideline



Image 2: Visual guide for safe usage, emphasizing proper supervision and positioning.

3. PRODUCT FEATURES

- **Durable Construction:** Made from natural bamboo, ensuring stability and longevity.
- **Foldable Design:** Easily folds for convenient storage and portability, saving space.
- **Height Adjustable:** The standing platform can be adjusted to two different heights to accommodate your child's growth.
- **Multi-Functional Safety Net:** Provides protection against falls and can also serve as a storage solution for small items.
- **Anti-Tip Feet:** Designed for increased stability and to prevent tipping.
- **Non-Slip Strips:** Included for application on steps to enhance foot grip.
- **Eco-Friendly Materials:** Constructed from safe, natural bamboo with no strong chemical odors.

Safety Net

Easy Access and Provides Extra Protection for Your Children



Image 3: Detailed view of key product features, including safety and adjustability.

4. SETUP

The COSYLAND Toddler Kitchen Stool is shipped mostly pre-assembled, requiring minimal effort for final setup. Follow these steps:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Attach Steps:** Securely attach the two bamboo steps to the designated slots on the main frame using the provided hardware.
3. **Install Anti-Tip Feet:** Fasten the anti-tip feet to the bottom of the stool's legs.
4. **Apply Non-Slip Strips:** Peel and stick the non-slip strips onto the surface of each step for improved traction.
5. **Attach Safety Net:** Secure the multi-functional safety net to the back of the stool using its buckles.

Once these steps are completed, ensure all connections are tight and stable before first use.

5. OPERATING INSTRUCTIONS

Adjusting Height

To adjust the standing platform's height:

1. Ensure no child is on the stool.
2. Locate the adjustment pins on the side of the stool.
3. Pull out the pins, slide the platform to the desired height, and re-insert the pins securely.

Folding for Storage

To fold the stool for storage:

1. Remove the safety net.
2. Locate the security knob or pull-ring mechanism.
3. Disengage the locking mechanism and carefully fold the tower inward until it is compact.
4. Ensure it is securely latched in the folded position.



Image 4: The stool in its folded state, demonstrating its space-saving design.

Usage Examples

The stool can be used in various settings:

- **Kitchen Counter:** Allows children to assist with cooking, baking, or washing dishes.
- **Bathroom Sink:** Helps children reach the sink for hand washing or teeth brushing.
- **Reading/Play Area:** Can be used as a comfortable seat for reading or engaging in tabletop activities.



Image 5: A child actively participating at the kitchen counter using the stool.

Extra Safety at the Back

Unique Safety Protection Anti-fall Net



Image 6: A child using the stool to reach the bathroom sink.

Sit or Stand, Play and Explore

This toddler tower grows with your child!



Image 7: The stool configured for sitting, used during a reading activity.

Official Product Video

Your browser does not support the video tag.

Video 1: An official COSYLAND video demonstrating the foldable toddler kitchen step stool's features, assembly, and various uses in a home environment.

6. MAINTENANCE

To ensure the longevity and hygiene of your COSYLAND Toddler Kitchen Stool:

- **Cleaning:** Wipe down the bamboo surfaces with a damp cloth and mild soap as needed. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Ensure the stool is completely dry after cleaning to prevent moisture damage to the wood.
- **Inspection:** Regularly check all screws, bolts, and connections to ensure they are tight. Retighten if necessary.
- **Storage:** When not in use, fold the stool and store it in a dry place away from direct sunlight or

extreme temperatures.

7. TROUBLESHOOTING

If you encounter any issues with your COSYLAND Toddler Kitchen Stool, please refer to the following common solutions:

- **Stool feels wobbly:** Check all assembly screws and bolts. Ensure they are tightened securely. Verify the stool is on a flat, even surface.
- **Difficulty folding/unfolding:** Ensure the safety net is removed and the locking pull-ring mechanism is fully disengaged. Do not force the folding mechanism.
- **Child slipping on steps:** Confirm that the non-slip strips are properly applied to the steps. Replace worn strips if necessary.

For any persistent problems or concerns not addressed here, please contact COSYLAND customer support.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	16.73"D x 19.09"W x 35.4"H
Brand	COSYLAND
Material	Bamboo
Color	Black & Natural
Special Features	Adjustable Height, Foldable, Portable, Safety net
Age Range	Toddler (18 Months to 6 Years)
Model Name	CS000183-6-US
Item Weight	13 Pounds
Assembly Required	Yes (Minimal)

Compatible Size



For 18 month to 6 year old

Image 8: Detailed dimensions of the stool in both open and folded positions.

9. WARRANTY AND SUPPORT

COSYLAND is committed to providing high-quality products. While specific warranty details are not provided in this document, for any product-related issues, questions, or support needs, please feel free to reach out to COSYLAND customer service. Contact information can typically be found on the product packaging or the official COSYLAND website.