

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Monster](#) /

› [Monster Shock Portable Bluetooth Speaker User Manual](#)

Monster S22

Monster Shock Portable Bluetooth Speaker User Manual

Model: S22 | Brand: Monster

1. INTRODUCTION

Thank you for choosing the Monster Shock Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before use.



Image 1.1: Front view of the Monster Shock Portable Bluetooth Speaker.

2. WHAT'S IN THE Box

Please check the package contents to ensure all items are present:

- Monster Shock Portable Bluetooth Speaker
- Audio Cable
- USB-C Cable
- Quick Start Guide
- Warranty Letter

3. PRODUCT FEATURES

3.1 Premium Audio Experience

The SHOCK speaker delivers crystal-clear highs, crisp mids, and rich lows. Its 30W power driver ensures powerful sound without distortion, even at maximum volume.



Image 3.1: Illustration of the speaker's internal drivers for high-fidelity stereo sound.

3.2 Portable Design

Designed for ultimate portability, this Bluetooth speaker features a compact, lightweight structure with a durable, rugged shell. It is easy to hold and includes a convenient handle, making it ideal for outdoor activities.



Image 3.2: The speaker's compact design allows for easy portability, shown here being carried outdoors.

3.3 Bluetooth 5.4 Connectivity

Utilizing the latest Bluetooth 5.4 technology, the speaker provides seamless connectivity to all Bluetooth-enabled devices within a range of up to 100 feet, ensuring stable and uninterrupted audio streaming.

Bluetooth Compatibility

Be it a smartphone, tablet, laptop, or any Bluetooth-enabled device, this speaker will provide you with a seamless and reliable connection experience.



Image 3.3: The speaker demonstrating Bluetooth compatibility with various devices.

3.4 TWS Functionality

The speaker supports True Wireless Stereo (TWS) functionality, allowing two units to connect wirelessly for an immersive surround sound experience without the need for cables.



TWS Stereo Pairing

Experience unparalleled, immersive audio with True Wireless Stereo.

Image 3.4: Two Monster Shock speakers demonstrating TWS pairing for enhanced stereo sound.

3.5 IPX6 Water Resistance

With an IPX6 rating, the speaker is resistant to high-pressure water jets from any direction, making it suitable for use in various outdoor environments, including near water.

IPX6 Water Resistant



Image 3.5: The speaker submerged in water, illustrating its IPX6 water resistance.

3.6 Extended Playback

Enjoy up to 17 hours of continuous music playback on a single charge, perfect for extended listening sessions on the go.

Extra Long Playback up to 17 Hours



Image 3.6: The speaker providing extended playback, suitable for long periods of relaxation.

4. SETUP GUIDE

4.1 Charging the Speaker

1. Connect the provided USB-C cable to the charging port on the speaker.
2. Connect the other end of the USB-C cable to a compatible USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate during charging and turn off when fully charged.
4. Allow approximately 3-4 hours for a full charge.

4.2 Powering On/Off

- To power on: Press and hold the Power button for 2-3 seconds until you hear an audible prompt.
- To power off: Press and hold the Power button for 2-3 seconds until you hear an audible prompt.

4.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Monster Shock" from the list of devices.
4. Once connected, the LED indicator will become solid, and you will hear a confirmation sound.

4.4 TWS (True Wireless Stereo) Pairing

To pair two Monster Shock speakers for stereo sound:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press the TWS button (if available) or the Bluetooth button twice rapidly.
3. The speakers will automatically search for each other and pair. You will hear a confirmation sound once paired.
4. Connect your device to the primary speaker via Bluetooth as described in section 4.3.

5. OPERATING INSTRUCTIONS

5.1 Basic Controls

Button/Action	Function
Power Button (Press & Hold)	Power On/Off
Play/Pause Button (Press)	Play/Pause Music
Volume + (Press)	Increase Volume
Volume - (Press)	Decrease Volume
Volume + (Press & Hold)	Next Track
Volume - (Press & Hold)	Previous Track
Play/Pause Button (Double Press)	Answer/End Call
Play/Pause Button (Press & Hold)	Reject Call

5.2 Auxiliary Input (AUX) Mode

To use the speaker with a non-Bluetooth device:

1. Connect one end of the provided audio cable to the AUX-in port on the speaker.
2. Connect the other end of the audio cable to the audio output jack of your device.
3. The speaker will automatically switch to AUX mode.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker. Do not use abrasive cleaners or solvents.
- **Water Exposure:** While IPX6 water-resistant, avoid prolonged submersion. Ensure the charging port cover is securely closed before exposure to water.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

- **Battery Care:** To preserve battery life, fully charge the speaker before first use and at least once every three months if not used regularly.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
No sound.	Volume too low; Device not connected; Incorrect mode.	Increase speaker/device volume; Re-pair Bluetooth; Ensure correct input mode (Bluetooth/AUX).
Bluetooth pairing fails.	Speaker not in pairing mode; Device Bluetooth off; Too far from speaker.	Ensure speaker is flashing LED; Turn device Bluetooth on/off; Move device closer (within 30 ft).
TWS pairing fails.	Speakers already connected to other devices.	Disconnect both speakers from any Bluetooth devices before initiating TWS pairing.

8. SPECIFICATIONS

Feature	Detail
Model Name	Monster Shock Portable Bluetooth Speaker
Model Number	S22
Speaker Type	Portable Speaker
Connectivity Technology	Bluetooth 5.4
Speaker Maximum Output Power	35 Watts
Product Dimensions	5.3"D x 2"W x 5"H
Item Weight	0.69 Kilograms (1.52 pounds)
Battery Life	Up to 17 hours
Water Resistance Rating	IPX6

9. WARRANTY AND SUPPORT

Monster offers a worry-free shopping experience for the Shock Portable Bluetooth Speaker. Your purchase includes a warranty letter. For any pre-sales or after-sales questions, our customer service team is available 24 hours a day to assist you.

Please refer to the included warranty letter for specific terms and conditions regarding your product's warranty coverage.

For support, please contact the seller directly or visit the official Monster support website.

