

[Manuals.plus](#) /

› [Kircuit](#) /

› Kircuit 12V AC/DC Adapter for PetSnowy PS-001 Cat Litter Box - Instruction Manual

Kircuit 12V AC/DC Adapter

Kircuit 12V AC/DC Adapter Instruction Manual

For PetSnowy PS-001 Snow Self-Cleaning Cat Litter Box

1. INTRODUCTION

The Kircuit 12V AC/DC Adapter is a replacement power supply specifically designed for charging and operating the PetSnowy PS-001 Snow Self-Cleaning Cat Litter Box. This adapter converts standard AC wall power into the DC power required by your device, ensuring reliable performance. It is important to note that this adapter is **NOT FOR SNOW+** models.



Image 1: The Kircuit 12V AC/DC Adapter, displaying its input and output specifications.

2. SETUP

1. **Unpack the Adapter:** Carefully remove the Kircuit 12V AC/DC Adapter from its packaging.
2. **Inspect for Damage:** Before use, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.
3. **Connect to Power Outlet:** Plug the AC input plug of the adapter into a standard 100-240V AC electrical wall outlet. Ensure the outlet is easily accessible.
4. **Connect to Device:** Insert the barrel tip connector of the adapter's DC output cable into the power input port of your PetSnowy PS-001 Snow Self-Cleaning Cat Litter Box. Ensure a secure connection.



Image 2: The Kircuit 12V AC/DC Adapter connected to a power strip, ready for use.

The adapter is now ready to supply power to your PetSnowy PS-001 device.

3. OPERATING INSTRUCTIONS

Once properly connected as described in the Setup section, the Kircuit 12V AC/DC Adapter will automatically provide power to your PetSnowy PS-001. The device will begin charging its internal battery or operate directly from the adapter's power, depending on its design.

- **Continuous Power:** The adapter is designed for continuous use to power or charge your device.
- **Monitoring:** Observe your PetSnowy PS-001's charging indicator (if available) to confirm it is receiving power.
- **Disconnection:** To disconnect, first unplug the barrel tip from the PetSnowy PS-001, then unplug the adapter from the wall outlet.

4. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your Kircuit 12V AC/DC Adapter.

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable.
- **Cable Care:** Do not bend, twist, or pull the power cord excessively. Avoid placing heavy objects on the cable.
- **Environmental Conditions:** Keep the adapter away from water, high humidity, and dusty environments.

5. TROUBLESHOOTING

If you encounter issues with your Kircuit 12V AC/DC Adapter, refer to the following common problems and solutions:

- **Device Not Receiving Power:**
 - Ensure the adapter is securely plugged into a working wall outlet.
 - Verify the barrel tip connector is fully inserted into the PetSnowy PS-001's power port.
 - Test the wall outlet with another device to confirm it is functional.
 - Check the adapter cable for any visible damage or breaks.
- **Adapter Overheating:**
 - Disconnect the adapter immediately.
 - Ensure the adapter is in a well-ventilated area and not covered.
 - Allow the adapter to cool down before attempting to use it again. If overheating persists, discontinue use.
- **Intermittent Power:**
 - Check all connections for looseness.
 - Ensure the cable is not crimped or damaged.

If these steps do not resolve the issue, please contact customer support.

6. SPECIFICATIONS

Brand	Kircuit
Input Voltage	AC 100-240V, 50/60Hz
Output Voltage	DC 12V
Connector Type	Barrel Tip
Cable Length	Approximately 6.5 feet (2 meters)
Compatible Device	PetSnowy PS-001 Snow Self-Cleaning Cat Litter Box (Not for SNOW+)
Manufacturer	Shenzhen Waweis Technology Co., Ltd



Image 3: The Kircuit 12V AC/DC Adapter, highlighting its 6.5 ft cord length.

7. WARRANTY INFORMATION

No specific warranty information is provided with this product at the time of documentation. Please refer to the seller's return policy or contact the seller directly for details regarding warranty coverage.

8. SUPPORT

For technical assistance, troubleshooting beyond the scope of this manual, or inquiries regarding your Kircuit 12V AC/DC Adapter, please contact the seller or manufacturer directly through the platform where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question