

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Gradio](#) /
- › [Gradio CD03P Portable Bluetooth CD Player User Manual](#)

Gradio CD03P

Gradio CD03P Portable Bluetooth CD Player User Manual

Model: CD03P | Brand: Gradio

INTRODUCTION

Thank you for choosing the Gradio CD03P Portable Bluetooth CD Player. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

The Gradio CD03P is a versatile audio device featuring CD playback, Bluetooth 5.3 connectivity, dual wireless karaoke microphones, dynamic LED lights, and multiple input options including USB, TF card, and AUX. It is powered by a 4000mAh rechargeable battery, offering portability for various environments.

PRODUCT OVERVIEW



Figure 1: Greadio CD03P Portable Bluetooth CD Player with two microphones and LED lights.

CD Player with Microphones & Party Lights

Enjoy your favorite music anytime, anywhere



Dual
Microphones



Colorful
Party Lights



CD / USB /
TF / AUX



4000mAh
Rechargeable



Remote
Control



Bluetooth
5.3



Figure 2: Top view of the CD03P showing control buttons and LED light bar.

Package Contents:

- Portable CD Player x 1
- Karaoke Microphone x 2
- Type-C Charging Cable x 1
- Remote Control x 1
- AUX Cable x 1

SETUP

Charging the Device:

Before first use, fully charge the CD player using the provided Type-C charging cable. Connect the cable to the Type-C port on the device and a compatible 5V/2A power adapter (not included). The battery indicator on the display will show charging status.

Charging the Microphones:

The two wireless microphones are rechargeable. Connect them to a power source using their respective charging cables (if provided, or compatible USB cables). Each microphone offers over 30 hours of playtime on a full charge.

OPERATING INSTRUCTIONS

1. Power On/Off:

Long press the Power button () on the device or remote control to turn the unit on or off.

2. Mode Selection:

Press the **M** (Mode) button on the device or the **FUNC.** button on the remote control to cycle through available modes: CD, Bluetooth, USB, TF Card, and AUX.

3. CD Playback:

1. Press the release button to open the CD compartment cover.
2. Carefully insert a CD (compatible with CD/CD-R/CD-RW/MP3/WMA formats) with the label side facing up.
3. Close the CD compartment cover securely.
4. Select "CD" mode using the Mode/FUNC. button. The device will begin loading and playing the CD.
5. Use the |< and >| buttons for track navigation (short press) or fast forward/rewind (long press).
6. Press the ►|| button to play or pause.

Your browser does not support the video tag.

Video Description: This video demonstrates how to play CDs, USB, and TF cards on the Greadio CD03P. It shows inserting a CD, selecting the CD mode, and using playback controls.

4. Bluetooth Connectivity (Receiving Mode):

1. Press the **M** (Mode) button until "Bluetooth" mode is selected. The display will show "BLUE" and a blinking Bluetooth icon.
2. On your mobile device, enable Bluetooth and search for "CD03P".
3. Select "CD03P" to pair. A confirmation tone will sound upon successful connection.
4. Play audio from your mobile device, and it will stream through the Greadio CD03P speakers.

Your browser does not support the video tag.

Video Description: This video illustrates the Bluetooth receiving mode, showing how to connect a mobile phone to the Greadio CD03P for audio playback.

5. Bluetooth Connectivity (Transmitting Mode):

The CD03P can transmit audio to external Bluetooth speakers or headphones when in CD, USB, TF, or AUX mode (not in Bluetooth receiving mode).

1. Ensure the CD03P is in CD, USB, TF, or AUX mode.
2. Short press the **BT** button on the remote control. The Bluetooth icon on the display will blink.
3. Put your external Bluetooth speaker or headphones into pairing mode.

4. Once connected, the Bluetooth icon on the CD03P will stop blinking. Audio will now play through the external Bluetooth device.
5. To disconnect, short press the **BT** button again.

Your browser does not support the video tag.

Video Description: This video demonstrates the Bluetooth transmitting mode, showing how to connect the Greadio CD03P to external Bluetooth speakers or headphones.

6. USB/TF Card Playback:

1. Insert a USB flash drive into the USB port or a TF card into the TF card slot on the back of the device.
2. Press the **M** (Mode) button or **FUNC.** button on the remote to select "USB" or "TF" mode.
3. The device will automatically detect and play compatible audio files (MP3/WMA/WAV/APE/FLAC).
4. Use the |< and >| buttons for track navigation (short press) or fast forward/rewind (long press).
5. Press the ►|| button to play or pause.

Note: For best performance with USB/TF cards, use 64GB or less. Reformat 128GB cards to FAT32 if needed.

7. AUX Input:

1. Connect an external audio device (e.g., smartphone, MP3 player) to the AUX port on the back of the CD03P using the provided AUX cable.
2. Press the **M** (Mode) button or **FUNC.** button on the remote to select "AUX" mode.
3. Play audio from your external device. The sound will be output through the CD03P speakers.

8. Karaoke Microphones:

1. Turn on the microphones by pressing their power buttons. They will automatically connect to the CD03P.
2. Use the +/- buttons on the microphone to adjust microphone volume.
3. Press the **MIC** button on the microphone to cycle through five voice effects: Female, Monster, Baby, Original, and KTV mode.
4. Press the **Power** button on the microphone to switch between microphone modes (e.g., adjust background music, microphone volume, reverb).

Your browser does not support the video tag.

Video Description: This video demonstrates how to connect and use the wireless microphones with the Greadio CD03P, including switching voice effects and adjusting settings.

9. LED Lights:

1. The RGB light (LED1) turns on automatically when the device is powered on.
2. Short press the **Light** button on the device or remote to cycle through various light effects: breathing light (red, purple, blue, cyan, green, yellow, orange) and solid colors.
3. Long press the **Light** button to turn the LED lights off.

Your browser does not support the video tag.

Video Description: This video showcases the dynamic LED light features of the Greadio CD03P, demonstrating how to cycle through different light modes and colors.

10. Volume Control:

Use the **VOL+** and **VOL-** buttons on the device or remote control to adjust the main speaker volume.

11. EQ Modes:

Short press the **EQ** button on the remote control to switch between different equalizer modes (e.g., Pop, Jazz, Classic, Bass, Flat, Rock).

12. Sleep Timer:

The CD03P can function as a night light with a sleep timer. Refer to the full user manual for detailed instructions on setting the sleep timer.

MAINTENANCE

- Keep the device away from water and moisture.
- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the device to extreme temperatures or direct sunlight.
- Do not press the CD base directly.
- When not in use for extended periods, store the device in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low battery or power issue.	Charge the device fully. Ensure the charging cable is properly connected.
CD does not play or skips.	CD is dirty, scratched, or inserted incorrectly.	Clean the CD with a soft cloth. Ensure the CD is inserted correctly with the label side up. Try a different CD.
Bluetooth pairing fails.	Device is not in Bluetooth mode or too far from the paired device.	Ensure the CD03P is in Bluetooth receiving mode. Move devices closer. Disconnect from other Bluetooth devices.
Microphone not working.	Microphone is off, uncharged, or out of range.	Turn on the microphone. Charge the microphone. Ensure it is within range of the CD03P.
No sound.	Volume is too low or muted. Incorrect mode selected.	Increase volume. Check if the device is muted. Ensure the correct input mode (CD, Bluetooth, USB, TF, AUX) is selected.
Device unresponsive.	Temporary software glitch.	Use a thin object to press the RESET button on the back of the device.

SPECIFICATIONS

Feature	Detail
Model Number	CD03P
Product Dimensions	6.81 x 2.52 x 8.15 inches
Item Weight	1.97 pounds
Battery Capacity	4000mAh (Rechargeable)
Connectivity	Bluetooth 5.3, USB, TF Card, AUX
CD Compatibility	CD/CD-R/CD-RW/MP3/WMA

Feature	Detail
Included Components	Portable CD Player, 2 Karaoke Microphones, Type-C Charging Cable, Remote Control, AUX Cable

WARRANTY AND SUPPORT

Greadio products come with a full year of coverage. For any issues or support needs, please contact Greadio customer service. Refer to the official Greadio website or your purchase documentation for contact details.

Note: This device is designed for personal and recreational use. Any unauthorized modifications or misuse may void the warranty.

© 2025 Greadio. All rights reserved.

For more information, visit the [Greadio Store](#).