

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Monster](#) /

> [Monster Clarity 200 Wireless Earbuds Instruction Manual](#)

## Monster W38

# Monster Clarity 200 Wireless Earbuds User Manual

Model: W38

## INTRODUCTION

The Monster Clarity 200 Wireless Earbuds are designed to provide a comfortable and immersive audio experience. Featuring Bluetooth 6.0 connectivity, active noise cancellation, and clear call functionality, these earbuds are suitable for various daily activities, from listening to music to making calls.

## WHAT'S IN THE BOX



### What's in the Box

Earphones x2 (L&R)  
Charging case x1  
USB-C cable x1  
Quick start guide  
Earphone caps

Image: Contents of the Monster Clarity 200 Wireless Earbuds package.

- Earphones x2 (Left & Right)
- Charging Case x1
- USB-C Charging Cable x1
- Quick Start Guide x1
- Earphone Caps (various sizes)

## PRODUCT OVERVIEW

---

The Monster Clarity 200 earbuds feature a sleek design with in-ear tips for a secure and comfortable fit. The compact charging case provides extended battery life and protects the earbuds when not in use.




Image: Earbuds stored in the charging case.



Image: Detailed view of an individual earbud.


## SETUP

---

### 1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging case and a power source. The indicator lights on the case will show the charging status. A full charge provides up to 5 hours of continuous earbud use, with the charging case extending total playtime to approximately 25 hours.

### 2. Pairing with a Device



## What's in the Box

Earphones x2 (L&R)  
Charging case x1  
USB-C cable x1  
Quick start guide  
Earphone caps

Image: Earbuds and phone illustrating the pairing process.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your mobile device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "Monster Clarity 200 ANC" in the list of available Bluetooth devices.
4. Select "Monster Clarity 200 ANC" to connect. A system tone will confirm successful pairing.

### 3. Wearing the Earbuds

Insert the Monster Clarity 200 ANC earbuds into your ears. Gently rotate them to find a comfortable and secure fit. A proper fit is essential for optimal sound quality and active noise cancellation performance.




Image: User wearing an earbud for comfortable listening.

## OPERATING THE EARBUDS

### Touch Controls

The Monster Clarity 200 earbuds feature capacitive touch controls on each earbud. The following gestures allow you to manage playback, calls, and other functions:



## What's in the Box

Earphones x2 (L&R)  
 Charging case x1  
 USB-C cable x1  
 Quick start guide  
 Earphone caps

Image: Visual guide to earbud touch controls.

Action	Left Earbud	Right Earbud
Previous Track	Click 3 times	N/A
Next Track	N/A	Click 3 times
Volume Down	Click 1 time	N/A
Volume Up	N/A	Click 1 time
Play/Pause	Click 2 times	Click 2 times
Answer/End Call	Click 2 times	Click 2 times
Reject Call	Press and hold for 2 seconds	Press and hold for 2 seconds
Activate Voice Assistant	Press and hold for 2 seconds	Press and hold for 2 seconds
Toggle ANC/Transparency Mode	<i>(Specific gesture not detailed in provided image, typically a long press on one earbud or a dedicated tap. Refer to quick start guide for exact control.)</i>	

## Active Noise Cancellation (ANC)

The three-microphone ANC system effectively minimizes ambient noise, providing a clearer audio experience and allowing for better focus. Refer to the quick start guide for specific instructions on how to activate and deactivate ANC or Transparency mode.

## Call Noise Reduction

With a dual-microphone array and advanced beamforming algorithm, it precisely captures your voice, minimizes environmental noise, and ensures every word is delivered with crystal-clear clarity.



Image: Earbud design emphasizing three-microphone ANC.

## Crystal-Clear Calls

The dual-microphone array structure precisely captures your voice and reduces environmental noise, ensuring clear communication during calls.



## Advanced Call Clarity Technology

Experience crystal-clear calls by blocking out background noise with advanced noise-canceling technology, ensuring clearer communication.

Image: User demonstrating clear call functionality.

## Low Latency Game Mode

Activate the Low Latency Game Mode for a synchronized audio experience with latency as low as 60ms, enhancing your gaming precision.

## Immersive Audio Experience

The bass is rich and detailed, with every note coming alive, immersing you in a sea of music.



Image: Earbuds in use during a gaming session, highlighting low latency.

## MAINTENANCE


---

### Cleaning

Regularly clean your earbuds and charging case to maintain optimal performance and hygiene. Use a soft, dry, lint-free cloth. For ear tips, you may gently wipe them with a slightly damp cloth and mild soap, then dry thoroughly before reattaching.

### Water Resistance

The Monster Clarity 200 earbuds are IPX5 water-resistant, meaning they can withstand splashes and light rain. They are not designed for submersion in water. Ensure the earbuds are dry before placing them back into the charging case to prevent damage.



### What's in the Box

Earphones x2 (L&R)  
Charging case x1  
USB-C cable x1  
Quick start guide  
Earphone caps

Image: Earbuds demonstrating water resistance.

### Storage

When not in use, store the earbuds in their charging case to protect them from dust, damage, and to keep them charged.

## TROUBLESHOOTING

---

- **No Sound:** Ensure earbuds are charged and properly paired. Check device volume and earbud placement.

- **Cannot Pair:** Make sure Bluetooth is enabled on your device and the earbuds are in pairing mode. Try turning Bluetooth off and on again on your device.
- **Intermittent Connection:** Ensure there are no obstructions between the earbuds and your device. Avoid excessive distance from the paired device.
- **One Earbud Not Working:** Place both earbuds back in the charging case, close the lid, wait a few seconds, then take them out again to re-establish connection.
- **Charging Issues:** Verify the USB-C cable is securely connected to both the case and the power source. Ensure the charging contacts on the earbuds and inside the case are clean.

## SPECIFICATIONS

Feature	Detail
Brand	Monster
Model Number	W38
Bluetooth Version	6.0
Ear Placement	In-Ear
Noise Control	Active Noise Cancellation (ANC)
Audio Driver Type	13mm Titanium Diaphragm Dynamic Driver
Earbud Battery Life	Up to 5 hours (continuous use)
Total Playtime (with case)	Up to 25 hours
Control Method	Touch
Water Resistance Level	IPX5 (Splash-proof)
Connectivity Technology	Wireless (Bluetooth)
Compatible Devices	Bluetooth-enabled devices (Android, iOS, HarmonyOS)
Additional Features	Built-in Microphone, Noise Cancellation

## WARRANTY INFORMATION

The Monster Clarity 200 Wireless Earbuds come with a **2-year warranty**. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included in your product packaging or visit the official Monster website.

## CUSTOMER SUPPORT

For any inquiries, feedback, or technical assistance regarding your Monster Clarity 200 Wireless Earbuds, please contact our professional customer service team. We are committed to ensuring your satisfaction. Please visit the official Monster website for contact details or refer to the support information provided in your product packaging.

