

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TOOLCY](#) /

› [TOOLCY Super Flexible Pressure Washer Hose & Gun Instruction Manual](#)

TOOLCY B0FJRZVPJX

TOOLCY Super Flexible Pressure Washer Hose & Gun Instruction Manual

Model: B0FJRZVPJX

INTRODUCTION

This manual provides essential instructions for the safe and effective use, setup, operation, and maintenance of your TOOLCY Super Flexible Pressure Washer Hose and 5000 PSI Pressure Washer Gun. Please read this manual thoroughly before operating the product and retain it for future reference.

SAFETY INFORMATION

WARNING: Pressure washers can cause serious injury if not used correctly. Always follow these safety guidelines:

- Always wear appropriate personal protective equipment, including eye protection, gloves, and hearing protection.
- Never point the spray gun at people, pets, or electrical devices.
- Ensure all connections are secure before operating.
- Do not operate if any part of the equipment is damaged.
- Keep children and bystanders away from the operating area.
- Always relieve pressure before disconnecting the hose or gun.
- Use only with compatible pressure washer units within the specified PSI limits.

PACKAGE CONTENTS

Verify that all items are present and undamaged upon unpacking:

- 1x TOOLCY Super Flexible Pressure Washer Hose (30ft, 3400 PSI)
- 1x TOOLCY Pressure Washer Gun (5000 PSI / 10.5 GPM)
- M22 and 3/8" Quick Connection Kit (various adapters)



Image 1: Contents of the TOOLCY Pressure Washer Hose and Gun Kit, including the blue flexible hose, the black and grey pressure washer gun, and a set of brass and black quick connectors.

SETUP

1. Connect the Hose to the Pressure Washer:

Attach one end of the TOOLCY pressure washer hose to the high-pressure outlet of your pressure washer unit. Ensure a secure, leak-free connection. Use the appropriate M22 or 3/8" quick connector as needed for your specific pressure washer model.

2. Connect the Gun to the Hose:

Attach the other end of the TOOLCY pressure washer hose to the inlet of the TOOLCY pressure washer gun. The gun features a 360° swivel inlet for flexible operation, allowing for easier maneuvering and reducing hose tangles. Ensure this connection is also secure.



KINK RESISTANT COMPARISON



Image 2: Close-up view of the TOOLCY pressure washer gun's 360-degree swivel inlet, showing how the hose connects to allow for flexible rotation during use, preventing tangles.

3. Connect Water Supply:

Connect your pressure washer unit to a suitable water supply according to its manufacturer's instructions.

4. Attach Nozzle (Not Included):

Attach your desired spray nozzle (not included with this kit) to the quick-connect fitting at the end of the pressure washer gun.

OPERATING INSTRUCTIONS

1. Start Water Flow:

Turn on the water supply to the pressure washer unit. Squeeze the trigger on the pressure washer gun to purge air from the system until a steady stream of water emerges.

2. Start Pressure Washer:

Start your pressure washer unit according to its manufacturer's instructions.

3. Begin Cleaning:

Hold the pressure washer gun firmly with both hands. Maintain a safe distance from the surface being cleaned. Squeeze the trigger to begin spraying. The ergonomic design and lightweight trigger of the TOOLCY gun reduce fatigue during extended use.



WITH TPR RUBBER GRIP UPGRADED ERGONOMIC HANDLE



Image 3: A hand demonstrating the grip on the TOOLCY pressure washer gun, highlighting its ergonomic handle with TPR rubber grip and ceramic trigger for comfortable and low-vibration operation.

4. Adjust Spray (with Nozzle):

Adjust the spray pattern by changing nozzles (if applicable) or adjusting the nozzle on your pressure washer gun to suit the cleaning task.

5. Finish Operation:

When finished, release the trigger, turn off the pressure washer unit, and then turn off the water supply. Squeeze the trigger again to relieve any remaining pressure in the system before disconnecting.

MAINTENANCE

- Hose Inspection:** Regularly inspect the pressure washer hose for cuts, abrasions, bulges, or leaks. Replace the hose immediately if any damage is found. The TOOLCY hose is designed to be kink-resistant and durable, but proper care extends its lifespan.
- Gun Inspection:** Check the pressure washer gun for any cracks, leaks, or damage to the trigger

mechanism. Ensure the swivel inlet rotates smoothly.

- **Connection Check:** Periodically check all quick connections and threaded fittings for tightness and wear. Replace O-rings or seals if leaks occur.
- **Cleaning:** After each use, flush the hose and gun with clean water to remove any detergent or debris. Wipe down the exterior surfaces.
- **Storage:** Store the hose and gun in a cool, dry place, away from direct sunlight and freezing temperatures. Coil the hose neatly to prevent kinks.



Image 4: An illustrative diagram of the internal construction of a pressure washer hose, highlighting features that prevent kinking, bubbling, and bursting, contributing to its durability.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No water flow or low pressure from gun	<ul style="list-style-type: none"> Water supply off or restricted Air in the system Hose kinked or blocked Nozzle clogged 	<ul style="list-style-type: none"> Ensure water supply is fully open. Purge air by squeezing trigger with water on, before starting pressure washer. Straighten hose; check for internal blockages. Clean or replace nozzle.
Leaks at connections	<ul style="list-style-type: none"> Loose connections Worn O-rings or seals Incorrect adapter used 	<ul style="list-style-type: none"> Tighten all connections securely. Inspect and replace damaged O-rings or seals. Ensure correct M22 or 3/8" quick connectors are used for your setup.
Hose kinking during use	<ul style="list-style-type: none"> Improper coiling or storage Extreme bending during operation 	<ul style="list-style-type: none"> Uncoil hose fully before use. Avoid sharp bends; the hose is designed to be flexible and kink-resistant, but extreme angles can still cause issues.



SPECIFICATIONS


- Hose Length:** 30 feet
- Hose Inner Diameter:** 1/4 inch
- Hose Max Pressure:** 3400 PSI
- Hose Max Temperature:** 140°F / 60°C
- Gun Max Pressure:** 5000 PSI
- Gun Max Flow Rate:** 10.5 GPM
- Gun Inlet:** M22-14mm (standard) with 360° swivel
- Gun Outlet:** 1/4 inch Quick Connect
- Compatibility:** Universal replacement for most gas power washers up to 7hp/220cc and electric pressure washers. Compatible with brands like Ryobi, Dewalt, Greenworks, Karcher, Craftsman, Honda, Troy Bilt, Generac, Flexzilla, Simpson. *Note: Not compatible with Sun Joe, AR Blue Clean, or other pressure washers with M22-15mm hoses without an additional adapter (M22-14mm Female to M22-15mm Male, sold separately).*

WARRANTY AND SUPPORT

For warranty information or technical support, please contact TOOLCY customer service through the retailer where the product was purchased or visit the official TOOLCY website. Please have your product model number (B0FJRZVPJX) and purchase date available when contacting support.

Related Documents - B0FJRZVPJX

	<p>TOOLCY Electric Pressure Washer TPWUA Series User Manual</p> <p>Comprehensive user manual for the TOOLCY Electric Pressure Washer (TPWUA Series), detailing specifications, intended application, setup guide, safety instructions, and troubleshooting tips for effective and safe operation.</p>
	<p>TOOLCY Electric Pressure Washer Manual (TPWUB Series) - Setup, Safety, and Troubleshooting</p> <p>Comprehensive user manual for the TOOLCY Electric Pressure Washer (TPWUB Series). Includes specifications, setup guide, safety instructions, and troubleshooting tips for optimal use and maintenance.</p>
	<p>TOOLCY OEM Quality Power Washer Pump Instruction Manual</p> <p>Instruction manual for the TOOLCY OEM Quality Power Washer Pump, covering technical specifications, safety guidelines, installation, maintenance, and troubleshooting.</p>
	<p>TOOLCY Electric Pressure Washer TPWUA Series User Manual</p> <p>Comprehensive user manual for the TOOLCY Electric Pressure Washer (TPWUA Series), detailing specifications, intended application, setup guide, safety instructions, and troubleshooting tips for effective and safe operation.</p>
	<p>TOOLCY Electric Pressure Washer Manual (TPWUB Series) - Setup, Safety, and Troubleshooting</p> <p>Comprehensive user manual for the TOOLCY Electric Pressure Washer (TPWUB Series). Includes specifications, setup guide, safety instructions, and troubleshooting tips for optimal use and maintenance.</p>



[TOOLCY OEM Quality Power Washer Pump Instruction Manual](#)

Instruction manual for the TOOLCY OEM Quality Power Washer Pump, covering technical specifications, safety guidelines, installation, maintenance, and troubleshooting.