

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GDFStudio](#) /

› **GDFStudio Aurla Loveseat Sofa Instruction Manual**

GDFStudio Aurla Loveseat Sofa

GDFStudio Aurla Loveseat Sofa Instruction Manual

INTRODUCTION

Thank you for choosing the GDFStudio Aurla Loveseat Sofa. This manual provides essential information for the safe assembly, proper use, and effective maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

The Aurla Loveseat Sofa is designed for comfort and style, featuring a sturdy solid wood frame and high-end breathable fabric with pocket spring filling. It offers a cozy seating experience suitable for various living spaces.

SAFETY INFORMATION

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the loveseat on a soft, clean surface to prevent scratches.
- Always tighten all fasteners securely. Periodically check and re-tighten as needed.
- Do not stand on the loveseat. It is designed for seating purposes only.
- Keep small parts away from children during assembly to prevent choking hazards.
- Distribute weight evenly across the seating area.

PACKAGE CONTENTS

Your GDFStudio Aurla Loveseat Sofa package includes the following components:

- Loveseat Frame (1)
- Seat Cushions (2)
- Back Cushions (2)
- Legs (6)
- Hardware Pack (bolts, washers, Allen wrench)



Image: Overview of the GDFStudio Aurla Loveseat Sofa components.

ASSEMBLY INSTRUCTIONS

Assembly of the GDFStudio Aurla Loveseat Sofa is designed to be straightforward. All necessary tools and instructions are included. It is recommended to have two people for assembly.

- 1. Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to avoid damage. Verify all components listed in the 'Package Contents' section are present.
- 2. Attach Legs:** Locate the six legs and the corresponding attachment points on the underside of the loveseat frame. Securely screw each leg into place. Ensure they are tightened firmly to prevent wobbling.



Image: Detail of a sofa leg attachment.

3. **Position Cushions:** Place the seat cushions onto the loveseat frame, followed by the back cushions. Adjust them for a comfortable fit.
4. **Final Check:** Once assembled, gently test the stability of the loveseat. Ensure all connections are secure before regular use.

OPERATING INSTRUCTIONS

The GDFStudio Aurla Loveseat Sofa is designed for comfortable seating and relaxation. Simply sit and enjoy its plush cushions and supportive structure.

- **Side Storage Pocket:** Utilize the integrated armrest side pocket for convenient storage of items such as magazines, remote controls, or small electronic devices.



Image: Side storage pocket detail.

MAINTENANCE

Proper care will extend the life and appearance of your loveseat.

- Cleaning:** For general cleaning, wipe the fabric with a dry cloth. For spills, blot immediately with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- Cushion Care:** Rotate and fluff cushions regularly to maintain their shape and even out wear.
- Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading. Position your loveseat away from direct sun exposure when possible.
- Keep Dry:** Protect the loveseat from excessive moisture.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Loveseat feels wobbly	Legs are not fully tightened or uneven.	Check and re-tighten all legs. Ensure the loveseat is on a level surface.

Issue	Possible Cause	Solution
Fabric appears discolored or stained	Spill or dirt accumulation.	Refer to the cleaning instructions in the Maintenance section. For stubborn stains, consult a professional upholstery cleaner.
Cushions losing shape	Lack of rotation or fluffing.	Regularly rotate and fluff cushions to maintain their loft and shape.

SPECIFICATIONS

Detailed specifications for the GDFStudio Aurla Loveseat Sofa:

- **Brand:** GDFStudio
- **Type:** Loveseat
- **Color:** White
- **Material:** Fabric
- **Frame Material:** Wood
- **Style:** Contemporary
- **Seating Capacity:** 2
- **Product Dimensions (D x W x H):** 33.07" x 74.27" x 34.65"
- **Seat Height:** 22.44 Inches
- **Item Weight:** 72.7 Pounds
- **Assembly Required:** Yes
- **UPC:** 194798234904
- **ASIN:** B0FJS2N699



Image: Dimensional drawing of the loveseat with key measurements.

WARRANTY INFORMATION

The GDFStudio Aurla Loveseat Sofa comes with a limited manufacturer's warranty.

- **Warranty Type:** Limited
- **Duration:** 90 Days Manufacturer Warranty

Please retain your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your GDFStudio Aurla Loveseat Sofa, please contact our dedicated customer service team.

Email: amazonvendorfeedback@gdfstudio.zendesk.com

Our team is available to help you with assembly, parts, or any product-related inquiries.

