



[Manuals.plus](#) /

> [GarveeLife](#) /

> GarveeLife Large Metal Chicken Coop Instruction Manual (Model gl-PHO_34CGJH8K-df)

GarveeLife gl-PHO_34CGJH8K-df

GarveeLife Large Metal Chicken Coop Instruction Manual

Model: gl-PHO_34CGJH8K-df

1. PRODUCT OVERVIEW

The GarveeLife Large Metal Chicken Coop is designed to provide a secure and spacious outdoor enclosure for poultry and small animals. Constructed from galvanized iron piping, it offers durability and stability. This coop includes an anti-UV cover and is waterproof, protecting animals from various weather conditions. Its generous dimensions of 13.12 x 9.84 x 6.56 ft (4L x 3W x 2H Meters) accommodate 10-20 chickens, or other small animals like ducks, rabbits, and small dogs.



Image 1.1: Fully assembled GarveeLife Large Metal Chicken Coop.

2. SAFETY INFORMATION

- Ensure all connections are secure and tightened during assembly to prevent collapse.
- Regularly inspect the structure for any signs of wear, damage, or loose components.
- The coop is designed for outdoor use. Position it on level ground to maintain stability.

- Keep children and pets away from the assembly area during installation.
- The netting is industrial-strength nylon, but sharp objects can damage it.
- The access door is lockable to prevent escapes and deter predators. Always ensure it is properly secured.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, contact customer service.

- Galvanized Iron Piping (various lengths and bends)
- Reinforced Triangular Corner Braces
- Heavy-Duty Ground Stakes
- Industrial-Strength Nylon Netting
- Anti-UV and Waterproof Cover (Polyester Cover Tarp)
- Lockable Access Door Components
- Spring-Plunger Connectors
- Tool Set (for assembly)
- Instruction Manual

4. SETUP AND ASSEMBLY

The GarveeLife Chicken Coop is designed for easy assembly with intuitive spring-plunger connectors. Follow these steps for proper installation:

1. **Prepare the Site:** Choose a level, clear area for the coop. Ensure adequate drainage and space around the structure for maintenance.
2. **Assemble the Frame:** Connect the galvanized iron pipes using the spring-plunger connectors. Ensure each connection clicks into place securely. Refer to the included diagram for the correct frame structure.
3. **Install Corner Braces:** Attach the reinforced triangular corner braces to the designated corners of the frame for added stability.
4. **Secure to Ground:** Drive the heavy-duty ground stakes into the ground through the base of the frame to anchor the coop firmly.
5. **Attach Netting:** Drape the industrial-strength nylon netting over the frame. Secure it tightly using the provided fasteners (e.g., zip ties, if included, or other securing mechanisms). Ensure there are no gaps that animals could exploit.
6. **Install Door:** Assemble and attach the lockable access door according to the instructions. Verify that it opens and closes smoothly and locks securely.
7. **Apply Cover:** Position the anti-UV and waterproof cover over the top section of the coop. Secure it to the frame to protect against sun and rain.

SOLVING WEATHER ISSUES

PE-Coated waterproof cover and galvanized iron pipe



Image 4.1: Key assembly features including spring plungers, corner braces, ground stakes, and the lockable door.

5. OPERATING INSTRUCTIONS

This chicken coop provides a safe and spacious environment for your animals. Follow these guidelines for optimal use:

- **Animal Capacity:** The coop is designed for 10-20 chickens. For optimal comfort, consider the recommended space per bird: 0.5 to 1 sq.ft for baby chicks, and 4 to 10 sq.ft for roosters or hens.

- **Secure Entry:** Always ensure the lockable access door is properly closed and secured when animals are inside to prevent escape and protect from predators.
- **Weather Protection:** The anti-UV and waterproof cover provides protection from sun and rain. Ensure it is securely fastened, especially during strong winds.
- **Multifunctional Use:** This enclosure is suitable for various small animals, including chickens, ducks, rabbits, and small dogs. Adjust internal setups (e.g., roosting bars, feeders, waterers) as needed for the specific animals housed.

Dimensions of Comfort

Baby Chicks: 0.5 to 1 sq.ft per bird.

Roosters or hens: 4 to 10 sq.ft per bird.




Image 5.1: The coop's multifunctional design for various small animals.

Multifunction



Chicken



Ducks



Rabbits



Dogs



Image 5.2: The coop's weather protection features, including a PE-coated waterproof cover and galvanized iron pipe construction.

6. MAINTENANCE

Regular maintenance ensures the longevity and safety of your GarveeLife Chicken Coop:

- **Cleaning:** Periodically clean the netting and frame to remove dirt, debris, and animal waste. A mild soap and water solution can be used.

- **Cover Inspection:** Check the anti-UV and waterproof cover for tears or damage, especially after severe weather. Replace if necessary to maintain protection.
- **Structural Integrity:** Inspect all pipe connections, corner braces, and ground stakes regularly. Tighten any loose connections and replace damaged parts promptly.
- **Netting Check:** Examine the nylon netting for holes or weak spots. Repair or reinforce any compromised areas to prevent animal escapes or predator entry.
- **Door Mechanism:** Ensure the lockable door mechanism is functioning correctly. Lubricate moving parts if they become stiff.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Coop feels unstable or wobbly.	Loose pipe connections or insufficient ground anchoring.	Ensure all spring-plunger connectors are fully engaged. Verify ground stakes are firmly driven into the ground. Add additional anchoring if needed.
Water pooling inside the coop.	Cover not properly installed or damaged.	Check that the waterproof cover is securely attached and covers the entire top area. Inspect for tears and repair or replace the cover if damaged.
Animals escaping or predators entering.	Gaps in netting or unsecured door.	Inspect the nylon netting for any holes or loose sections and repair them. Ensure the lockable access door is fully closed and secured at all times.
Difficulty assembling pipes.	Misalignment or spring-plunger not engaging.	Ensure pipes are correctly oriented according to the diagram. Apply gentle pressure and wiggle to align the spring-plunger with the receiving hole.

8. SPECIFICATIONS

- **Model Number:** gl-PHO_34CGJH8K-df
- **Dimensions (L x W x H):** 13.12 x 9.84 x 6.56 ft (4L x 3W x 2H Meters)
- **Material:** Galvanized Iron (Frame), Industrial-Strength Nylon (Netting), PE-Coated Polyester (Cover)
- **Color:** Silver
- **Weight:** 32.9 kg (approximately 72.5 lbs)
- **Capacity:** Suitable for 10-20 chickens
- **Special Features:** Durable, Waterproof, Weather-proof, Multifunctional, Easy to install, Spacious



Image 8.1: Dimensional drawing of the chicken coop with recommended animal spacing.

9. WARRANTY AND SUPPORT

GarveeLife provides a **2-Year Warranty** for this product. This warranty covers shipping damage, parts failure under normal use, and any other functional issues for one full year from the date of purchase. For assistance or replacement parts, please contact our customer service team. Our support team is available to help with any questions or concerns you may have regarding assembly, operation, or maintenance.

Customer Service Contact: Refer to your purchase documentation or the GarveeLife official website for contact information.

