

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Volkano](#) /

› [Volkano Galena Series Wireless Keyboard VK-20247-BK Instruction Manual](#)

Volkano VK-20247-BK

Volkano Galena Series Wireless Keyboard Instruction Manual

Model: VK-20247-BK

INTRODUCTION

The Volkano Galena Series Wireless Keyboard is a compact, versatile input device designed for efficiency and portability. It offers multi-device connectivity and seamless switching, making it suitable for various operating systems including Windows, Android, and MacOS. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your keyboard.

PACKAGE CONTENTS

- Volkano Galena Series Wireless Keyboard
- 2 x AAA Batteries
- Instruction Manual

SETUP

1. Battery Installation

The Volkano Galena Series Wireless Keyboard operates on two AAA batteries. These are included in the package.

1. Locate the battery compartment cover on the underside of the keyboard.
2. Slide the cover open.
3. Insert the two AAA batteries, ensuring correct polarity (+ and - terminals).
4. Close the battery compartment cover securely.

2. Powering On/Off

Locate the power switch on the keyboard. Slide it to the 'ON' position to power on the keyboard. Slide it to the 'OFF' position when not in use to conserve battery life. The keyboard features an auto-power saving mode to further extend battery life during periods of inactivity.

3. Bluetooth Pairing

The keyboard supports Bluetooth 5.0 for a stable wireless connection. It can be paired with up to two devices simultaneously.

GALENA SERIES

Compact Bluetooth Keyboard



Bluetooth:
BT 5.0 + BT 3.0



Bluetooth Device
Switching



Anti-Slip
Rubber Feet



Connects to
Multiple Devices



Windows &
Android

Image: The Volkano Galena Series keyboard, illustrating its compact design and key features such as Bluetooth 5.0 + BT 3.0 connectivity, multi-device switching, anti-slip rubber feet, and compatibility with Windows and Android operating systems.

1. Ensure the keyboard is powered on.
2. On your device (Laptop, PC, Smart TV, Tablet), enable Bluetooth and search for available devices.
3. Press and hold the **Fn + 1** key combination for the first device, or **Fn + 2** for the second device, until the corresponding indicator light (usually above the '1' or '2' key) starts blinking, indicating pairing mode.
4. Select "Volkano Galena" or a similar name from the list of available Bluetooth devices on your screen.
5. Follow any on-screen prompts to complete the pairing process. The indicator light will stop blinking once successfully paired.

OPERATING INSTRUCTIONS

1. Multi-Device Switching

The keyboard allows for quick switching between two paired devices.

Compact



Image: A detailed view of the Volkano Galena Series keyboard, showcasing its compact form factor and features like Bluetooth device switching, non-slip feet, a dedicated Copilot shortcut key, scissor-structure keycaps, and auto-power saving mode.

- To switch to the first paired device, press **Fn + 1**.
- To switch to the second paired device, press **Fn + 2**.

2. Function Keys (Fn)

The keyboard includes multimedia and special function keys accessible by pressing the **Fn** key in combination with the corresponding F-keys or other designated keys.

- **Fn + F1-F12**: Access various multimedia controls and system functions (e.g., volume, playback, screen brightness). Refer to the icons on the F-keys for specific functions.
- **Fn + Q/W/E**: Switch between operating system layouts (e.g., Android, Windows, iOS/MacOS).
- **Copilot Shortcut Key**: A dedicated key for quick access to AI assistant features on compatible operating systems.

3. Typing Experience

The keyboard features quiet keys with a scissor structure, providing a comfortable and responsive typing experience suitable for

focused environments.

MAINTENANCE

1. Cleaning

- Ensure the keyboard is powered off before cleaning.
- Use a soft, dry, lint-free cloth to wipe the surface of the keyboard.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not spray cleaning solutions directly onto the keyboard.
- Use compressed air to remove debris from between the keys.

2. Storage

- Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, remove the AAA batteries to prevent leakage.

TROUBLESHOOTING

- **Keyboard not powering on:** Check if the batteries are correctly inserted and fully charged. Replace batteries if necessary. Ensure the power switch is in the 'ON' position.
- **Keyboard not connecting via Bluetooth:**
 - Ensure Bluetooth is enabled on your device.
 - Make sure the keyboard is in pairing mode (indicator light blinking).
 - Delete previous pairings on your device and attempt to re-pair.
 - Ensure the keyboard is within the 8-10 meter Bluetooth range of your device.
 - Try restarting both the keyboard and your device.
- **Keys not responding:** Check battery level. Ensure the keyboard is properly connected to your device. Clean any debris from around the keys.
- **Lag or delayed input:** Ensure there are no strong interferences (e.g., other wireless devices) nearby. Check battery level.

SPECIFICATIONS



Image: A clear, angled view of the Volkano Galena Series Wireless Keyboard, highlighting its sleek black design and full key layout.

Feature	Detail
Model Number	VK-20247-BK
Connectivity	Bluetooth Wireless Technology
Bluetooth Version	Bluetooth 5.0 + Bluetooth 5.0 (Dual Channel)
Wireless Range	8-10 meters
Power Source	2 x AAA Alkaline Batteries (included)
Key Type	Scissor Structure Keycaps
Special Features	Quiet keys, Multi-device pairing, Instant switching, Anti-slip rubber base, Auto-power saving mode, Lightweight, Portable, Copilot Shortcut Key
Compatible Devices	Laptop, PC, Smart TV, Tablet (Windows, Android, MacOS)
Dimensions (L x W x H)	29.5L x 12.8W x 2.2H centimetres
Material	Plastic
Color	Black

WARRANTY AND SUPPORT

1. Limited Warranty

This Volkano product is covered by a 12-Month Limited Coverage from the date of purchase. You can extend this coverage by an additional 12 months, for a total of 24 months, by registering your product with Volkano.

2. Customer Support

For any questions, assistance, or support regarding your Volkano Galena Series Wireless Keyboard, please contact Volkano customer service through their official channels. Refer to the Volkano website or product packaging for contact details.