

[Manuals.plus](#) /

› [plimpton](#) /

› Plimpton Kids20 10-inch Android 15 Tablet User Manual

plimpton Kids20

Plimpton Kids20 10-inch Android 15 Tablet User Manual

Model: Kids20

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Plimpton Kids20 10-inch Android 15 Tablet. Please read these instructions carefully before operating the device.

Package Contents:

- Plimpton Kids20 Android 15 Tablet (with protective EVA case)
- USB-C Charging Cable
- Power Adapter
- User Manual (this document)
- Tempered Film (screen protector)
- Tablet Storage Bag (may vary by package)



Image: The Plimpton Kids20 tablet in its blue protective case, alongside a USB-C charging cable, power adapter, tempered film, and user manual.

2. INITIAL SETUP

2.1 Charging the Tablet

Before first use, fully charge the tablet. Connect the USB-C cable to the tablet's charging port and the power adapter, then plug the adapter into a wall outlet. The charging indicator will show the charging status.




64GB ROM



12GB(4+8) RAM



Android 15



8-Core CPU



1.8M charging cable length



1TB SD

(Sold Separately)



**Eye protection
mode**

Image: Close-up of the Plimpton Kids20 tablet's side, showing the USB-C charging port and other buttons.

2.2 Powering On/Off

- To power on: Press and hold the Power button located on the side of the tablet until the screen turns on.
- To power off: Press and hold the Power button, then select "Power off" from the options that appear on the screen.

2.3 Wi-Fi Connection

1. Go to **Settings**.
2. Select **Network & Internet**.
3. Tap **Wi-Fi** and turn it on.
4. Select your desired Wi-Fi network from the list.
5. Enter the password if prompted and tap **Connect**.

3. OPERATING INSTRUCTIONS

3.1 Google Kids Space

The Plimpton Kids20 tablet comes pre-installed with Google Kids Space, offering a curated selection of apps, books, and videos for children. This mode provides a child-friendly interface and content tailored for various age groups.


Android 15


Privacy management


Simple operation


Octa-core


Parental Controls


6000 mAh battery

A full-feature tablet for kids

Made for kids and loved by parents, this tablet for 3-7 year-old is meant to last, with robust parental controls, a bright, 10.1" 1080p Full HD display, and 25% faster performance than the previous generation. Plus, the kid-proof case with kickstand stands up to all their adventures.

Image: A child interacting with the Google Kids Space interface on the Plimpton Kids20 tablet, showing various educational and entertainment apps.

3.2 Parental Controls (Google Family Link)

Parents can manage content, set screen time limits, and monitor activity using Google Family Link. This feature allows for a safe and controlled digital environment for children.

1. Download the Google Family Link app on your own device.
2. Follow the on-screen instructions to link your child's Plimpton Kids20 tablet.
3. Customize settings such as app approvals, content filters, and daily screen time limits.



Family Link

Set Boundaries with Parental Controls
via the Google Family Link App to Control






Image: A parent and child using the Plimpton Kids20 tablet, with an overlay showing the Google Family Link parental control interface on a smartphone.

3.3 App Management

Apps can be downloaded from the Google Play Store. Parental controls can restrict access to certain apps or prevent unauthorized downloads.



Image: The Plimpton Kids20 tablet screen displaying numerous app icons, indicating access to a wide range of applications.

3.4 Media Playback

The tablet supports various media formats for videos and music. YouTube Kids is pre-installed for child-safe video content.

Your browser does not support the video tag.

Video: A demonstration of the Plimpton Kids20 tablet's parental control features, highlighting how parents can manage content and usage.

4. KEY FEATURES

- **Operating System:** Android 15 for a user-friendly and secure experience.
- **Processor:** Octa-Core 2.0GHz for smooth performance.
- **Display:** 10.1-inch HD IPS glass screen (1280 x 800 resolution) with eye protection mode.
- **Memory & Storage:** 4GB RAM + 64GB internal storage, expandable up to 1TB via microSD card.
- **Protective Case:** Rugged, anti-drop EVA material case with a 360° rotatable stand.

- **Battery:** Optimized for extended daily use.




Image: The Plimpton Kids20 tablet in its blue protective case, showcasing the integrated stand for hands-free viewing.

Your browser does not support the video tag.

Video: A brief overview of the Plimpton Kids20 tablet's features, including its Android 15 operating system and 8-core processor.

5. MAINTENANCE

5.1 Cleaning

To clean the tablet screen, use a soft, lint-free cloth. For the protective case, a damp cloth with mild soap can be used. Avoid harsh chemicals or abrasive materials.

5.2 Battery Care

- Avoid completely draining the battery regularly.

- Do not expose the tablet to extreme temperatures.
- Use only the provided charger and cable.

5.3 Software Updates

Periodically check for system updates in the tablet's settings to ensure optimal performance and security. Connect to Wi-Fi before performing updates.

6. TROUBLESHOOTING

Problem	Solution
Tablet won't turn on	Ensure the tablet is fully charged. Press and hold the power button for 10-15 seconds.
Slow performance	Close unused apps, clear cache, or perform a factory reset (backup data first).
Wi-Fi connection issues	Restart the tablet and your Wi-Fi router. Ensure the Wi-Fi password is correct.
Apps crashing	Update the app to the latest version. Clear the app's cache and data in settings.

7. SPECIFICATIONS

Feature	Detail
Standing screen display size	10.1 Inches
Screen Resolution	1280 x 800 pixels
Processor	2 GHz Octa-Core
Operating System	Android 15
RAM	4 GB
Memory Storage Capacity	64 GB (expandable to 1TB)
Wireless Type	802.11n (Wi-Fi), BT5.3 (Bluetooth)
Average Battery Life	8 Hours
Item Weight	2.61 pounds
Product Dimensions	10.86 x 7.83 x 1.22 inches

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The Plimpton Kids20 tablet comes with a 1-year warranty from the date of purchase. Additionally, a 30-day worry-free return and replacement policy is offered. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact Plimpton customer support. Contact details

can typically be found on the official Plimpton website or through the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question