

[Manuals.plus](#) /

› [Globe Electric](#) /

› GLOBE Electric 60000164 1-Light Outdoor Flush Mount Instruction Manual

Globe Electric 60000164

GLOBE Electric 60000164 1-Light Outdoor Flush Mount Instruction Manual

Model: 60000164 | Brand: Globe Electric

PRODUCT OVERVIEW

The Globe Electric 60000164 1-Light Outdoor Flush Mount is designed to provide illumination for outdoor spaces. This fixture features a matte black finish and a frosted glass shade, offering a modern transitional aesthetic. It is suitable for various outdoor environments such as porches, balconies, and decks.



Image: The GLOBE Electric 60000164 1-Light Outdoor Flush Mount, showcasing its matte black frame and frosted glass shade.

Key Features:

- **Modern Transitional Design:** Matte black finish with frosted glass complements various outdoor decors.
- **Frosted Glass Shade:** Provides an even and diffused light distribution.
- **Bulb Requirements:** Requires 1x E26/Medium Base 60W bulb (sold separately). LED or incandescent bulbs are recommended.
- **Dimmable:** Compatible with a dimmer switch (sold separately) for adjustable brightness.
- **Easy Installation:** Includes all necessary mounting hardware for straightforward setup.
- **Weather Resistant:** Designed for outdoor use, capable of withstanding various weather conditions.

SAFETY INFORMATION

Please read and understand all instructions before beginning installation. Failure to do so may result in electric shock, fire, or other injuries that could be hazardous or fatal. All wiring connections must be in accordance with local and national electrical codes (NEC). If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.

- **WARNING:** To avoid electric shock, disconnect power at the circuit breaker or fuse box before installation.
- **CAUTION:** Use only with bulbs rated for the fixture. Do not exceed the maximum wattage.
- Ensure all connections are secure and properly insulated.
- Do not install on surfaces that are not structurally sound.

PACKAGE CONTENTS

Verify that all components listed below are included in your package before proceeding with installation.

- 1 x Light Fixture (Matte Black Frame with Frosted Glass Shade)
- 1 x Mounting Hardware Kit (includes screws, wire nuts, and mounting plate)
- 1 x Instruction Manual

Note: Bulb (E26/Medium Base 60W) is sold separately and is not included in the package.

SETUP AND INSTALLATION

This outdoor flush mount is designed for easy installation. Follow these steps carefully.

1. **Turn Off Power:** Before starting, ensure the power to the installation area is turned off at the circuit breaker or fuse box to prevent electrical shock.
2. **Prepare Mounting Surface:** Ensure the ceiling or wall surface is clean, dry, and structurally sound to support the fixture.
3. **Attach Mounting Plate:** Secure the mounting plate to the junction box using the provided screws. Ensure it is firmly attached.
4. **Make Electrical Connections:**
 - Connect the ground wire (usually bare copper or green) from the fixture to the ground wire from the junction box.
 - Connect the white wire (neutral) from the fixture to the white wire from the junction box.
 - Connect the black wire (live) from the fixture to the black wire from the junction box.
 - Secure all connections with wire nuts and wrap with electrical tape for added safety.
5. **Mount the Fixture:** Carefully align the fixture with the mounting plate and secure it using the provided screws or nuts. Ensure the fixture is flush against the surface.
6. **Install Bulb:** Insert one E26/Medium Base 60W maximum bulb (sold separately) into the socket. Do not overtighten.
7. **Restore Power:** Once the fixture is securely installed and the bulb is in place, restore power at the circuit breaker.



Image: A close-up view of the light fixture's matte black frame and frosted glass, illustrating its construction for installation.



Image: The flush mount light installed on a garage ceiling, demonstrating its outdoor application.




Image: The flush mount light installed above a front door, showcasing another common outdoor placement.

OPERATING INSTRUCTIONS

The Globe Electric 60000164 flush mount operates via a standard wall light switch. For dimming functionality, ensure a compatible dimmer switch is installed (sold separately).

- **Turning On/Off:** Use the wall light switch connected to the fixture to turn the light on or off.
- **Dimming:** If a compatible dimmer switch is installed, adjust the dimmer control to achieve the desired brightness level.
- **Bulb Selection:** Choose a lower wattage bulb for a softer glow or a higher wattage bulb (up to 60W) for brighter illumination.



Image: The flush mount light illuminated, showcasing the warm glow provided by the frosted glass shade.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your light fixture.

- **Cleaning:** To clean the fixture, turn off the power and wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents as they may damage the finish or glass.
- **Bulb Replacement:**
 - a. Turn off power at the circuit breaker.
 - b. Allow the old bulb to cool completely before touching.
 - c. Carefully unscrew the old bulb.
 - d. Screw in a new E26/Medium Base bulb, ensuring it does not exceed 60W.
 - e. Restore power.
- **Inspection:** Periodically check for any loose connections or signs of wear. If any damage is observed, consult a qualified electrician.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker or fuse.
	Loose wiring connection.	Verify all wiring connections are secure.
	Faulty bulb.	Replace bulb with a new one.
Light flickers.	Loose bulb.	Tighten bulb.
	Incorrect bulb type for dimmer.	Ensure bulb is dimmable and compatible with your dimmer switch.
	Loose wiring.	Check wiring connections.
Dimming not working.	Non-dimmable bulb.	Use a dimmable bulb.
	Incompatible dimmer switch.	Ensure dimmer switch is compatible with LED or incandescent bulbs.

SPECIFICATIONS

Model Number	60000164
Brand	Globe Electric
Color	Matte Black, Frosted Glass
Material	Metal, Glass
Dimensions (L x W x H)	10"L x 10"W x 4.75"H (25.4 cm L x 25.4 cm W x 12 cm H)
Item Weight	4 Pounds
Power Source	Hardwired
Voltage	120 Volts
Wattage (Max)	60 watts
Bulb Base	E26 (Medium Base)
Indoor/Outdoor Usage	Outdoor
Water Resistance Level	Water Resistant
Installation Type	Flush Mount
UPC	058219868836




Image: Diagram showing the dimensions of the flush mount fixture: 10 inches (25.4 cm) length, 10 inches (25.4 cm) width, and 4.75 inches (12 cm) height.

WARRANTY AND SUPPORT

This Globe Electric product is covered by a **1-year limited manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For technical support, warranty claims, or replacement parts, please contact Globe Electric customer service. Refer to the contact information provided on the product packaging or the official Globe Electric website.

Online Resources: For additional information and support, visit the [Globe Electric Store on Amazon](#).

© 2024 Globe Electric. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question