

[Manuals.plus](#) /

› [Midea](#) /

› Midea MERI26B1AGN Ice Maker Countertop, Portable Ice Maker 26lbs, 8 Cubes Ready in 6 Mins, Self-Cleaning with Ice Basket and Scoop, 2 Sizes of Bullet Ice for Home, Camping, Office, Party

Midea MERI26B1AGN

Midea MERI26B1AGN Ice Maker User Manual

Model: MERI26B1AGN

1. INTRODUCTION

Thank you for purchasing the Midea MERI26B1AGN Countertop Ice Maker. This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your ice maker. Please read this manual thoroughly before using the appliance and retain it for future reference.

This portable ice maker is designed to produce bullet-shaped ice cubes quickly and efficiently, suitable for home, office, camping, or party use.

2. SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not touch the evaporator or ice blades when the unit is operating.
- Do not immerse the cord, plug, or any part of the unit in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only potable water for ice production.
- Ensure the appliance is placed on a stable, level surface away from direct sunlight or heat sources.
- Unplug the appliance from the outlet before cleaning or performing any maintenance.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Midea ice maker:



Image: The Midea MERI26B1AGN ice maker in a light green color, with its transparent lid open, revealing a basket full of bullet-shaped ice cubes. To the left, a glass of iced tea with ice, and in the foreground, a clear plastic ice scoop with ice cubes. The Midea logo is visible on the front of the unit.

- **Control Panel:** Contains indicator lights and buttons for operation.

- **Ice Basket:** Removable basket for collecting produced ice.
- **Water Reservoir:** Area where water is stored for ice production.
- **Ice Scoop:** Included for convenient ice retrieval.
- **Transparent Lid:** Allows monitoring of ice levels.
- **Air Vent:** Located on the side for heat dissipation.

4. SETUP

Before first use, follow these steps:

1. Unpack the appliance and remove all packaging materials.
2. Place the ice maker on a flat, stable surface, ensuring adequate ventilation around the unit (at least 4 inches of space on all sides).
3. Clean the interior of the ice maker, ice basket, and ice scoop with a soft cloth and warm water.
4. Allow the unit to rest for at least 2 hours before plugging it in, especially if it has been tilted during transport. This allows the refrigerant to settle.
5. Plug the ice maker into a grounded electrical outlet.

5. OPERATING INSTRUCTIONS

5.1 Filling the Water Reservoir

1. Open the transparent lid.
2. Remove the ice basket.
3. Fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
4. Replace the ice basket and close the lid.

5.2 Starting Ice Production

1. Press the POWER button to turn on the ice maker.
2. Select your desired ice cube size (Small or Large) by pressing the SELECT button. The corresponding indicator light will illuminate.
3. The ice maker will begin the ice-making cycle. The first batch of ice typically takes 6-10 minutes.
4. The "ICE FULL" indicator light will illuminate when the ice basket is full. The unit will automatically stop ice production.
5. The "ADD WATER" indicator light will illuminate when the water reservoir is low. Add more water to resume ice production.

5.3 Stopping Ice Production

Press the POWER button again to stop the ice maker at any time.

6. MAINTENANCE

6.1 Self-Cleaning Function

The ice maker features a one-touch auto-clean function:

1. Ensure the water reservoir is filled with clean water.
2. Hold the POWER button for 3 seconds to initiate the self-cleaning cycle.
3. The cleaning cycle will run for a few minutes.

4. Once complete, drain the water from the unit by removing the drain plug located at the bottom.

6.2 General Cleaning and Care

- Always unplug the appliance before cleaning.
- Clean the interior with a soft cloth dampened with warm water and a mild detergent. Rinse thoroughly.
- Clean the exterior with a soft, damp cloth.
- Regularly clean the air vents on the side of the unit to ensure proper airflow and prevent overheating. Use a soft brush or vacuum cleaner.
- When not in use for an extended period, drain all water, clean the unit, and store it in a dry, well-ventilated area.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Ice maker not working	No power; Unit too hot; Compressor issue.	Check power connection; Ensure proper ventilation; Contact customer support.
"ADD WATER" light on	Water reservoir is empty or low.	Add potable water to the reservoir up to the MAX line.
"ICE FULL" light on	Ice basket is full.	Remove ice from the basket.
Ice cubes are small or clumpy	Water temperature too high; Ambient temperature too high.	Use colder water; Place unit in a cooler environment.
Unusual noise during operation	Unit not level; Internal component issue.	Ensure unit is on a level surface; Contact customer support if noise persists.

If the problem persists after attempting the solutions above, please contact Midea customer support.

8. SPECIFICATIONS

Specification	Detail
Brand	Midea
Model Name	Countertop Ice Maker
Product Dimensions	11.6"D x 8.4"W x 11.6"H
Capacity	26 Pounds (daily production)
Voltage	115 Volts
Refrigerant	R600a
Item Weight	15.76 pounds
ASIN	B0FJWYVS31
Item Model Number	MERI26B1AGN

Specification	Detail
UPC	840296516508

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Midea website or contact their customer service directly. Keep your purchase receipt for warranty claims.

Online Resources:

- Official Midea Store: [Visit the Midea Store on Amazon](#)
- User Manual (PDF): [Download User Manual](#)

© 2025 Midea. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question