

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [FEZIBO](#) /

› FEZIBO Electric Standing Desk (Model 40x24 Black) User Manual

FEZIBO 40x24 Black

FEZIBO Electric Standing Desk (Model 40x24 Black) User Manual

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your FEZIBO Electric Standing Desk, model 40x24 Black. Please read this manual thoroughly before assembly and use to ensure proper function and safety.



Image: FEZIBO Electric Standing Desk, 40x24 Black.

SAFETY INFORMATION

- Ensure all components are present and undamaged before assembly.
- Follow assembly instructions carefully. Incorrect assembly can lead to instability or injury.
- Keep children and pets away from the desk during operation to prevent accidents.
- Do not overload the desk. Refer to the specifications for maximum weight capacity.
- Ensure there are no obstructions in the desk's path during height adjustment to prevent damage or injury. The desk features an anti-collision system, but manual checks are recommended.
- Only use the provided power adapter and cable.
- Disconnect power before cleaning or maintenance.

PACKAGE CONTENTS

Verify that all parts are included in your package. The desk platform is typically packaged in two sections. Assembly tools and detailed instructions are provided.

- Desktop sections (2)
- Desk frame components (legs, crossbar, feet)
- Control panel
- Power adapter and cable
- Assembly hardware (screws, bolts, etc.)
- Assembly tools
- Desk hooks (optional installation)

ASSEMBLY INSTRUCTIONS

Assembly is required for this product. A detailed installation video may be available from the manufacturer. The process typically takes approximately 1.5 hours for one person.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all components against the package contents list.
2. **Assemble the Frame:** Attach the desk legs to the crossbar using the provided hardware. Ensure all connections are secure.





Image: Steel frame components before desktop attachment.

3. **Attach Feet:** Secure the feet to the bottom of the desk legs. These provide stability.




Frame Base

Enhance the stability of the desk

Image: Detail of the frame base for enhanced stability.

4. **Assemble Desktop:** Join the two desktop sections together using the precise screws and accessories. Ensure the seam is aligned and secure.
5. **Attach Desktop to Frame:** Carefully place the assembled desktop onto the frame and secure it using the designated screws.



Black Top/Black Frame

Simple Assembly:

The desk platform comes packaged in 2 sections for assembly by the precise screws and accessories



Elegant Workspace

Organize Your Workspace with Upgraded Comfort and Connectivity

Image: Desktop attachment to the frame.

6. **Install Control Panel:** Mount the control panel to the underside of the desktop in the desired location. Connect the necessary cables to the motor and power supply.
7. **Optional: Install Desk Hooks:** Attach the provided desk hooks to the underside of the desktop if desired. These are suitable for hanging headphones or bags.

Desk Hooks (set of 2)

Feel free to hook your headphones and bags on it



Image: Optional desk hooks for accessories.

8. **Connect Power:** Plug the power cable into the desk's control box and then into a wall outlet.

OPERATING INSTRUCTIONS

Height Adjustment

The desk's electric lifting system allows for smooth height adjustments between 27.3 inches and 45.5 inches.

- **Raise Desk:** Press and hold the **Up arrow (^)** button on the control panel.
- **Lower Desk:** Press and hold the **Down arrow (v)** button on the control panel.

Sitting and Standing Height Adjustment Range 28.3"-45"



Image: Desk height adjustment range from sitting to standing.

Memory Presets

The control panel features two programmable memory height buttons to save your preferred sitting and standing heights.



Image: Control panel with up/down and memory buttons.

1. Set a Memory Position:

- Adjust the desk to your desired height using the Up/Down buttons.
- Press and hold one of the memory buttons (**1** or **2**) until the display flashes or a beep is heard, indicating the position is saved.

- Recall a Memory Position:** Press the corresponding memory button (**1** or **2**) once. The desk will automatically move to the saved height.

Anti-Collision Technology

The desk is equipped with an anti-collision system. If the desk encounters an obstacle during height adjustment, it will automatically stop and move approximately 2 cm in the opposite direction to prevent potential damage or injury.

Anti-Collision Technology

Auto-sensing anti-collision system protects your desk



Image: Anti-collision system detecting an obstacle.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your desk.

- **Cleaning:** The desktop surface is scratch-proof and waterproof. Use a soft, damp cloth with mild soap to clean the surface. Avoid abrasive cleaners or harsh chemicals.



Image: Desktop surface demonstrating water resistance.

- **Inspections:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Cable Management:** Ensure power cables and other cords are neatly managed to prevent entanglement or

damage during height adjustments.

TROUBLESHOOTING

If you encounter issues with your FEZIBO Electric Standing Desk, consider the following common solutions:


- **Desk Not Moving:** Check if the power cable is securely plugged into both the desk and the wall outlet. Ensure the outlet is functional.
- **Uneven Movement:** Ensure the desk is not overloaded and that weight is distributed evenly. Check for any obstructions.
- **Error Codes:** If the control panel displays an error code, refer to the manufacturer's online resources or contact customer support for specific guidance.
- **Reset Procedure:** Some issues can be resolved by performing a reset. Consult the manufacturer's website or support for the specific reset procedure for your model.

If problems persist, please contact FEZIBO customer support for assistance.

SPECIFICATIONS

Feature	Detail
Model	40x24 Black
Product Dimensions (D x W x H)	24"D x 40"W x 28.3"H (minimum height)
Height Adjustment Range	27.3" - 45.5"
Top Material	Engineered Wood (Laminated)
Base Material	Alloy Steel
Noise Level	Under 50 dB
Lift Test Durability	50,000 cycles with full load
Special Features	Electric Height Adjustment, 2 Memory Presets, Anti-Collision Technology, Scratch-proof & Waterproof Top
Assembly Required	Yes

Product Dimensions



Various Colors:



Image: Detailed product dimensions.




Image: Noise level comparison during desk operation.

WARRANTY AND SUPPORT

For any questions, warranty concerns, or technical support regarding your FEZIBO Electric Standing Desk, please contact FEZIBO customer service. Contact information can typically be found on the manufacturer's official website or through your purchase platform.

Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details.](#)

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FJXY2MNL>

More documents and user manuals: <https://manuals.plus/>