

Bontempi 10 3030

Bontempi Electronic Grand Piano 32-Key with Microphone and Stool

INSTRUCTION MANUAL

INTRODUCTION

Thank you for choosing the Bontempi Electronic Grand Piano. This manual provides essential information for the safe and proper use, assembly, and maintenance of your new instrument. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

- **Age Recommendation:** This product is suitable for children aged 0-6 years. Adult supervision is recommended during play.
- **Battery Safety:** Use 4 x 1.5V R6/AA batteries (not included). Do not mix old and new batteries, or different types of batteries. Insert batteries with correct polarity. Remove exhausted batteries promptly. Do not recharge non-rechargeable batteries. Remove batteries if the product will not be used for an extended period.
- **Choking Hazard:** This product contains small parts (e.g., screws, battery cover). Ensure all components are securely fastened before use. Keep packaging materials away from children.
- **Electrical Safety:** Do not expose the product to water or moisture. Do not attempt to disassemble or modify the product. Use only the provided external music source cable.
- **Placement:** Place the piano on a stable, flat surface to prevent tipping.

PACKAGE CONTENTS

Carefully unpack the box and ensure all items are present:

- Electronic Grand Piano (32-key keyboard with legs)
- Adjustable Microphone with Stand
- Stool
- External Music Source Cable (for MP3 player/smartphone connection)



Image: The Bontempi Electronic Grand Piano, microphone, and stool packaged in its retail box.

SETUP INSTRUCTIONS

1. **Unpack:** Remove all components of the electronic piano from its packaging.
2. **Install Batteries:** Locate the battery compartment (usually on the underside of the piano). Insert 4 x 1.5V R6/AA batteries (not included), ensuring correct polarity (+/-). Securely close the battery compartment.
3. **Assemble Stool:** If the stool requires assembly, follow the specific instructions provided with the stool to ensure it is stable and safe for sitting.
4. **Position Microphone:** Attach the microphone to its adjustable stand and connect it to the designated microphone input on the piano. Adjust the stand to a comfortable height.
5. **Placement:** Place the assembled piano and stool in a suitable playing area.



Image: The Bontempi Electronic Grand Piano fully assembled with the microphone and stool, ready for use.

OPERATING INSTRUCTIONS

Power On/Off

- Locate the ON/OFF switch, usually on the control panel. Slide it to the 'ON' position to power on the piano.
- To turn off, slide the switch to the 'OFF' position.

Playing the Piano

- Press the 32 keys to play individual notes.
- Use the dedicated buttons on the control panel to select from 5 different instrument sounds.

Using the Microphone

- Ensure the microphone is securely connected.
- Speak or sing into the microphone while playing the piano.

Rhythms and Songs

- Press the 'Rhythm' buttons to choose from 4 different rhythms with arrangements.
- Press the 'Song' or 'Demo' buttons to play any of the 19 prerecorded songs.
- Activate the 4 drum sounds using their respective buttons.

Recording and Playback

- Press the 'Record' button to begin recording your performance.
- Press the 'Playback' or 'Listen' button to hear your recorded music.

Adjusting Volume and Tempo

- Use the 'Volume' controls (buttons or dial) to increase or decrease the sound level.
- Use the 'Tempo' controls to adjust the speed of rhythms and prerecorded songs.

External Music Source Connection

- Connect an MP3 player or smartphone to the external music source jack using the provided cable.
- Play music from your external device through the piano's speakers.

FEATURES

- **32-Key Electronic Keyboard:** Designed in a grand piano shape for a realistic musical experience.
- **Multiple Sounds and Rhythms:** Includes 5 instrument sounds, 4 rhythms with arrangements, 19 prerecorded songs, and 4 drum sounds.
- **Microphone with Adjustable Stand:** Allows for singing along while playing.
- **Recording and Playback Function:** Record and listen to your musical creations.
- **Adjustable Controls:** Volume and tempo can be adjusted to suit preferences.
- **External Connectivity:** Features a jack for connecting external music sources like MP3 players or smartphones (cable included).
- **Light Effects:** Integrated light effects enhance the playing experience.

MAINTENANCE

- **Cleaning:** Wipe the surface of the piano with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Care:** Always remove batteries if the product is not going to be used for an extended period to prevent leakage.
- **Storage:** Store the piano in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

- **No Sound:**
 - Ensure the piano is switched ON.
 - Check if the batteries are correctly inserted and not depleted. Replace if necessary.
 - Increase the volume level.
- **Microphone Not Working:**
 - Ensure the microphone is securely plugged into its jack.
 - Check if the microphone volume is turned up.
- **External Music Not Playing:**
 - Ensure the external device is connected correctly with the provided cable.
 - Check the volume on both the piano and the external device.

SPECIFICATIONS

Brand	Bontempi
-------	----------

Model Number	10 3030
Number of Keys	32
Dimensions	53 x 40 x 32 cm
Weight	2 Kilograms
Material	Plastic
Power Source	4 x 1.5V R6/AA Batteries (not included)
Recommended Age	0 - 6 years
Educational Objective	Teaching and encouraging musical learning and expression

WARRANTY INFORMATION

This Bontempi Electronic Grand Piano comes with a **2-year manufacturer's warranty**. Please retain your proof of purchase for any warranty claims. The warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, or unauthorized modifications.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Bontempi Electronic Grand Piano, please refer to the contact information provided on the product packaging or visit the official Bontempi website. You may also contact your retailer for support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question