

Lenovo ThinkPad L15

Lenovo ThinkPad L15 User Manual

Essential information for setting up, operating, and maintaining your Lenovo ThinkPad L15 laptop.

1. GETTING STARTED

1.1 Unpacking and Initial Setup

Carefully remove your Lenovo ThinkPad L15 from its packaging. Ensure all components are present:

- Lenovo ThinkPad L15 Laptop
- 65W USB-C Power Adapter

1.2 Powering On

Connect the 65W USB-C power adapter to the laptop's USB-C port and a power outlet. Press the power button, typically located on the side or top right of the keyboard, to turn on the device. Follow the on-screen instructions to complete the initial Windows 11 Professional setup.



Front view of the Lenovo ThinkPad L15 laptop, open to reveal its 15.6-inch display and full-size keyboard. The screen shows a vibrant landscape image, highlighting the display quality.

2. OPERATING YOUR LAPTOP

2.1 Keyboard and Touchpad

The ThinkPad L15 features a full-size, spill-resistant keyboard with a 10-key numeric pad and a TrackPoint pointing device for precise navigation.

- **Keyboard:** Standard QWERTY layout with dedicated function keys for system controls.
- **TrackPoint:** A red pointing stick located between the G, H, and B keys, used for cursor control.
- **Touchpad:** Supports multi-touch gestures for scrolling, zooming, and other functions.

2.2 Fingerprint Reader

For enhanced security, the laptop includes a fingerprint reader. Configure it through Windows Hello settings to enable secure biometric login.

2.3 Display

The 15.6-inch Full HD (1920x1080) IPS Anti-Glare display provides clear and comfortable viewing. The non-touch screen offers a 45% NTSC color gamut and 250 nits brightness at 60Hz.



A side profile of the Lenovo ThinkPad L15, showing its slim design and the hinge mechanism when partially open.

3. CONNECTIVITY

3.1 Ports and Connections

The ThinkPad L15 offers various ports for connecting peripherals and external devices:

- **USB-C Thunderbolt 4:** For high-speed data transfer, video output, and charging.
- **USB-C 3.2 Gen 1:** For data transfer and charging.
- **USB-A 3.2 Gen 1 (x2):** For connecting standard USB devices.
- **HDMI 2.0:** For connecting to external displays.
- **Headphone / Mic Combo Jack:** For audio input/output.
- **MicroSD Card Reader:** For expanding storage or transferring data from memory cards.
- **Ethernet Port:** For wired network connection.



Close-up of the left side of the Lenovo ThinkPad L15, featuring an Ethernet port, two USB-C ports (one Thunderbolt 4), an HDMI 2.0 port, and a USB-A 3.2 Gen 1 port.



Close-up of the right side of the Lenovo ThinkPad L15, showing a USB-A 3.2 Gen 1 port, a MicroSD card reader, and a security lock slot.

3.2 Wireless Connectivity

- **Wi-Fi 6E (802.11AX):** For high-speed wireless internet access.

- **Bluetooth 5.3:** For connecting wireless accessories such as headphones, mice, and keyboards.

4. MAINTENANCE AND CARE

4.1 General Care

To ensure the longevity and optimal performance of your laptop:

- Keep the device clean and free from dust. Regularly wipe surfaces with a soft, dry cloth.
- Avoid exposing the laptop to extreme temperatures, direct sunlight, or high humidity.
- Use a soft, lint-free cloth, slightly dampened with water or a screen cleaner, for cleaning the display.

4.2 Software Updates

Regularly update your Windows 11 Professional operating system and device drivers to maintain optimal performance, security, and compatibility. Access updates through Windows Settings.

5. TROUBLESHOOTING

5.1 Common Issues and Solutions

- **Laptop does not power on:** Ensure the power adapter is securely connected to both the laptop and a working power outlet. Verify the battery has sufficient charge.
- **Screen is blank:** Check power connections. If connected to an external monitor, ensure the correct display output settings are selected (e.g., by pressing Fn + F7 or similar key combination).
- **Slow performance:** Close unnecessary applications running in the background. Check for pending Windows updates or run a system diagnostic tool.
- **Wi-Fi connectivity issues:** Verify that Wi-Fi is enabled in Windows settings. Restart your wireless router. Update your network drivers if necessary.

For further assistance, refer to the Lenovo support website or contact customer service.

6. SPECIFICATIONS

6.1 Technical Specifications

Feature	Detail
Processor	AMD Ryzen 5 PRO 5650U (2.30 GHz, up to 4.20 GHz Max Boost, 6 Cores, 12 Threads, 16 MB Cache)
RAM	16GB DDR4 3200Mhz
Storage	256GB PCIe SSD
Display	15.6" FHD (1920 x 1080), IPS, Anti-Glare, Non-Touch, 45%NTSC, 250 nits, 60Hz
Operating System	Windows 11 Professional
Graphics	Integrated AMD Radeon Graphics
Wireless Connectivity	Wi-Fi 6E 802.11AX (2 x 2), Bluetooth 5.3

Feature	Detail
Ports	USB-C Thunderbolt 4, USB-C 3.2 Gen 1, 2 x USB-A 3.2 Gen 1, HDMI 2.0, Headphone / mic combo, MicroSD card reader, Ethernet
Webcam	720P HD RGB Webcam
Keyboard	Spill Resistant Keyboard with 10-Key Numeric Pad
Dimensions (LxWxH)	14.43 x 0.83 x 9.84 inches
Item Weight	5.79 pounds
Color	Black

7. WARRANTY AND SUPPORT

7.1 Product Warranty

This product is an Amazon Renewed, Certified Refurbished item. It comes with a 90-day refund/replacement return policy. For specific warranty details, please refer to the Amazon Renewed program terms and conditions.

7.2 Customer Support

For technical support or service inquiries, please visit the official Lenovo support website or contact the seller, USA Computers, directly for assistance with your Amazon Renewed purchase.