

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Perixx](#) /

› [Perixx PERIMICE-813RX Wireless Rechargeable Vertical Mouse User Manual](#)

Perixx PERIMICE-813RX

Perixx PERIMICE-813RX Wireless Rechargeable Vertical Mouse User Manual

Model: PERIMICE-813RX | Brand: Perixx

INTRODUCTION

The Perixx PERIMICE-813RX is an ergonomic wireless vertical mouse designed to provide a comfortable and natural hand position, reducing wrist strain during extended use. It features multi-device connectivity, dual charging options (wired USB-C and wireless), and adjustable DPI settings for precise control. This manual provides detailed instructions for setting up, operating, and maintaining your mouse.

PACKAGE CONTENTS

Please verify that all items are present in your package:

- 1 x Perixx PERIMICE-813RX Wireless Vertical Mouse
- 1 x USB Receiver (stored in the mouse)
- 1 x USB-C to A Charging Cable
- 1 x Wireless Charging Pad
- 1 x User Manual

Image: Contents of the Perixx PERIMICE-813RX package.

PRODUCT OVERVIEW

The PERIMICE-813RX features a vertical design for ergonomic comfort and multiple buttons for enhanced functionality.



Image: The Perixx PERIMICE-813RX mouse in use, demonstrating a relaxed natural grip.

Key Features:

- Ergonomic Vertical Design:** Positions your hand and arm in a natural handshake posture (47° angle) to reduce wrist and forearm strain.
- Dual Charging Options:** Supports both wired charging via USB-C and wireless charging with the included charging pad.
- Multi-Device Connectivity:** Connects to up to three devices using 2.4GHz wireless (via USB receiver) and two Bluetooth channels (BT 3.0 and BT 5.0).
- Adjustable DPI:** Cycle through 1000/1600/2400/3200 DPI settings for customized cursor sensitivity.
- Programmable Buttons:** Features six buttons including left/right click, scroll wheel, DPI switch, and forward/back buttons for web navigation.
- Quiet Clicking:** Designed for silent operation, suitable for quiet environments.

Image: Overview of mouse buttons including DPI switch and side navigation buttons.

SETUP

1. Charging the Mouse

Before first use, it is recommended to fully charge the mouse.

- Wired Charging:** Connect the included USB-C to A cable to the USB-C port on the front of the mouse and to a USB power source (e.g., computer, wall adapter).
- Wireless Charging:** Place the mouse on the included wireless charging pad. Ensure the mouse is correctly aligned for charging. The charging pad will illuminate to indicate charging status.



Image: Dual charging options for the mouse, wired via USB-C and wirelessly on the charging pad.

2. Connecting the Mouse

The PERIMICE-813RX supports three connection modes: 2.4GHz wireless and two Bluetooth channels.

- **2.4GHz Wireless Connection:**

1. Locate the Nano USB receiver stored in the bottom compartment of the mouse.
2. Plug the USB receiver into an available USB port on your computer.
3. Turn on the mouse. It should automatically connect.

- **Bluetooth Connection (BT 3.0 / BT 5.0):**

1. Turn on the mouse.
2. Press the mode switch button on the bottom of the mouse to select either BT 3.0 or BT 5.0 channel. The indicator light will flash.
3. On your device (computer, tablet, smartphone), go to Bluetooth settings and search for new devices.
4. Select "PERIMICE-813RX" from the list of available devices to pair.



Image: The mouse connected to multiple devices via 2.4GHz and Bluetooth.

OPERATING INSTRUCTIONS

1. DPI Adjustment

The DPI (Dots Per Inch) button allows you to adjust the cursor sensitivity. Press the DPI button located on the top of the mouse to cycle through the available settings: 1000, 1600, 2400, and 3200 DPI. Choose the setting that best suits your preference and task.

2. Multi-Device Switching

To switch between connected devices (2.4GHz, BT 3.0, BT 5.0), use the mode switch button located on the bottom of the mouse. Press the button to cycle through the channels. The corresponding indicator light will show which channel is active.

3. Forward/Back Buttons

The two side buttons on the mouse are pre-programmed for page forward and page back functions, useful for web browsing and file navigation.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mouse. Avoid using harsh chemicals or abrasive materials.
- **Battery Care:** To prolong battery life, avoid fully discharging the mouse frequently. Charge it when the low battery indicator appears.
- **Storage:** When not in use for extended periods, store the mouse in a cool, dry place.

TROUBLESHOOTING

• Mouse not responding:

- Ensure the mouse is powered on.
- Check battery level and charge if necessary.
- For 2.4GHz, ensure the USB receiver is securely plugged in.
- For Bluetooth, ensure the mouse is paired correctly and the correct Bluetooth channel is selected. Try re-pairing if issues persist.

• Cursor movement is erratic or slow:

- Adjust the DPI setting using the DPI button.
- Ensure the mouse sensor is clean and free from obstructions.
- Use the mouse on a suitable surface (e.g., a mouse pad).

• Wireless charging not working:

- Ensure the wireless charging pad is powered on and connected.
- Verify the mouse is correctly centered on the charging pad.

SPECIFICATIONS

Model Number	12410
Connectivity Technology	Bluetooth, Radio Frequency (2.4GHz)

Movement Detection Technology	Optical
DPI Settings	1000/1600/2400/3200
Special Features	Ergonomic Design, Lightweight, Rechargeable, Wireless, Multi-Device
Color	Black
Item Weight	10.5 ounces
Package Dimensions	5.35 x 4.41 x 3.5 inches
Batteries	1 AA batteries required (included)
Compatibility	Windows 7, 8, 10, and 11
Certifications	FCC, CE, RoHS compliant

WARRANTY AND SUPPORT

Perixx products are manufactured to high-quality standards. For warranty information, technical support, or any inquiries regarding your PERIMICE-813RX mouse, please refer to the contact information provided in the product packaging or visit the official Perixx website. Keep your purchase receipt for warranty claims.

© 2025 Perixx. All rights reserved.