

## VEVOR IF-1330TCL

# VEVOR 30-inch Electric Fireplace Instruction Manual

Model: IF-1330TCL

## 1. IMPORTANT SAFETY INFORMATION

Please read and understand this entire owner's manual, including all safety information, before plugging in or using this product. Failure to do so could result in fire, electric shock, or serious personal injury.

- Always disconnect the fireplace from the power supply before cleaning, performing maintenance, or relocating.
- Do not operate any fireplace with a damaged cord or plug, or if the heater has malfunctioned or been dropped/damaged in any manner.
- Do not use outdoors. This fireplace is intended for indoor use only.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the fireplace.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the fireplace.
- This appliance is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Always use properly grounded, fused, and polarized outlets.

## 2. PRODUCT COMPONENTS

The VEVOR 30-inch Electric Fireplace package includes the following items:

- 1 x Main Unit (Electric Fireplace)
- 1 x Faux Log Set
- 1 x User Manual
- 9 x M4\*28 Plastic Expansion Anchors (Outer Diameter  $\phi 6$ )
- 1 x Remote Control (Requires 2 x AAA Batteries, not included)
- 9 x ST4\*30 Self-Tapping Screws
- 0.6 lbs / 270 g Acrylic Imitation Crystals



Image: Overview of the VEVOR 30-inch Electric Fireplace dimensions and included accessories.

### 3. SETUP AND INSTALLATION

---

This electric fireplace offers two primary installation options: wall-mounted or recessed. Choose the method that best suits your space and aesthetic preferences.

#### 3.1 Installation Options

- **Wall-Mounted Installation:** The unit can be securely mounted directly onto a wall using the provided mounting bracket and hardware. Ensure the wall material can support the weight of the fireplace.
- **Recessed Installation:** The fireplace can be built into a wall opening for a flush, integrated look. Refer to the detailed installation guide for specific framing and clearance requirements.



Item Model Number: **IF-1330TCL**

Net Weight: **24.9 lbs / 11.3kg**

Item Dimensions: **30 x 4.6 x 17 inch / 760 x 118 x 432 mm**

Accessories: **1 x Main Unit, 1 x Faux Log Set, 1 x User Manual**

**9 x M4\*28 Plastic Expansion Anchors (Outer Diameter  $\phi$ 6)**

**1 x Remote Control (No Dry Batteries, Requires 2 x AAA Batteries)**

**9 x ST4\*30 Self-Tapping Screws, 0.6 lbs / 270 g Acrylic Imitation Crystals**

Width: **30 inch / 760 mm**

Power: **1500W**

Image: Examples of wall-mounted and recessed installation for the electric fireplace.

### 3.2 Pre-Installation Checks

- Ensure the power outlet is easily accessible and meets the electrical requirements (120V AC, 60Hz).
- Verify that the chosen location is away from water sources and direct sunlight.
- Confirm adequate clearance around the unit for proper ventilation.

## 4. OPERATING INSTRUCTIONS

The VEVOR electric fireplace can be operated using either the touch screen controls on the unit or the included remote control.

## 4.1 Controls Overview

# Two Installation Options



Wall Mount (Mounting Bracket Included)



Built-In Installation

Image: Touch screen controls on the unit and functions of the remote control buttons.

## 4.2 Power On/Off

Press the **Power** button on the remote or touch screen to turn the fireplace on or off.

## 4.3 Flame Effects

The fireplace features realistic flame effects with adjustable settings:

- **Flame Color:** Choose from 12 different flame colors (e.g., orange, green, blue, white) to match your ambiance. Press the **Flame Color** button to cycle through options.

- **Flame Brightness:** Adjust the flame intensity with 5 brightness levels. Press the **Flame Brightness** button to select your desired level.

## 5 Flame Brightness Levels




Image: Realistic flame effect with enhanced features.

## 2 Heat Settings

Choose Energy Saving or Fast Heating



Image: Demonstrating 5 flame brightness levels and 12 flame color options.

### 4.4 Heat Settings

The fireplace provides two heating modes and a temperature range control:

- **Heating Modes:** Select between 750W (energy-saving) and 1500W (fast heating) modes. Press the **Heater** button to toggle between these settings.
- **Temperature Control:** Adjust the desired room temperature between 62°F and 82°F (17°C and 27°C). Use the **Temperature** buttons on the remote to set.
- **Overheat Protection:** The unit is equipped with an automatic shut-off feature to prevent overheating, ensuring safe operation.

# Touch Screen & Remote Control

Easy Adjustments Anytime



Image: Illustration of 750W and 1500W heat settings and temperature control.

## 4.5 Timer Function

Set the fireplace to automatically shut off after a specified period:

- Press the **Timer** button to activate the timer.
- The timer can be set in 1-hour increments, from 1 to 8 hours.
- This feature helps save energy and provides convenience for overnight use.

## 5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your electric fireplace.

## 5.1 Cleaning

- Always unplug the unit before cleaning.
- Use a soft, damp cloth to clean the exterior surfaces. Do not use abrasive cleaners or sprays.
- Gently wipe the glass panel with a soft cloth to remove dust or smudges. Avoid harsh chemicals that may damage the finish.
- Periodically vacuum the air intake and exhaust vents to prevent dust buildup, which can affect heating efficiency.

## 5.2 Storage

If storing the fireplace for an extended period, unplug it and store it in a dry, dust-free location. It is recommended to keep the original packaging for storage.

## 6. TROUBLESHOOTING

If you encounter issues with your VEVOR electric fireplace, refer to the following common problems and solutions:

| Problem                     | Possible Cause   | Solution   |
|-----------------------------|--|--|
| Fireplace does not turn on. | No power to the unit; Power cord not fully plugged in; Main power switch off; Remote control batteries dead. | Check power outlet and circuit breaker; Ensure power cord is securely plugged in; Turn on the main power switch; Replace remote control batteries. |
| Flame effect not working.   | Flame effect motor malfunction; LED lights failure.  | Contact customer support for assistance.   |
| Heater not producing heat.  | Heater function not activated; Temperature setting too low; Overheat protection activated.                   | Ensure heater function is on; Increase desired temperature setting; Unplug unit for 15 minutes to reset overheat protection, then plug back in.    |
| Remote control not working. | Batteries are dead or incorrectly inserted; Obstruction between remote and unit.                             | Replace batteries, ensuring correct polarity; Remove any obstructions; Point remote directly at the unit.  |

## 7. SPECIFICATIONS

Detailed technical specifications for the VEVOR 30-inch Electric Fireplace:

- **Brand:** VEVOR
- **Model Number:** IF-1330TCL
- **Power Source:** Corded Electric
- **Product Dimensions (D x W x H):** 4.6" x 30" x 17" (118 x 760 x 432 mm)
- **Net Weight:** 24.91 lbs (11.3 kg)
- **Material:** Plastic

- **Finish Type:** Brushed
- **Installation Type:** Wall Mount / Recessed
- **Heat Output:** 750W / 1500W
- **Special Feature:** Adjustable Flame Color and Brightness, Timer, Overheat Protection
- **Style:** Modern
- **Color:** Black
- **Ventilation Type:** Vent Free
- **Specific Uses For Product:** Indoor
- **Orientation:** Front-facing
- **Maximum Compatible Size:** 30 Inches
- **Included Components:** Remote Control
- **UPC:** 197988700333
- **Manufacturer:** VEVOR

## 8. WARRANTY AND SUPPORT

---

This VEVOR electric fireplace comes with a limited warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your product or visit the official VEVOR website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact VEVOR customer service. Contact information can typically be found on the VEVOR website or in the product packaging.