

[Manuals.plus](#) /

› [HEBECA](#) /

› HEBECA 7D Electric Shaver for Women - Model BS7001 Instruction Manual

HEBECA BS7001

HEBECA 7D Electric Shaver for Women - Model BS7001 Instruction Manual

Your guide to safe and effective use of your HEBECA electric shaver.

1. INTRODUCTION

Thank you for choosing the HEBECA 7D Electric Shaver for Women. This device is designed for efficient and gentle hair removal across various body areas, including legs, arms, underarms, bikini line, and face. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.

2. PRODUCT FEATURES

- **7D Floating Magnetic Shaver Head:** Contours to body curves for a close shave.
- **Titanium-Coated Floating Blades:** Designed for sensitive skin, reducing nicks and redness.
- **IPX6 Waterproof:** Suitable for both wet and dry shaving.
- **USB-C Rechargeable:** Features a 1400mAh battery providing up to 150 minutes of cordless use after a 2-hour charge.
- **LED Smart Display:** Shows usage time and battery level.
- **Versatile Attachments:** Includes a rotary shaver head, hair trimmer head, (3/5/7mm) combs, and a cleansing brush.

7D MAGNETIC FLOATING SHAVER HEAD

Painless and Hypoallergenic Hair Shaver



360° Close
Shaving



Increase
Shaving Area

Image: The 7D Floating Magnetic Shaver Head, designed for close and comfortable shaving.



Image: The shaver being used in a wet environment, demonstrating its IPX6 waterproof rating.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Hair Shaver Main Device
- 1 x 7D Floating Facial & Body Hair Shaver Head
- 1 x Body Precise Trimmer Head
- 3 x Trimming Combs (3mm, 5mm, 7mm)
- 1 x Small Cleaning Brush
- 1 x Travel Cloth Pouch
- 1 x USB-C Charging Cable
- 1 x User Manual (in 6 languages)



Image: The HEBECA shaver with its various attachments and accessories, including the travel pouch and charging cable.

4. SETUP

1. **Initial Charge:** Before first use, fully charge the shaver using the provided USB-C cable. Connect the cable to the shaver's charging port and a compatible USB power source. The LED display will indicate charging status.
2. **Attach Desired Head:** Select the appropriate shaver head (7D rotary or precise trimmer) for your intended use. Align the head with the main device and gently twist or push until it clicks securely into place.
3. **Install Trimming Comb (if applicable):** For the precise trimmer head, slide one of the trimming combs (3mm, 5mm, or 7mm) onto the head if you desire a specific hair length.

HEBECA

ALL-IN-1 BODY HAIR SHAVER

Smoothness Unleashed,
Softness That Sets You Free



Image: Visual guide demonstrating the installation of the 7D floating shaver head onto the main device.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- To turn on the shaver, press and hold the power button for 3 seconds.
- To turn off the shaver, press and hold the power button for 3 seconds.
- The LED display will show the battery level and operating status.

5.2 Shaving Techniques

- **For Rotary Shaver Head:** Gently press the shaver head against your skin and move it in small, circular motions. For best results, stretch the skin taut.
- **For Precise Trimmer Head:** Hold the trimmer at a slight angle against the skin and move it slowly against the direction of hair growth. Use the trimming combs for desired hair length.
- The shaver can be used on dry skin or with water, foam, or gel for a wet shave.
- Avoid pressing too firmly or lingering on one spot to prevent skin irritation.



Image: Demonstrates the versatility of the shaver for use on legs, armpits, back, arms, and bikini area.

Your browser does not support the video tag.

Video: A demonstration of the HEBECA trimmer in action, showcasing its use for various hair removal needs.

6. MAINTENANCE AND CLEANING

1. **Daily Cleaning:** After each use, turn off the shaver and detach the head. Use the small cleaning brush to remove any trapped hairs from the blades and the shaver body.
2. **Rinsing:** Since the shaver is IPX6 waterproof, you can rinse the shaver head and the main device under running water. Ensure the charging port cover is securely closed before rinsing the main device.
3. **Drying:** Allow all parts to air dry completely before reattaching the head or storing the shaver.
4. **Storage:** Store the shaver in the provided travel pouch in a dry place, away from direct sunlight and extreme temperatures.




Image: A user demonstrating how to easily clean the shaver head under running water.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Low battery; power button not pressed correctly.	Charge the shaver fully. Press and hold the power button for 3 seconds.
Poor shaving performance.	Blades are dull or clogged with hair; shaver head not properly attached.	Clean the shaver head thoroughly. Ensure the head is securely attached. Consider replacing the shaver head if blades are dull.
Skin irritation after shaving.	Pressing too hard; moving too fast; sensitive skin reaction.	Use gentle pressure and slow movements. Try wet shaving with foam or gel. Apply a soothing lotion after shaving.

8. SPECIFICATIONS

Feature	Detail
Model Number	BS7001
Power Source	Battery Powered (Rechargeable)
Battery Type	Lithium-Ion (1400mAh)
Charging Time	Approx. 2 hours
Operating Time	Up to 150 minutes
Waterproof Rating	IPX6
Head Type	Rotary

Feature	Detail
Blade Material	Stainless Steel
Product Dimensions	2.83 x 3.35 x 3.65 inches
Item Weight	15.7 ounces (445 Grams)
Color	Rose Golden

9. WARRANTY AND SUPPORT

The HEBECA 7D Electric Shaver (Model BS7001) comes with a **1-year manufacturer's warranty**. For warranty claims, technical support, or any inquiries, please contact HEBECA customer service through your purchase platform or the contact information provided in the product packaging.

Important Safety Information:

- Avoid use on infants.
- Keep away from water sources when not in use or charging.
- Follow recommended cleaning and maintenance procedures to ensure longevity and hygiene.