

[Manuals.plus](#) /

› [ODIKA](#) /

› ODIKA Ultra Soft Area Rug (Pattern 19, 2' x 3', Faux Silk) Instruction Manual

ODIKA CRT-20250722-23393-2T3FT

ODIKA Ultra Soft Area Rug Instruction Manual

Model: CRT-20250722-23393-2T3FT

INTRODUCTION

Welcome to the instruction manual for your new ODIKA Ultra Soft Area Rug. This guide provides important information regarding the proper setup, care, and maintenance of your rug to ensure its lasting beauty and functionality. Please read this manual thoroughly before use.

PRODUCT OVERVIEW

The ODIKA Ultra Soft Area Rug, featuring Pattern 19 (Blossom Branch), is designed to enhance your living space with its modern aesthetic and comfortable texture. Crafted from faux silk polyester with a low pile, it offers a soft touch and is suitable for various indoor environments.

- **Modern Design:** Adds a contemporary and artistic touch to any room.
- **Soft Comfort:** Faux silk texture provides a smooth, soft feel underfoot.
- **Durable Construction:** Designed for high-traffic areas without shedding.
- **Kid & Pet Friendly:** Constructed to withstand daily use and common household messes.




Image: The ODIKA Ultra Soft Area Rug, Pattern 19, displayed in a living room, showcasing its floral design and how it complements modern decor.

SETUP & PLACEMENT


Upon receiving your rug, carefully unroll it. Minor creases from packaging are normal and will typically flatten out within a few days. For faster flattening, you can reverse roll the rug or place heavy objects on the affected areas.

Recommended Placement:

- **Living Room:** For a 2' x 3' rug, it can serve as an accent piece in front of a chair or as a decorative element in a smaller seating area.
- **Bedroom:** Ideal as a bedside rug or at the foot of a bed for added comfort.
- **Entryway:** Perfectly complements entryways or foyers without overwhelming the space.



5x7



8x10

For Living Room

5x7 foot rugs pair well with love seats or 3 seater sofas, while 8x10 foot rugs pair well with sectionals.



Image: A 2'x3' rug placed in a living room, demonstrating its use as an accent piece near a sofa.

Entryway

2x3 foot rugs complement entryways or foyers perfectly without overwhelming the space.




Image: The rug positioned in an entryway, illustrating its suitability for smaller spaces.

Non-Slip Feature:

The rug is equipped with a Thermoplastic Rubber (TPR) backing to help prevent slipping. Ensure the rug is placed on a clean, dry surface for optimal grip.



Image: A close-up view of the rug's underside, highlighting the non-slip TPR backing for secure placement.

GENERAL USE

This area rug is designed for indoor use only. Its durable construction and stain-resistant properties make it suitable for various rooms, including living rooms, bedrooms, and entryways. The low pile design ensures easy movement of furniture and robot vacuums.

Kid & Pet Friendly



Image: Two children playing on a rug, illustrating the rug's suitability for households with kids and pets.

MAINTENANCE & CARE

Cleaning Instructions:

- **Machine Washable:** The rug can be machine washed. Use a mild detergent and wash on a gentle cycle with cold water.
- **Drying:** Tumble dry on low heat or air dry. Avoid high heat to prevent damage to the backing.
- **Spot Cleaning:** For small spills, blot immediately with a clean cloth and mild detergent.
- **Vacuuming:** Regular vacuuming is recommended to remove dirt and debris. The rug is compatible with robot vacuums.

Machine Washable & Robot Vacuum Friendly




Image: A robot vacuum cleaning the rug, with washing machines visible, highlighting the rug's machine washable and robot vacuum friendly features.

TROUBLESHOOTING

Common Issues:

- **Creases from Shipping:** If your rug has creases upon arrival, reverse roll it or place heavy, flat objects on the creased areas for 24-48 hours. The creases should relax over time.
- **Rug Slipping:** Ensure the floor surface beneath the rug is clean and dry. The TPR backing provides non-slip properties, but extreme moisture or debris can reduce its effectiveness.
- **Color Variation:** Rug colors may appear differently under various lighting conditions (natural, warm, cool light). This is normal and not a defect.



Color in Different Light Settings

In Different Light



Natural



Warm



Cool

Image: Examples of the rug's appearance under different lighting conditions (natural, warm, and cool light), demonstrating how color perception can vary.

SPECIFICATIONS

Brand	ODIKA
Model Name	CRT-20250722-23393-2T3FT
Size	2' x 3' (Rectangular) / 36"L x 24"W
Material	Polyester (Faux Silk)
Back Material Type	Thermoplastic Rubber (TPR)
Pile Height	Low Pile
Item Thickness	0.3 Inches

Item Weight	1.5 Pounds
Color / Pattern	Pattern 19 (Blossom Branch)
Weave Type	Printed
Construction Type	Machine Made
Indoor/Outdoor Usage	Indoor
Special Features	Non Slip, Stain Resistant, Washable, Shed Resistant, Spill Resistant, Static Resistant, Quick Dry, Weather Resistant
Product Care Instructions	Machine wash with mild detergent



Image: A close-up demonstrating the rug's thickness, measured at approximately 0.14 inches, for reference.

WARRANTY INFORMATION

Specific warranty details for this product are not provided in the available information. For warranty inquiries or claims, please refer to the product packaging or contact ODIKA customer support directly.

CUSTOMER SUPPORT

If you have any questions, concerns, or require assistance with your ODIKA Ultra Soft Area Rug, please visit the official ODIKA store on Amazon or their website for contact information.
ODIKA Store Link: [Visit the ODIKA Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question