

## BANGE 7875

# BANGE Travel Backpack Model 7875 Instruction Manual

Model: 7875 | Brand: BANGE

## INTRODUCTION

Thank you for choosing the BANGE Travel Backpack Model 7875. This backpack is designed for versatility, offering secure storage and comfortable carrying for daily commutes, business trips, and overnight travel. It features a TSA-approved lock, dedicated compartments for electronics and essentials, and durable, water-resistant materials.

## PRODUCT FEATURES

- **Durable Material:** Constructed from Oxford cloth, providing water-resistant and scratch-resistant properties.
- **Optimal Dimensions:** Measures approximately 11.8"L x 19"H x 5.9"W, designed to meet most flight carry-on and personal item requirements.
- **Integrated TSA Lock:** Features a built-in TSA-approved lock to secure main compartments, protecting your valuables during travel.
- **Multi-functional Pockets:** Includes a front pocket for small items (pencils, keys, notebooks), a spacious main compartment for 2-3 days of clothing, and a dry-wet separation pocket.
- **Dedicated Laptop Compartment:** Padded compartment designed to securely hold laptops up to 15.6 inches.
- **Smooth Zippers:** Equipped with high-quality, smooth-gliding zippers for easy access and durability.
- **Ergonomic Design:** Ergonomically designed shoulder straps are adjustable for comfort and include reflective strips for enhanced visibility at night.
- **Luggage Strap:** A convenient strap on the back allows the backpack to be securely attached to luggage handles for easier transport.

## TSA LOCK SETUP INSTRUCTIONS

The BANGE Travel Backpack includes a TSA-approved combination lock. Follow these steps to set your personal combination:

1. **Initial Setting:** The default password is "000". Ensure the dials are set to this combination.
2. **Reset Button:** Locate the small reset button (usually on the side or bottom of the lock). Use a pen or a similar

pointed tool to press and hold this button until you hear a click.

3. **Set New Combination:** While holding the reset button, rotate the dials to your desired three-digit combination.
4. **Confirm New Combination:** Release the reset button. Your new combination is now set. Test it by scrambling the numbers and then entering your new combination to open the lock.



Figure 1: Visual guide for setting the TSA lock combination. The default is '000', press the reset button, set your new code, then release.

## USAGE GUIDELINES

### Organizing Your Backpack

The BANGE Travel Backpack is designed with multiple compartments for efficient organization:

- **Main Compartment:** Ideal for clothing and larger items. The spacious design can accommodate essentials for 2-3 days of travel.
- **Dry-Wet Separation Pocket:** Located within the main compartment, this waterproof pocket is perfect for toiletries or damp items, preventing them from affecting other contents.
- **Laptop Compartment:** Positioned at the back, this padded section safely stores laptops up to 15.6 inches.
- **Front Organizer Pocket:** Features smaller pockets for pens, keys, passports, and other quick-access items.
- **Side Bottle Pocket:** An external pocket for water bottles or umbrellas.

# NO VACUUM POCKET VERSION



Figure 2: Interior view of the BANGE backpack, highlighting the main storage, dry-wet separation, and laptop compartment.


## Carrying and Travel

- **Backpack Style:** Adjust the ergonomic shoulder straps for a comfortable fit. The reflective strips enhance safety during nighttime use.
- **Luggage Attachment:** Utilize the back luggage strap to slide the backpack over the handle of your rolling luggage, making airport navigation easier.
- **Flight Approved:** The backpack's dimensions are designed to fit in most overhead bins and under airplane seats, complying with common airline personal item requirements.

# LUGGAGE STRAP



1 luggage strap



2 Anti sweat and breathable



3 Adjustable Chest strap




Figure 3: Detail of the backpack's back panel, illustrating the luggage strap for attaching to rolling luggage, breathable padding, and adjustable chest strap.



Figure 4: The backpack's dimensions (11.8"L x 19"H x 5.9"W) are suitable for overhead bins and under-seat storage on most flights.

## Product Overview Video

Video 1: This video provides a comprehensive overview of the BANGE Travel Backpack, demonstrating its various features, compartments, and how it can be used for travel.

## MAINTENANCE

To ensure the longevity and appearance of your BANGE Travel Backpack, follow these maintenance guidelines:

- **Cleaning:** For general cleaning, wipe the exterior with a damp cloth and mild soap. Avoid harsh detergents or abrasive cleaners.
- **Drying:** Allow the backpack to air dry completely before storing. Do not machine wash or tumble dry.
- **Storage:** Store the backpack in a cool, dry place away from direct sunlight when not in use.
- **Avoid Overloading:** While durable, avoid consistently overloading the backpack beyond its intended capacity to prevent strain on zippers and seams.
- **Gentle Use:** Backpacks are consumable products. Please handle with care and avoid violent use to maintain product integrity.

## WATERPROOF & WEAR-RESISTANT MATERIAL

Not Afraid of Rainy Days and wear and tear. >>>>



Figure 5: The Oxford cloth material provides water resistance, making it suitable for various weather conditions.

## TROUBLESHOOTING

If you encounter any issues with your BANGE Travel Backpack, please consider the following:

- **Zipper Issues:** Ensure zippers are not forced. If a zipper snags, gently pull the fabric away from the teeth and try again. Lubricating with a zipper wax can help.
- **TSA Lock Malfunction:** Double-check your combination. If you forget your combination, refer to the lock manufacturer's instructions for resetting or contact customer support.
- **General Quality Concerns:** Our products undergo double QA quality inspection. If you experience any product quality issues, please consult our customer support for assistance.

## SPECIFICATIONS

Feature	Detail
Brand Name	BANGE
Model Name	7875
Material Type	Nylon (Oxford Cloth)
Item Weight	1.29 Kilograms
Item Dimensions (D x W x H)	6"D x 12"W x 18"H
Storage Volume	25 Liters
Compatible Device Size Maximum	15.6 Inches (Laptop)
Water Resistance Level	Not Water Resistant (but made of water-resistant material)
Number Of Pockets	5
Strap Type	Adjustable
Apparel Closure Type	Zipper

## SAFETY INFORMATION

This item is not intended for use by children 12 and under.

## **WARRANTY AND SUPPORT**

---

For any product quality issues or support inquiries, please contact BANGE customer service. We are committed to ensuring your satisfaction with our products.