

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [DEEGO](#) /

> [DEEGO 120-Capacity DVD/CD Storage Case with Lock \(Model 987600BRD\) - Instruction Manual](#)

DEEGO 987600BRD

DEEGO 120-Capacity DVD/CD Storage Case with Lock

Model: 987600BRD

PRODUCT OVERVIEW

The DEEGO 120-Capacity DVD/CD Storage Case is designed for organizing and protecting your disc collection. It features a compact design, a security lock, and additional storage for accessories, making it suitable for various environments.

Key features include:

- **120-Disc Capacity:** Holds up to 120 CDs, DVDs, or game discs across 30 inner pages.
- **Compact and Portable:** Measures 12"L x 7"W x 3.5"H, with a sturdy handle for easy transport.
- **Enhanced Protection:** Features a built-in combination lock and flame-retardant materials for added security and disc safety.
- **Smart Multi-Slot Design:** Includes integrated slots for a USB drive, SD card, and AirTag, plus two front mesh pockets for small accessories and a dedicated rear pocket for valuable items.
- **Anti-Slip Sleeves:** Inner pages are designed to keep discs securely in place, reducing movement and potential surface scratches.


PRODUCT FEATURES

Handled Disc Storage Case



The case features 30 inner pages, providing storage for up to 120 discs, including CDs, DVDs, and game discs.

Ultimate Protection for Your Collection



Smart multi-slot design includes dedicated spaces for a USB drive, SD card, and AirTag, along with mesh pockets for accessories.

Capacity Up To 120 Discs

30 Inner Pages for CDs, DVDs & Game Discs



A 3-digit security lock provides protection for your disc collection, complemented by smooth zippers.



The sturdy handle allows for easy portability, making it convenient for travel or moving between locations.

Video Demonstration

Your browser does not support the video tag.

This video demonstrates the features of the DEEGO DVD CD Storage Case, including its 3-digit security lock, smooth zipper, 120-disc capacity, smart multi-slot design for USB drives, SD cards, and AirTags, and its durable handle for portability.

SETUP: SETTING THE COMBINATION LOCK

The DEEGO storage case comes with a 3-digit combination lock to secure your discs. Follow these steps to set your personal code:

1. **Open the Lock:** The lock is factory-set to 0-0-0. Ensure the current combination is set to 0-0-0 and press the release button to open the lock.
2. **Locate Adjustment Button:** With the lock open, find the small adjustment button or lever, usually on the side or bottom of the lock mechanism.
3. **Slide Adjustment Button:** Use a pen or a small pointed object to slide the adjustment button in the direction indicated by an arrow. Hold it in this position.
4. **Set Your Code:** While holding the adjustment button, rotate the number dials to your desired 3-digit combination. Choose a memorable code.
5. **Release Adjustment Button:** Once your new code is set, release the adjustment button. Your new combination is now active.
6. **Test the Lock:** Scramble the numbers and then enter your new code to ensure it opens correctly.

Important: Remember your combination. There is no master key or override if the code is forgotten.

How To Set Your Password



Visual guide for setting your personal 3-digit combination lock.

OPERATING INSTRUCTIONS

Inserting and Removing Discs

- Open the case using your set combination.
- Gently slide discs into the anti-slip sleeves. Ensure the disc is fully seated to prevent it from falling out.
- To remove a disc, gently pull it out from the sleeve. Avoid bending the disc or forcing it.

Utilizing Multi-Slots and Pockets

- **USB/SD Card Slots:** Insert your USB drives and SD cards into their designated elastic loops for secure storage.
- **AirTag Compatibility:** A dedicated slot is provided for an AirTag, allowing you to track your case.
- **Mesh Pockets:** Use the two front mesh pockets for small accessories like cleaning cloths, headphones, or small cables.
- **Dedicated Rear Pocket:** Store valuable or special edition discs, liner notes, or small documents in the rear pocket for extra protection and separation.

MAINTENANCE

- **Cleaning the Exterior:** Wipe the leather exterior with a soft, damp cloth. For stubborn stains, use a mild leather cleaner. Avoid harsh chemicals.
- **Cleaning Interior Sleeves:** If disc sleeves become dusty, gently wipe them with a dry, lint-free cloth. Do not use liquids directly on the sleeves while discs are inside.
- **Disc Care:** Always handle discs by their edges. Store them in the sleeves when not in use to prevent scratches and dust accumulation.
- **Storage:** Store the case in a cool, dry place away from direct sunlight and extreme temperatures to preserve the material and discs.

TROUBLESHOOTING

Lock Issues

- **Lock Not Opening:** Ensure you are entering the correct 3-digit combination. If you recently changed it, try the new code. If forgotten, there is no reset method; the lock may need to be replaced or carefully bypassed.
- **Zipper Jamming:** The zippers are designed to be smooth. If a zipper jams, avoid forcing it. Gently pull the zipper tab back and forth, ensuring no fabric is caught.

Disc Storage Issues

- **Discs Falling Out:** Ensure discs are fully inserted into the anti-slip sleeves. The sleeves are designed to hold discs securely, but improper insertion can lead to slippage.
- **Scratches on Discs:** Always insert and remove discs carefully. Avoid overfilling sleeves or forcing multiple discs into a single slot.

SPECIFICATIONS

Product Dimensions	12 x 7 x 3.5 inches
Item Weight	1.39 pounds
Model Number	987600BRD
Capacity	120 Discs (CDs, DVDs, Blu-rays, Game Discs)
Material	Leather exterior, flame-retardant fabric

WHAT'S IN THE BOX

Your DEEGO 120-Capacity DVD/CD Storage Case package includes:

- 1 x DEEGO 120-Capacity DVD/CD Storage Case with integrated lock

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or contact DEEGO customer service through the retailer where the product was purchased. Keep your purchase receipt for warranty claims.