

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Waipfaru](#) /

› [Waipfaru 22-Inch Prelit Christmas Planter Bushes \(2-Pack\) Instruction Manual](#)

Waipfaru B0FK4PDPS5

Waipfaru 22-Inch Prelit Christmas Planter Bushes (2-Pack)

INSTRUCTION MANUAL

Introduction

Thank you for choosing the Waipfaru 22-Inch Prelit Christmas Planter Bushes. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your product. Please read these instructions carefully before use and retain them for future reference.

Setup

- Unpacking and Inspection:** Carefully remove all components from the packaging. Inspect the planter bushes for any signs of damage. Ensure all parts are present: 2 prelit planter bushes and 2 metal stakes.
- Assembly of Stand:** Each planter bush comes with a metal stake. Insert the bottom stem of the artificial bush into the top opening of the metal stake. Ensure it is securely seated.
- Branch Fluffing:** The branches may be compressed during shipping. Gently spread and shape the branches to achieve a full and natural appearance. Adjust the pinecones and berries as desired.
- Battery Installation:** Locate the battery box attached to the light string. Open the battery compartment and insert 3 AA batteries (not included), ensuring correct polarity. Close the compartment securely.



Image: Two prelit planter bushes in urns, ready for display.



Multicolored LEDs



Long & Round Pinecones



Red Berried Clusters



Lifelike PVC Branch Tips



Lifelike Norfolk Pine Tips

Image: Detailed view of the artificial branches, pinecones, and berries, illustrating the product's realistic design.

Video: This video demonstrates the assembly and features of the Waipfaru Prelit Planter Bushes, including how to attach the stand and adjust the branches.

Operating Instructions

The integrated LED lights are battery-operated and feature multiple lighting modes and a timer function.

- **Power On/Off:** Press the 'ON' button on the battery box to turn the lights on. Press 'OFF' to turn them off.
- **Lighting Modes:** Press the 'MODE' button repeatedly to cycle through the 8 different lighting effects: Combination, In Wave, Sequential, Slo Glo, Chasing/Flash, Slow Fade, Twinkle/Flash, Steady On.
- **Timer Function:** To activate the timer, press the 'TIMER' button. The lights will stay on for 6 hours and then automatically turn off for 18 hours, repeating the cycle daily.

8 Different Lighting Modes with Timer Function



Image: Battery box with controls for 8 lighting modes and timer function.

Maintenance

- **Cleaning:** To clean the planter bushes, gently wipe with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the materials or finish.
- **Storage:** When not in use, store the planter bushes in their original packaging or a protective container in a cool, dry place away from direct sunlight. Ensure branches are gently compressed to prevent damage.
- **Battery Replacement:** If the lights dim or stop working, replace the 3 AA batteries in the battery box. Always use fresh batteries and dispose of old batteries responsibly.

Troubleshooting

- **Lights Not Turning On:**
 - Check if batteries are installed correctly with proper polarity.
 - Replace old batteries with new ones.
 - Ensure the 'ON' button is pressed and the timer is not active if continuous lighting is desired.

- **Branches Appear Sparse:**

- Gently fluff and reshape the individual branches and tips. The product is designed to be adjustable for a full appearance.

- **Product Instability:**

- Ensure the metal stake is fully inserted into the base of the bush and placed firmly in a planter, urn, or ground.

Specifications

Feature	Detail
Brand	Waipfaru
Product Dimensions	3"D x 1"W x 0.7"H (Individual Bush)
Height	22 inches
Color	Green (with multicolor lights)
Material	Plastic
Item Weight	1.6 ounces (per bush)
Item Package Quantity	2
Recommended Uses	Outdoor, Front Porch, Planters, Urns, Garden Beds
Occasion	Christmas
Built-in Light	Yes
Light Color	Multicolor
Included Components	2 Artificial Trees, 2 Metal Stakes
Power Source	3 AA Batteries (not included)

Product Size



Image: Product dimensions, illustrating the 22-inch height.

Warranty and Support

For any questions, concerns, or support needs regarding your Waipfaru PreLit Christmas Planter Bushes, please refer to your purchase documentation or contact the retailer directly. Keep your proof of purchase for warranty claims, if applicable.