

[Manuals.plus](#) /

› [SlickBlue](#) /

› SlickBlue Wooden Heptagon Wedding Arch Arbor Instruction Manual

SlickBlue D-CO-NP11809BN

SlickBlue Wooden Heptagon Wedding Arch Arbor Instruction Manual

Model: D-CO-NP11809BN

1. PRODUCT OVERVIEW

The SlickBlue Wooden Heptagon Wedding Arch Arbor is designed to provide a beautiful and stable backdrop for various events, including weddings, photo shoots, and parties. Crafted from durable fir wood, this arch features a unique heptagon shape and is treated for weather resistance, ensuring longevity and aesthetic appeal.

Its versatile design allows for decoration with flowers, fabrics, lights, and balloons, making it suitable for both indoor and outdoor settings such as grassy lawns, sandy beaches, or rustic venues.



Image 1.1: The SlickBlue Heptagon Wedding Arch providing a backdrop for a ceremony on a beach, adorned with white floral arrangements.

2. SAFETY INFORMATION

- **Assembly:** Always assemble the arch on a flat, stable surface. Ensure all screws and fasteners are securely tightened before use.
- **Stability:** For outdoor use, utilize the provided U-shaped metal stakes to anchor the arch firmly to the ground. This product is not suitable for use on concrete or indoors without additional stabilization if heavy decorations are applied.
- **Weight Limit:** Avoid hanging excessively heavy objects or allowing individuals to climb on the arch, as this may compromise its stability and structural integrity.
- **Weather Conditions:** In strong winds or severe weather, disassemble the arch or ensure it is exceptionally well-secured to prevent tipping or damage.
- **Children and Pets:** Keep children and pets away from the arch during assembly and ensure they do not play unsupervised around the erected structure.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Wooden arch segments (various lengths and angles for heptagon shape)
- Triangular base supports
- Connection plates/brackets
- Screws and fasteners
- U-shaped metal ground stakes (4 pieces)
- Assembly tool (e.g., Allen wrench or screwdriver)
- Instruction Manual

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the SlickBlue Wooden Heptagon Wedding Arch requires two people for optimal ease and safety.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Identify each segment according to the included diagram (if provided).
2. **Assemble Base:** Attach the triangular base supports to the bottom horizontal wooden segments using the provided screws. Ensure these connections are tight and stable.
3. **Connect Arch Segments:** Begin connecting the wooden heptagon segments. The arch is designed with reinforced joints. Align the pre-drilled holes and secure each joint with four screws. Work systematically around the heptagon shape.
4. **Erect Arch:** Once the main heptagon structure is assembled, carefully lift and position the arch onto the assembled base. Secure the arch to the base using the remaining screws, ensuring all connections are firm.
5. **Ground Fixation (Outdoor Use):** For outdoor placement, position the arch in the desired location. Drive the four U-shaped metal stakes through the designated holes in the base into the ground. Ensure the stakes are fully embedded for maximum stability.

Reliable & Weather-Resistant



Natural Fir Wood
Not easy to warp or buckle



Delicate Polishing Treatment
Smooth & splinter-free



Protective Painting
Enhance the natural beauty of wood grains

Image 4.1: Details of the natural fir wood construction, polishing, and protective painting that contribute to the arch's durability and appearance.

5. OPERATING INSTRUCTIONS (USAGE)

The SlickBlue Wooden Heptagon Wedding Arch is designed for versatile use as a decorative backdrop.

- **Decoration:** Adorn the arch with various decorative elements such as flowers, greenery, fabrics, balloons, or string lights to match your event's theme. Ensure decorations are evenly distributed and do not place excessive strain on any single point of the arch.
- **Placement:** Position the arch in a location that provides a clear, unobstructed view for guests and photographers. Consider the background and lighting conditions for optimal visual impact.
- **Indoor Use:** When using indoors, ensure the arch is placed on a level surface. If heavy decorations are used, consider adding sandbags or weights to the base for enhanced stability, as the ground stakes cannot be used.
- **Outdoor Use:** Always use the U-shaped metal stakes to secure the arch to the ground when outdoors. Regularly check the stability, especially in changing weather conditions.



Image 5.1: The Heptagon Wedding Arch styled with elegant drapes and vibrant floral decorations, showcasing its versatility.

6. MAINTENANCE

Proper maintenance will ensure the longevity and appearance of your wooden arch.

- **Cleaning:** Wipe down the wooden surfaces with a soft, damp cloth to remove dust and dirt. Avoid abrasive cleaners or harsh chemicals that could damage the protective finish.
- **Storage:** When not in use, disassemble the arch and store it in a dry, covered area to protect it from extreme weather conditions, which can cause warping or fading.
- **Inspection:** Periodically inspect all screws and joints to ensure they remain tight. Re-tighten if necessary. Check the wood for any signs of wear, cracks, or damage.
- **Refinishing:** Over time, the protective finish may wear. To maintain the wood's integrity and appearance, consider applying a suitable outdoor wood sealant or stain as needed.

7. TROUBLESHOOTING

- **Arch feels wobbly after assembly:** Ensure all screws at every joint and connection point are fully tightened. For outdoor use, verify that the U-shaped ground stakes are deeply and securely embedded in the soil.
- **Difficulty aligning segments:** Double-check that you are using the correct segments for each part of

the heptagon. Sometimes rotating a segment can help align the pre-drilled holes. Do not force connections.

- **Missing parts:** Refer to the 'Package Contents' section. If any parts are missing upon unboxing, contact SlickBlue customer support immediately for assistance.
- **Wood appears discolored or damaged:** Small variations in wood grain and color are natural. If there is significant damage or discoloration beyond normal wood characteristics, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	SlickBlue
Model Number	D-CO-NP11809BN
Style	Heptagon
Color	Brown
Product Dimensions (W x H)	30"W x 84"H (approx. 2.5 ft W x 7 ft H)
Item Weight	16.5 Pounds
Material	Fir Wood
Assembly Required	Yes
GTIN / UPC	610803444330



Image 8.1: Dimensional overview of the Heptagon Wedding Arch, illustrating its height and width.

9. WARRANTY AND SUPPORT

SlickBlue is committed to providing quality products. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For product support, missing parts, or any inquiries, please contact SlickBlue customer service through the retailer where the product was purchased or visit the official SlickBlue brand store online.

Online Store: [SlickBlue Amazon Store](#)