



Manuals.plus /

› Rowood /

› Rowood Notre-Dame de Paris Cathedral 3D Wooden Puzzle Instruction Manual (Model TG511)

## Rowood TG511

# Rowood Notre-Dame de Paris Cathedral 3D Wooden Puzzle Instruction Manual

Model: TG511

[Overview](#)

[Setup](#)

[Assembly](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Support](#)

## 1. PRODUCT OVERVIEW

The Rowood Notre-Dame de Paris Cathedral 3D Wooden Puzzle (Model TG511) is a meticulously designed architectural model kit. This DIY puzzle allows you to construct a detailed replica of the iconic Notre-Dame de Paris Cathedral using laser-cut wooden pieces. It is intended for display as a decorative piece and offers an engaging building experience.



*Image 1.1: The fully assembled Notre-Dame de Paris Cathedral 3D Wooden Puzzle.*

## **2. SETUP AND PREPARATION**

---

### **2.1 Unpacking the Kit**

Carefully open the product packaging. Remove all wooden sheets, the instruction manual, and any included accessories such as sandpaper. Inspect all components for any damage. If any parts are missing or damaged, please refer to the "Support" section.

# Notre Dame de Paris

## 3D Puzzle



330

Pcs

2H

Assembly time

14+

Age

Image 2.1: Overview of the puzzle kit, highlighting key features and specifications.

## 2.2 Workspace Requirements

Ensure you have a clean, flat, and well-lit workspace. This kit does not require glue or additional tools for assembly, but a small craft knife or tweezers may be helpful for delicate pieces. Keep small children and pets away from the workspace due to small parts.

## 2.3 Material Information

The puzzle pieces are crafted from non-toxic, splinter-free wooden materials. Some pieces are delicate and require careful handling during removal from the sheets and assembly.

## 3. ASSEMBLY INSTRUCTIONS

This 3D wooden puzzle features an intuitive interlocking system designed for straightforward assembly. The estimated assembly time is approximately 2 hours. Follow the included step-by-step instructions provided in the kit.

### 3.1 General Assembly Tips

- **Review Instructions:** Before starting, carefully read through the entire instruction manual provided in your kit to understand the assembly sequence.
- **Handle with Care:** The wooden pieces are laser-cut for precision but can be delicate. Gently push pieces out from their sheets. Avoid excessive force to prevent breakage.
- **Dry Fit:** Whenever possible, dry fit pieces together before fully interlocking them to ensure correct orientation and fit.
- **Sanding:** If a piece is too tight, use the included sandpaper or an emery board to gently sand the edges for a smoother fit. Do not over-sand.
- **Patience:** Take your time during assembly. Rushing can lead to errors or damage to the pieces.



*Image 3.1: Demonstrating the assembly of individual wooden components.*

# Enjoyable DIY Experience

Assemble your own landmark building and immerse yourself in the joy and sense of accomplishment brought by success.

ROWOOD




Image 3.2: A user engaged in the assembly process of the model kit.

## 3.2 Official Assembly Video

For visual guidance, please refer to the official assembly video below. This video demonstrates the step-by-step process of constructing the Notre-Dame de Paris Cathedral model.

Your browser does not support the video tag.

Video 3.1: Official assembly guide for the Rowood Notre-Dame de Paris Cathedral 3D Wooden Puzzle.

## 4. MAINTENANCE

To ensure the longevity and appearance of your assembled Notre-Dame de Paris Cathedral model, follow these simple maintenance guidelines:

- **Dusting:** Regularly dust the model with a soft, dry brush or a microfiber cloth to prevent dust accumulation in intricate areas.

- **Environment:** Keep the model in a dry environment, away from direct sunlight, excessive humidity, or extreme temperature changes, which can cause the wood to warp or fade.
- **Cleaning:** Avoid using liquid cleaners or abrasive materials, as these can damage the wooden surface.

## 5. TROUBLESHOOTING

---

While this kit is designed for ease of assembly, you may encounter minor issues. Here are some common solutions:

- **Broken Pieces:** Some delicate pieces may break during removal or assembly. The kit includes spare pieces for common fragile components. If a piece breaks and no spare is available, a small amount of wood glue can be used to repair it.
- **Tight Fit:** If pieces do not fit together smoothly, gently use the provided sandpaper to slightly reduce the thickness of the tab or the size of the slot until they fit without excessive force.
- **Loose Fit:** If a piece fits too loosely, a tiny drop of wood glue can be applied to secure it. Allow ample time for the glue to dry.
- **Missing Steps in Instructions:** Refer to the included instructions carefully. If a step seems unclear or missing, cross-reference with the visual diagrams or the official assembly video.

For persistent issues or further assistance, please contact customer support as detailed in the "Support" section.

## 6. PRODUCT SPECIFICATIONS

---

<b>Model Number</b>	TG511
<b>Brand</b>	Rowood
<b>Assembled Dimensions (Approx.)</b>	9.5 inches (Width) x 4 inches (Depth) x 7.5 inches (Height)
<b>Number of Pieces</b>	330
<b>Estimated Assembly Time</b>	2 hours
<b>Recommended Age</b>	14 years and up
<b>Material</b>	Wood (Non-toxic, splinter-free)
<b>Item Weight</b>	4 ounces

## 7. CUSTOMER SUPPORT

---

For any questions, concerns, or assistance with your Rowood Notre-Dame de Paris Cathedral 3D Wooden Puzzle, please contact our customer support team. We are committed to providing prompt and free assistance to ensure your satisfaction.

Please refer to the contact information provided in your product packaging or visit the official Rowood website for support details.