

- Manuals.plus /
- › [Dpofirs](#) /
 - › Dpofirs E Book Reader (Model Dpofirskm0qavy6bo) Instruction Manual

Dpofirs Dpofirskm0qavy6bo

Dpofirs E Book Reader (Model Dpofirskm0qavy6bo) Instruction Manual

Comprehensive Guide for Setup, Operation, and Maintenance

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Dpofirs E Book Reader, Model Dpofirskm0qavy6bo. Please read this manual thoroughly before operating the device to ensure proper functionality and to maximize your reading experience. Keep this manual for future reference.



Figure 1.1: The Dpofirs E Book Reader in its protective cover, displaying an ebook. This image illustrates the device's primary function and its sleek design.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your product package. If any items are missing or damaged, please contact customer support.

- 1 x Electronic Book Reader
- 1 x Protective Cover
- 1 x Charging Cable (Type-C)
- 1 x Earphone (3.5mm)
- 1 x Stylus Pen
- 1 x Screen Protector
- 1 x Writing Board
- 1 x Writing Board Stylus Pen
- 1 x Instruction Manual (this document)




Figure 2.1: Contents of the Dpofirs E Book Reader package. This image displays all included accessories for the device.

3. PRODUCT OVERVIEW

The Dpofirs E Book Reader is designed for an enhanced reading and multimedia experience. It features a 5-inch HD

screen, runs on Android 5.1, and includes Wi-Fi and Bluetooth connectivity.

3.1 Physical Components

- **Screen:** 5-inch, 480x854 resolution.
- **Physical Keys:** Volume Up, Volume Down, Photo, On/Off.
- **USB Port:** Type-C for charging and data transfer.
- **Headset Jack:** 3.5mm for earphones.
- **Camera:** 5MP with flash.
- **Speaker:** 2030 Single Magnetic Chamber Speaker.
- **Microphone:** Integrated for audio input.

4. SETUP

4.1 Initial Charging

1. Connect the provided Type-C charging cable to the device's USB port.
2. Plug the other end of the charging cable into a compatible USB power adapter (not included) or a computer's USB port.
3. Allow the device to charge fully before first use. The battery indicator on the screen will show charging status.

High Resolution



Figure 4.1: The e-reader's battery indicator, highlighting its extended operational capacity on a single charge.

4.2 Powering On/Off

- **To Power On:** Press and hold the On/Off key until the screen illuminates.
- **To Power Off:** Press and hold the On/Off key, then select 'Power Off' from the options that appear on the screen.
- **To Restart:** Press and hold the On/Off key, then select 'Restart' from the options.

5. OPERATING INSTRUCTIONS

5.1 Navigating the Interface

The device runs on Android 5.1, offering a familiar interface. Use the touchscreen for navigation. Swipe to scroll, tap to select, and use the physical keys for specific functions.

5.2 Reading Ebooks

1. Open the pre-installed ebook reader application.
2. Select an ebook from your library. The device supports various ebook formats.
3. Tap the screen to access reading options such as font size, night mode, and bookmarks.




Figure 5.1: The e-reader's high-resolution display showing text and interface elements for an optimized reading experience.

5.3 Display Settings

The 5-inch HD screen provides clear visuals. Adjust brightness and other display settings for optimal comfort, especially in varying light conditions.



Read More Comfortable

Figure 5.2: The e-reader's display in bright outdoor conditions, showcasing its anti-reflective properties for comfortable reading.

5.4 Night Mode

To reduce eye strain in low-light environments, activate the night mode feature. This typically inverts colors, displaying white text on a dark background.



Figure 5.3: The e-reader screen in night mode, providing a comfortable reading experience in dim lighting.

5.5 Connectivity

- **Wi-Fi:** Connect to wireless networks via IEEE 802.11 b/g/n for internet access and content downloads.
- **Bluetooth:** Pair with Bluetooth 4.0LE compatible devices such as headphones or speakers for audio playback.
- **OTG (On-The-Go):** Supports OTG functionality for connecting external USB devices.

5.6 Multimedia Functions

- **Camera:** Use the built-in 5MP camera with flash to capture photos.
- **FM Radio:** Tune into FM radio stations.
- **Audio/Video Playback:** The device supports various sound and video formats for entertainment.

6. MAINTENANCE AND CARE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the device. Avoid abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid exposing the device to extreme temperatures. Charge the device regularly, but avoid leaving it fully discharged for extended periods.
- **Storage:** Store the device in a cool, dry place away from direct sunlight when not in use.
- **Protective Cover:** Utilize the provided protective cover to shield the device from scratches and minor impacts.

7. TROUBLESHOOTING

If you encounter issues with your Dpofirs E Book Reader, refer to the following common problems and solutions:

Problem	Possible Solution
Device does not power on.	Ensure the battery is charged. Connect the device to a charger for at least 30 minutes. If it still doesn't turn on, perform a hard reset by holding the power button for 10-15 seconds.
Screen is unresponsive.	Restart the device. If the issue persists, ensure the screen is clean and free of debris.
Cannot connect to Wi-Fi.	Check if Wi-Fi is enabled in settings. Ensure you are within range of a known network and have entered the correct password. Restart your Wi-Fi router if necessary.
Ebooks are not loading.	Verify that the ebook files are in a supported format. Try restarting the ebook reader application or the device itself. Ensure sufficient storage space is available.
Battery drains quickly.	Reduce screen brightness. Turn off Wi-Fi and Bluetooth when not in use. Close background applications.

If these solutions do not resolve the issue, please contact Dpofirs customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Model Name	Dpofirskm0qavy6bo
Screen Size	5 inch
Resolution	480x854
Operating System	Android 5.1
Processor	MT6580 Quad Core 1.3GHz, ARM Cortex A7
Memory (RAM)	1GB
Storage (ROM)	8GB
Wi-Fi	IEEE 802.11 b/g/n
Bluetooth	4.0LE
Camera	5MP with Flash
Battery Type	Built-in Li Battery
Battery Capacity	2500mAh
USB Port	Type-C
Headset Jack	3.5mm

Feature	Detail
Sensors	G sensor
FM Radio	Supported
OTG	Supported
Speaker	2030 Single Magnetic Chamber Speaker
Microphone	Supported
Supported Image Formats	JPG, JPEG, BMP, GIF, PNG
Item Weight	14.5 ounces
Package Dimensions	8.27 x 5.51 x 1.18 inches

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Dpofirs website. Keep your proof of purchase for any warranty claims.

If you require technical assistance or have questions not covered in this manual, please contact Dpofirs customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0FK5MJ3ZS>

More documents and user manuals: <https://manuals.plus/>