

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [bmani](#) /

› [bmani T16 Wireless Earbuds Instruction Manual](#)

## bmani T16

# bmani T16 Wireless Earbuds Instruction Manual

Model: T16

## 1. PRODUCT OVERVIEW

The bmani T16 Wireless Earbuds are designed for active lifestyles, offering an ultra-long 80-hour playtime with their dual LED display charging case. They feature immersive stereo sound with 10mm dynamic drivers, clear calls with dual microphones, and seamless Bluetooth connectivity. The adjustable over-ear hooks ensure a secure and comfortable fit for various activities. Easy button controls provide intuitive management of music and calls.



Wireless Earbuds with Earhooks Designed for Sports

- Dual LED Battery Display
- 600mAh Charging Case
- Anti-skid Earhooks
- IPX5 Waterproof
- Hi-Fi Stereo
- Voice Assistants

Image: bmani T16 Wireless Earbuds in their charging case, highlighting 80 hours of total playtime and the dual LED battery display.

## 2. WHAT'S IN THE Box

- bmani T16 Wireless Earbuds (Left and Right)
- Charging Case with LED Display
- Eartips (Small, Medium, Large sizes)
- Type-C Charging Cable
- User Manual (this document)




Image: The bmani T16 Wireless Earbuds, charging case, and various eartip sizes.

## 3. SETUP AND PAIRING

The bmani T16 earbuds feature one-step pairing for quick and easy connection to your devices.

1. **Initial Pairing:** Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.

3. Search for available devices and select "T16" from the list.
4. Once connected, you will hear a voice prompt confirming the successful pairing.
5. **Automatic Reconnection:** After the initial pairing, the earbuds will automatically reconnect to the last paired device when removed from the charging case.



Image: Illustration of the one-step pairing process for the bmani T16 earbuds with a smartphone and other compatible devices.

Your browser does not support the video tag.

Video: An official seller video demonstrating the features and pairing process of the bmani T16 Wireless Earbuds.

#### 4. WEARING INSTRUCTIONS

For optimal sound quality and a secure fit, follow these steps to wear your bmani T16 earbuds:

1. Choose the correct eartip size (S, M, L) that best fits your ear canal.
2. Place the flexible ear hook over the back of your ear.
3. Gently insert the earbud into your ear canal.
4. Adjust the earbud and hook by twisting until you achieve a comfortable and secure fit. The ear hooks are designed to adapt to different ear shapes, minimizing slippage during movement.



## Bluetooth 5.0 Voice Assistance

Bluetooth 5.0 technology offers extended range and fewer dropouts, so they stay connected as you keep moving



**5.0**

Bluetooth



**Siri**

Voice Assistance

Image: Visual guide demonstrating how to correctly position the bmani T16 earbuds with their flexible ear hooks for a secure fit.

## 5. OPERATING CONTROLS

The bmani T16 earbuds feature intuitive physical buttons for easy control of your audio and calls.

- **Play/Pause:** Click once on either earbud.
- **Next Track:** Quick double-click on the Right (R) earbud.
- **Previous Track:** Quick double-click on the Left (L) earbud.
- **Volume Up:** Press the "+" button on the earbud.
- **Volume Down:** Press the "-" button on the earbud.
- **Answer/End Call:** Click once on either earbud.
- **Reject Call:** Hold either earbud button.
- **Activate Voice Assistant (Siri/Google Assistant):** Quick triple-click on either earbud.
- **Power On/Off:** Hold the button on either earbud.




Image: Detailed diagram showing the various button controls on the bmani T16 earbuds for managing audio playback, calls, and voice assistant.

## 6. CHARGING

The bmani T16 earbuds and charging case provide an impressive 80 hours of total playtime.

- **Earbud Charging:** Place the earbuds back into the charging case. The LED indicators on the case will show the charging status of each earbud. Each earbud offers up to 8 hours of playtime per charge.
- **Case Charging:** Connect the provided Type-C charging cable to the charging port on the case and to a USB power source. The digital display on the left side of the case will show the remaining power percentage of the charging case.
- The charging case can recharge the earbuds multiple times, extending total usage to 80 hours.



Image: The bmani T16 charging case with its dual LED digital display, indicating the battery percentage of the case and the charging status of each earbud.

Your browser does not support the video tag.

Video: An official seller video showcasing the 48-hour playback (note: product features state 80H) and LED display of the bmani T16 Sport Earphones.

## 7. MAINTENANCE

- Regularly clean the earbuds and charging contacts with a soft, dry cloth to prevent dust and debris buildup.
- Avoid exposing the earbuds to extreme temperatures or direct sunlight for prolonged periods.
- Store the earbuds in their charging case when not in use to protect them and ensure they remain charged.
- The earbuds are sweat-resistant and dust-resistant, but avoid submerging them in water.

## 8. TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are removed from the case and are powered on. Turn off Bluetooth on your device and turn it back on. If issues persist, try resetting the earbuds (refer to the full user manual for specific reset instructions).
- **No sound:** Check the volume level on both your device and the earbuds. Ensure the earbuds are properly connected to your device via Bluetooth.
- **Charging issues:** Verify that the charging cable is securely connected to both the case and the power source. Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.
- **Unstable connection:** Ensure your device is within the Bluetooth range (approximately 33 feet/10 meters) and there are no significant obstacles between the earbuds and your device.

## 9. SPECIFICATIONS

Model Name	T16
Connectivity Technology	Wireless (Bluetooth 5.0)
Playtime (Earbuds)	Up to 8 hours per charge
Total Playtime (with Case)	Up to 80 hours
Audio Driver Type	10mm Dynamic Driver
Noise Control Features	Noise Cancellation (Dual Mics)
Water Resistance Level	Sweat-resistant and Dust-resistant
Control Method	Button Controls
Ear Placement	Over Ear
Item Weight	2 ounces

## 10. WARRANTY AND SUPPORT

bmani offers a lifetime warranty for permanent replacement of damaged, defective, upgraded, or lost products. Please refer to the warranty card included in your package for activation details and terms. For further assistance, please contact bmani customer support.