Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TV98 ATV Stick 8K

Generic TV98 ATV Stick 8K Android TV Streaming Stick 14 User Manual

Model: TV98 ATV Stick 8K

1. Introduction

The Generic TV98 ATV Stick 8K is an advanced Android TV streaming device designed to transform your television into a smart entertainment hub. Running on Android 14.0, it offers a smooth and responsive user experience, supporting Ultra HD 8K streaming. With its powerful Allwinner H313 Quad-Core processor and G31 GPU, dual-band WiFi (2.4G/5G), and Bluetooth 5.0, this stick ensures stable connections and high-quality media playback. The included voice remote control simplifies navigation and content search, providing convenient access to your favorite streaming applications like YouTube and Netflix.



Image 1.1: The TV98 ATV Stick 8K demonstrating its versatility for entertainment and productivity.

2. What's in the Box

Please check the package contents carefully. If any items are missing or damaged, contact your retailer.

- TV98 ATV Stick
- Voice Remote Control
- HDMI Extension Cable
- USB Power Cable
- Power Adapter (may vary by region)
- User Manual (this document)



Image 2.1: All components included with the TV98 ATV Stick 8K.

3. Product Features

The TV98 ATV Stick 8K offers a range of features designed for an optimal streaming experience:

- **Android 14.0 Operating System:** Provides smoother performance and enhanced app compatibility.
- **Allwinner H313 Quad-Core CPU with G31 GPU:** Ensures lag-free playback and efficient processing.

- **2GB RAM + 16GB Storage:** Ample memory and storage for applications, media, and stable operation.
- **Dual-Band WiFi (2.4G/5G) and Bluetooth 5.0:** For fast, stable network connections and seamless pairing with wireless accessories.
- **Voice Remote Control:** Features shortcut keys and numeric buttons for intuitive and easy control.
- **4K Video Support:** Capable of playing high-resolution video content.
- **Screen Mirroring:** Allows you to cast content from compatible devices to your TV.
- **Wide App Compatibility:** Supports all popular streaming applications.



Image 3.1: Technical specifications and core features of the TV98 ATV Stick 8K.

4. Setup Guide

Follow these steps to set up your TV98 ATV Stick 8K:

1. **Connect the ATV Stick:** Plug the TV98 ATV Stick directly into an available HDMI port on your television. If space is limited, use the provided HDMI extension cable.
2. **Power the Device:** Connect the USB power cable to the micro-USB port on the ATV Stick and the other end to the power adapter. Plug the power adapter into a wall outlet. Alternatively, you can connect the USB cable to a powered USB port on your TV if available and it provides sufficient power.
3. **Select HDMI Input:** Turn on your TV and use your TV remote to select the correct HDMI input source to which the ATV Stick is connected.
4. **Pair the Remote Control:** Insert two AAA batteries (not included) into the voice remote control. The remote should automatically pair with the stick. If not, follow the on-screen instructions or press and hold the 'OK' and 'Volume Down' buttons simultaneously for a few seconds until the pairing indicator appears.
5. **Initial Setup Wizard:** Follow the on-screen instructions to complete the initial setup. This typically includes:
    - Selecting your language.
    - Connecting to a Wi-Fi network (select your network and enter the password).
    - Signing in with your Google Account (required to download apps from the Google Play Store).
    - Accepting terms and conditions.

6. **Start Streaming:** Once the setup is complete, you will be taken to the Android TV home screen. You can now download and enjoy your favorite streaming apps.



Image 4.1: The TV98 ATV Stick 8K, ready for connection to an HDMI port.

5. Operating Instructions

5.1 Navigating the Interface

Use the directional pad (D-pad) on your remote control to move through the Android TV interface. The 'OK' button confirms selections, and the 'Back' button returns to the previous screen. The 'Home' button takes you directly to the home screen.

5.2 Voice Control

Press the dedicated Voice Assistant button on your remote (usually a microphone icon) and speak clearly into the remote to search for content, open apps, or control playback. For example, say "Open Netflix" or "Search for action movies."

5.3 Installing and Managing Apps

Access the Google Play Store from the home screen to browse and install new applications. To manage installed apps, go to Settings > Apps, where you can uninstall, force stop, or clear data for any application.

5.4 Screen Mirroring

The TV98 ATV Stick supports screen mirroring from compatible devices. Look for a 'Cast' or 'Screen Mirroring' option on your smartphone or tablet and select the TV98 ATV Stick from the list of available devices.

5.5 Bluetooth Connectivity

Connect Bluetooth accessories such as game controllers, headphones, or keyboards to enhance your experience. Go to Settings > Remotes & Accessories > Add accessory, and follow the on-screen instructions to pair your device.



Image 5.1: The TV98 ATV Stick 8K's Bluetooth connectivity with various peripherals.

6. Maintenance

To ensure the longevity and optimal performance of your TV98 ATV Stick 8K, follow these maintenance guidelines:

- **Keep it Clean:** Gently wipe the device with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.
- **Avoid Overheating:** Ensure the stick has adequate ventilation and is not covered or placed in an enclosed space that could trap heat.
- **Software Updates:** Regularly check for and install system updates to benefit from new features, performance improvements, and security patches. Go to Settings > Device Preferences > About > System update.
- **Power Cycle:** If the device becomes unresponsive, disconnect it from the power source for a few seconds, then plug it back in.
- **Factory Reset:** As a last resort for persistent issues, you can perform a factory reset (Settings > Device Preferences > Reset). Be aware that this will erase all data and settings.

7. Troubleshooting

If you encounter issues with your TV98 ATV Stick 8K, refer to the following common problems and solutions:

- **No Power/No Display:**
  - Ensure the power cable is securely connected to the stick and the power adapter is plugged into a working outlet.
  - Verify your TV is on the correct HDMI input source.
  - Try a different HDMI port on your TV.
- **Remote Control Not Responding:**
  - Check and replace the batteries in the remote control.
  - Re-pair the remote by following the instructions in Section 4.

- **No Wi-Fi Connection:**
  - Ensure your Wi-Fi router is on and working.
  - Go to Settings > Network & Internet and check if your Wi-Fi network is visible. Re-enter the password if necessary.
  - Restart your Wi-Fi router and the ATV Stick.
- **Apps Crashing or Freezing:**
  - Clear the cache and data for the problematic app (Settings > Apps > [App Name] > Clear cache/Clear data).
  - Ensure the app is updated to its latest version.
  - Restart the ATV Stick.
- **Poor Video Quality/Buffering:**
  - Check your internet speed. A stable, high-speed connection is required for 4K streaming.
  - Ensure you are connected to the 5GHz Wi-Fi band if available, as it offers faster speeds.
  - Reduce the distance between the ATV Stick and your Wi-Fi router.

8. Specifications

Feature	Specification
Brand	Generic
Model Number	06c1f454-dc8e-4eb1-81c1-8eedb25dc66f
Operating System	Android 14.0
Processor	Allwinner H313 Quad-Core CPU
GPU	G31
RAM	2 GB
Storage	16 GB
Connectivity Technology	Wi-Fi 2.4G/5G, Bluetooth 5.0
Connector Type	HDMI
Special Feature	Ultra HD 4K (supports 8K)
Resolution	4K (Output Resolution: 3840 Pixels)
Supported Internet Services	Netflix (and other popular streaming apps)
Controller Type	Bluetooth Voice Remote Control
Form Factor	TV Stick
Color	Black
Product Dimensions (L x W x H)	10L x 3W x 12H centimeters
Compatible Devices	Television

Feature	Specification
Video Codec	H.265

9. Warranty and Support

The Generic TV98 ATV Stick 8K comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or external factors.

For warranty claims or technical support, please contact your original retailer or refer to the contact information provided with your purchase documentation. Please have your proof of purchase and the product's serial number (if applicable) ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question