Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PHI VILLA PV-489

PHI VILLA Wicker Patio Furniture Set (Model PV-489) Instruction Manual

Outdoor L-Shaped Sectional Sofa with Cushions and Acacia Wood Coffee Table

1. Introduction

Thank you for choosing the PHI VILLA Wicker Patio Furniture Set. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new outdoor furniture. Please read these instructions carefully before assembly and retain them for future reference.
This set includes an L-shaped sectional sofa with cushions and an acacia wood coffee table, designed for outdoor use in gardens, decks, or poolside lounge areas.

2. Safety Information

- **Read All Instructions:** Ensure you understand all assembly steps and safety warnings before beginning.
- **Adult Assembly Required:** This product requires adult assembly. Keep children and pets away during assembly.
- **Use on Level Surface:** Always place the furniture on a flat, stable, and level surface to prevent tipping.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 350 lbs per seat.
- **Inspect Regularly:** Periodically check all bolts and connections to ensure they remain tight. Retighten as necessary.
- **Weather Protection:** While designed for all-weather use, prolonged exposure to extreme weather conditions (heavy rain, snow, strong sun) may reduce product lifespan. Consider using a furniture cover or storing cushions indoors during harsh weather.
- **Avoid Sharp Objects:** Do not use sharp objects on the wicker or wood surfaces to prevent damage.
- **Fire Safety:** Keep furniture away from open flames or extreme heat sources.

3. Package Contents

Before assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- Left Sofa Section (1)
- Right Sofa Section (1)
- Coffee Table (1)
- Seat Cushions (Quantity as per sofa sections)
- Back Cushions (Quantity as per sofa sections)
- Assembly Hardware (Bolts, washers, Allen wrench)



Image 3.1: Rattan Chaise Lounge Set Dimensions. This diagram illustrates the overall dimensions of the L-shaped sofa and the coffee table, including length, width, and height measurements for each component.

4. Assembly Instructions

Please follow these steps carefully for proper assembly. It is recommended to assemble with two people.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Assemble Sofa Sections:**

- Attach the backrests to the seat frames using the provided bolts and Allen wrench. Do not fully tighten bolts until all connections are made.
- Connect the two sofa sections to form the L-shape. Secure them together with the designated connectors.
- Once all parts are aligned, fully tighten all bolts.

3. **Assemble Coffee Table:**
    - Attach the acacia wood legs to the tabletop. Ensure the lower wicker shelf is properly positioned before securing the legs.
    - Tighten all bolts securely.
4. **Attach Adjustable Feet:** Screw the adjustable foot pads into the bottom of each acacia wood leg on both the sofa and coffee table. Adjust them as needed to ensure stability on uneven surfaces.
5. **Place Cushions:** Position the seat and back cushions onto the assembled sofa sections.



Image 4.1: Fully assembled PHI VILLA Wicker Patio Furniture Set. This image displays the complete L-shaped sectional sofa with navy blue cushions and the matching coffee table, arranged on a wooden deck next to a swimming pool.

5. Operating Instructions

Your PHI VILLA Wicker Patio Furniture Set is designed for comfortable outdoor lounging. Here are some guidelines for optimal use:

- **Cushion Use:** The cushions are water-repellent and fade-resistant. However, for extended longevity, it is recommended to store them indoors during heavy rain or prolonged periods of non-use.
- **Coffee Table Use:** The double-layer tabletop provides space for drinks, snacks, and decorative items. The lower shelf offers additional storage for books or outdoor essentials.
- **Adjustable Feet:** Use the adjustable foot pads to level the furniture on uneven patio or deck surfaces, ensuring stability and preventing wobbling.



Image 5.1: Bohemian Style Wicker Design. This close-up shows the handwoven PE rattan with an elegant diamond pattern, highlighting the aesthetic detail of the furniture.



Image 5.2: Thicker Cushion Seat. This image provides a detailed view of the high-density foam cushion, emphasizing its thickness and plush texture for comfort.

6. Maintenance

Proper care will extend the life and appearance of your furniture set.

- **Cleaning Wicker:** Wipe down the PE rattan wicker with a soft cloth dampened with mild soap and water. Rinse thoroughly with clean water and allow to air dry. Avoid harsh chemicals or abrasive cleaners.
- **Cleaning Cushions:** The cushion covers are typically removable and can be spot cleaned with mild soap and water. For deeper cleaning, follow the care instructions on the cushion tags. Ensure cushions are completely dry before storing to prevent mildew.
- **Acacia Wood Care:** The acacia wood legs are coated with PU for protection. Clean with a soft, damp cloth. Avoid prolonged exposure to moisture. Periodically, you may apply a wood protector or sealant to maintain its appearance and durability, especially if the PU coating shows signs of wear.
- **Coffee Table Top:** The polymer wood top is UV-resistant and waterproof. Clean with a damp cloth.
- **Winter Storage:** During winter months or extended periods of non-use, it is recommended to store the furniture in a

dry, covered area or use a high-quality outdoor furniture cover.



Image 6.1: Natural Acacia Wood Legs with Adjustable Feet. This image highlights the solid acacia wood legs, coated for protection, and the adjustable foot pads designed for stability on various surfaces.



Image 6.2: Extra Large Storage Space. This view of the coffee table emphasizes its dual-shelf design, showcasing the spacious lower shelf for storing various items.

7. Troubleshooting

Problem	Possible Cause	Solution
Furniture is wobbly or uneven.	Uneven ground or improperly adjusted feet.	Adjust the leveling feet on the bottom of the acacia wood legs until the furniture is stable. Ensure it is placed on a flat surface.
Cushions appear flattened or misshapen.	Prolonged use or improper storage.	Fluff cushions regularly. Store cushions indoors when not in use for extended periods to help maintain their shape.

Problem	Possible Cause	Solution
Wicker appears faded or brittle.	Excessive exposure to direct sunlight or harsh weather.	While the wicker is UV-resistant, prolonged exposure can still cause wear. Consider using a furniture cover during intense sun or storing in shade.
Assembly hardware does not align.	Parts are not correctly oriented or bolts are overtightened prematurely.	Loosen all bolts slightly, realign the parts, and then tighten gradually. Ensure parts are oriented as shown in the assembly diagrams.

8. Specifications

Feature	Detail
Brand	PHI VILLA
Model Number	PV-489
Material	PE Rattan Wicker, Acacia Wood, Powder-Coated Metal Frame, Polymer Wood Tabletop
Color	Navy Blue (Cushions)
Product Dimensions (L x W x H)	Approximately 48.8 x 25 x 13 inches (Individual components vary)
Item Weight	93 pounds
Weight Capacity (per seat)	350 lbs
Waterproof	Yes (Cushions water-repellent, Tabletop waterproof)
UV Resistance	Yes (Wicker and Tabletop)

9. Warranty and Customer Support

PHI VILLA stands behind the quality of its products. For specific warranty details, please refer to the warranty card included with your purchase or visit the official PHI VILLA website. If you have any questions, require replacement parts, or need assistance with assembly or troubleshooting, please contact PHI VILLA customer support:

- **Customer Service:** Refer to your purchase documentation for contact information.
- **Online Support:** Visit the PHI VILLA Store on Amazon for additional product information and support resources.

© 2025 PHI VILLA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FK9JFXNJ

More documents and user manuals: **https://manuals.plus/**