

Jugeman V10

Jugeman V10 Smartwatch User Manual

Model: V10

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Jugeman V10 Smartwatch. Please read this manual carefully to ensure proper use and to maximize the device's features.

1. SETUP

1.1 Package Contents

- Jugeman V10 Smartwatch
- Charging Cable
- User Manual

1.2 Initial Charging

Before first use, fully charge your smartwatch. Connect the charging cable to the charging port on the back of the watch and plug the USB end into a power adapter (not included) or a computer's USB port. The watch display will indicate charging status.

1.3 App Installation and Pairing

1. **Download the App:** Scan the QR code provided in the quick start guide or search for the companion app (e.g., "Jugeman Fit" or similar, specific app name not provided in data) in your smartphone's app store (Android or iOS).
2. **Create Account:** Open the app and follow the on-screen instructions to create a user account.
3. **Enable Bluetooth:** Ensure Bluetooth is enabled on your smartphone.
4. **Pair Device:** In the app, navigate to "Device" or "Add Device" and select your Jugeman V10 from the list of available devices. Confirm the pairing request on both your phone and the smartwatch.

Once paired, the watch will synchronize time and language settings with your phone.

2. OPERATING INSTRUCTIONS

2.1 Basic Navigation

- **Touchscreen:** Swipe left/right, up/down to navigate menus and screens. Tap to select.
- **Side Buttons:** Typically, one button serves as a power/back button, while others may be customizable shortcuts for sports modes or specific functions.

2.2 Bluetooth Calls and Notifications

The Jugeman V10 supports Bluetooth 5.4 calls. Once connected to your phone via Bluetooth, you can:


- **Make Calls:** Access the dial pad or contact list directly from the watch.
- **Receive Calls:** Answer, reject, or mute incoming calls from your wrist.
- **Notifications:** The watch will vibrate and display notifications from your paired smartphone for messages, social media alerts, and other app notifications. Ensure notification permissions are granted in the companion app.

2.3 Sports Modes and GPS Tracking

The smartwatch offers over 100 sports modes, including walking, running, cycling, and yoga. It features integrated GPS for precise tracking.

1. **Select a Sport:** Navigate to the "Sports" menu on your watch and choose your desired activity.
2. **Start Tracking:** Tap to begin the activity. The integrated GPS will record your route, distance, average/real-time speed, and calories burned.
3. **View Data:** After completing an activity, save the data. Detailed statistics can be viewed on the watch and synchronized with the companion app on your phone.

Size



Built for Adventure



Image: Jugeman V10 Smartwatch dimensions and features like anti-impact, temperature test, anti-fluid corrosion, and dust-proof capabilities.

2.4 Health Monitoring

The V10 smartwatch provides 24-hour health monitoring:

- **Heart Rate:** Continuous heart rate monitoring. View real-time data on the watch or historical data in the app.
- **Blood Oxygen (SpO2):** Measure your blood oxygen saturation levels.
- **Sleep Tracking:** Automatically monitors your sleep patterns, including deep sleep, light sleep, and wake times. Detailed analysis is available in the app.

All recorded health data can be synchronized and displayed in the companion app for a comprehensive overview of your physical condition.

2.5 Customizing Watch Faces

Personalize your smartwatch with various watch faces:

- **Pre-installed Faces:** Choose from over 200 built-in watch face styles via the companion app.
- **Custom Faces:** Upload your favorite photos (e.g., family pictures, travel photos) to set as your watch face background.



Image: Jugeman V10 Smartwatch displaying its main interface with time, date, weather, steps, and heart rate information.

3. MAINTENANCE

3.1 Cleaning

Regularly clean your smartwatch and strap to prevent skin irritation and maintain device functionality.

- Wipe the screen and body with a soft, lint-free cloth.
- For stubborn stains, use a slightly damp cloth with mild soap, then wipe dry.
- Avoid using harsh chemicals, abrasive cleaners, or solvents.

3.2 Water Resistance (IP68)

The Jugeman V10 is IP68 water-resistant, meaning it can withstand rain, sweat, and splashes. It is suitable for daily use and light water exposure.

- **Do not** use the watch for swimming, diving, or showering with hot water.
- **Do not** expose the watch to high-pressure water or prolonged submersion.
- If the watch gets wet, wipe it dry thoroughly before charging or using buttons.

3.3 Battery Care

- Avoid extreme temperatures, which can affect battery life.
- Charge the watch using the provided cable.
- Do not leave the watch fully discharged for extended periods.

4. TROUBLESHOOTING

Issue	Possible Solution
Watch does not turn on	Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
Cannot pair with smartphone	◦ Ensure Bluetooth is enabled on your phone and the watch. ◦ Make sure the watch is within range of your phone. ◦ Restart both your phone and the watch. ◦ Try unpairing and re-pairing through the companion app.
Inaccurate health data	◦ Ensure the watch is worn snugly on your wrist, not too tight or too loose. ◦ Clean the sensor on the back of the watch. ◦ Avoid excessive movement during measurements.
Notifications not received	◦ Check notification permissions in your phone's settings for the companion app. ◦ Ensure the watch is connected via Bluetooth. ◦ Verify notification settings within the companion app.
Short battery life	◦ Reduce screen brightness. ◦ Disable continuous heart rate monitoring if not needed 24/7. ◦ Limit frequent use of GPS and Bluetooth calls. ◦ Ensure background app refresh is optimized on your phone.

4.1 Factory Reset

If issues persist, a factory reset may resolve them. This will erase all data on the watch and restore it to its original

settings. Consult the watch's settings menu for the "Factory Reset" option.

5. SPECIFICATIONS

Feature	Detail
Brand	Jugeman
Model Number	V10
Screen Size	2.06 Inches
Operating System	Android Wear 2.0 (Compatibility with Android/iOS)
Connectivity	Bluetooth 5.4
Special Features	Activity Tracking, Integrated GPS, Bluetooth Calling, Heart Rate Monitor, SpO2 Monitor, Sleep Tracking, 100+ Sports Modes, Customizable Watch Faces
Water Resistance	IP68
Battery Composition	Lithium-polymer
Memory Storage Capacity	1 GB
Manufacturer	Jugeman
Country of Origin	China

6. WARRANTY AND SUPPORT

6.1 Manufacturer's Warranty

The Jugeman V10 Smartwatch comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or failure to follow the instructions in this manual.

6.2 Customer Support

For technical assistance, warranty claims, or further inquiries, please contact your retailer or the manufacturer's customer support. Refer to the product packaging or the official Jugeman website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question