

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Lapcare](#) /

› [Lapcare Bravo 27000mAh 65W PD Power Bank User Manual](#)

Lapcare Bravo

Lapcare Bravo 27000mAh 65W PD Fast Charging Power Bank User Manual

Model: Bravo

INTRODUCTION

Thank you for choosing the Lapcare Bravo 27000mAh 65W PD Fast Charging Power Bank. This device is designed to provide portable and efficient power for your laptops, tablets, smartphones, and other USB-powered devices. Please read this manual carefully before using the product to ensure safe and optimal performance. Keep this manual for future reference.

PRODUCT OVERVIEW

The Lapcare Bravo Power Bank features a high-capacity battery and multiple charging ports to meet diverse power needs. Its compact design makes it suitable for travel, work, and daily use.

Key Features:

- **65W Power Delivery (PD) Ultra-Fast Charging:** Capable of charging laptops, tablets, and smartphones at high speeds.
- **Massive 27,000mAh Battery:** Provides extended power backup for multiple charges.
- **Dual Type-C Input/Output Ports:** Supports fast bi-directional charging for convenience.
- **Laptop Charging Support:** Specifically designed to power compatible laptops efficiently.
- **22.5W USB-A Quick Charge Port:** Allows simultaneous high-speed charging for additional devices.
- **LED Display:** Indicates current battery level and charging status.

Components:

Familiarize yourself with the various ports and indicators on your power bank.

Power Up in Minutes

USB Output 


2 Type C Input/ Output Port 



Image: The Lapcare Bravo Power Bank showing its dual Type-C input/output ports and a USB-A output port. The LED display is visible on the top surface.

- **Type-C Ports (x2):** Used for both charging the power bank and charging compatible devices with Power Delivery.
- **USB-A Port (x1):** Used for charging devices that support USB-A, including Quick Charge compatible devices.
- **LED Digital Display:** Shows the remaining battery percentage of the power bank.
- **Power Button:** Activates the LED display and initiates charging for some devices.

SETUP

Initial Charging of the Power Bank:

Before first use, it is recommended to fully charge your Lapcare Bravo Power Bank.

1. Connect a compatible USB-C PD wall charger (not included) to one of the Type-C input/output ports on the power bank.
2. Plug the wall charger into a power outlet.
3. The LED display will show the charging progress, indicating the battery percentage increasing until it reaches 100%.

4. Once fully charged, disconnect the power bank from the wall charger.

OPERATING INSTRUCTIONS

Checking Battery Level:

Press the power button once to activate the LED digital display, which will show the current battery percentage.

Charging Your Devices:

The Lapcare Bravo Power Bank can charge various devices, including laptops, tablets, and smartphones, using its Type-C PD and USB-A Quick Charge ports.



Image: The Lapcare Bravo Power Bank connected via USB-C to a laptop and via USB-A to a smartphone, demonstrating its multi-device charging capability.

1. **For Type-C PD Compatible Devices (Laptops, Tablets, Smartphones):**

Connect your device to one of the Type-C input/output ports on the power bank using a compatible USB-C to USB-C cable. The power bank will automatically begin charging your device.

2. **For USB-A Compatible Devices (Smartphones, other gadgets):**

Connect your device to the USB-A output port on the power bank using a compatible USB-A charging cable. The power bank will automatically begin charging your device.

3. **Multi-Device Charging:** You can charge multiple devices simultaneously using the available Type-C and

USB-A ports. The power bank will intelligently distribute power.

The LED display will remain active during charging, showing the power bank's remaining battery level. Disconnect your devices once they are fully charged or when you no longer need to charge them.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the power bank. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, fully charge the power bank at least once every three months if not in regular use. Avoid completely draining the battery frequently.
- **Avoid Drops:** Do not drop or subject the power bank to strong impacts, as this can damage internal components.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Faulty charging cable or adapter; power outlet issue; power bank fault.	Try a different USB-C cable and wall adapter. Ensure the wall outlet is functional. If the issue persists, contact support.
Device not charging from power bank	Low power bank battery; faulty charging cable; incompatible device; device charging port issue.	Ensure the power bank is sufficiently charged. Try a different charging cable. Verify device compatibility. Check your device's charging port.
Slow charging	Non-PD or non-Quick Charge cable/adapter; device not supporting fast charging; multiple devices charging simultaneously.	Use a high-quality USB-C PD cable and adapter for fast charging. Ensure your device supports fast charging protocols. Charging multiple devices may reduce individual charging speeds.
LED display not working	Power bank is completely drained; internal fault.	Charge the power bank for a period. If it still doesn't light up, contact support.

SPECIFICATIONS

Feature	Detail
Model Number	Bravo
Battery Capacity	27000mAh
Max Output Power	65W Power Delivery (PD)
Input/Output Ports	2 x Type-C (PD), 1 x USB-A (22.5W Quick Charge)
Special Features	Laptop Charging Support, LED Display, Safety Protection System
Product Dimensions	18 x 3 x 8 cm

Feature	Detail
Item Weight	550 g
Color	Black

SAFETY INFORMATION

To ensure safe operation and prevent damage to the power bank or connected devices, please observe the following safety guidelines:



Image: The Lapcare Bravo Power Bank highlighting its multiple layer protection features, including Over Voltage, Over Current, Short Circuit, Electrostatic, Circuit Identification, and Over Temperature Protection.

- Do not expose the power bank to water, moisture, or high humidity.
- Avoid extreme temperatures. Do not store or use the power bank in direct sunlight or in hot environments (e.g., inside a car on a hot day).
- Do not disassemble, modify, or attempt to repair the power bank yourself. This will void the warranty and may cause safety hazards.
- Keep out of reach of children.
- Use only original or certified compatible charging cables and adapters.

- Do not use the power bank if it is visibly damaged, swollen, or leaking.
- Dispose of the power bank responsibly according to local regulations. Do not dispose of it in household waste.

WARRANTY AND SUPPORT

The Lapcare Bravo Power Bank comes with a **6-month warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.

For warranty claims, technical support, or any inquiries regarding your product, please contact Lapcare customer service through their official website or the retailer where you purchased the product. Please have your proof of purchase ready when contacting support.