

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Narcissus](#) /

› [Narcissus Portable Electric Espresso Machine CM-2599 User Manual](#)

Narcissus CM-2599

Narcissus Portable Electric Espresso Machine CM-2599

USER MANUAL

Product Overview

The Narcissus Portable Electric Espresso Machine CM-2599 is a versatile 2-in-1 device designed for on-the-go espresso preparation. It supports both ground coffee powder (up to 12g) and Nespresso Original capsules, offering flexibility for various preferences. Featuring an 86.6-watt heating element and a 7800mAh built-in battery, it provides rapid brewing capabilities, making it ideal for travel and outdoor use.

Portable Electric Espresso Machine for Outdoors

- 1.5 pounds machine
- 12g coffee powder capacity
- Max 80ml espresso shots
- 7800mAh battery



Figure 1: Portable Electric Espresso Machine with key features.

Included Components

Before setup, ensure all components are present:

- Portable Electric Espresso Machine (Main Unit)
- Coffee Powder Chamber
- Nespresso Capsule Adapter
- Espresso Cup
- USB-C Cable
- Quick Charger (Wall Adapter)
- Coffee Scoop
- User Manual




Figure 2: All components included in the package.

Setup

1. Charging the Device

Before initial use, fully charge the espresso machine. Use only the included 15-watt quick charger and USB-C cable. The power indicator lights will turn on when charging, reaching 90% in approximately 2 hours and 40 minutes for a full charge.



Outdoors

During the trip

Long drive times

Break times

Figure 3: Connecting the device to the quick charger.

2. Preparing Coffee (2-in-1 Functionality)

The machine supports both ground coffee and Nespresso Original capsules.

- **For Ground Coffee:** Fill the coffee powder chamber with up to 12g of ground coffee. Secure the lid.
- **For Nespresso Original Capsules:** Place a Nespresso Original capsule into the designated adapter. Secure the lid.



Figure 4: Preparing the coffee chamber for capsules or ground coffee.

3. Assembling the Machine

1. Fill the espresso container with ground coffee powder or a coffee capsule and assemble the appropriate part.



Figure 5: Filling the coffee container.

2. Screw the espresso container onto the main unit and place it on the included cup.



Figure 6: Assembling the coffee container to the main unit.

3. Add water to the water tank (max 80ml) and close the cover.




Figure 7: Adding water to the machine.

Operating Instructions

1. Brewing Espresso

1. After preparing the coffee and water as described in the Setup section, click the power button on the machine.




Figure 8: Initiating the brewing process with a single button press.

2. The machine will automatically heat the water to 195°F (90.5°C) and then begin brewing.
3. If using cold water, brewing takes approximately 6 minutes. If using hot water, brewing can be completed in about 50 seconds.




Figure 9: Quick heating and brewing in progress.

4. Once brewing is complete, your espresso will be dispensed into the cup.




Figure 10: Enjoying your espresso.

Maintenance

- **Cleaning:** The machine is **not** dishwasher safe. Clean all removable parts with warm, soapy water and rinse thoroughly. Wipe the main unit with a damp cloth.
- **Gas Release:** After each brew, it is necessary to open the coffee powder chamber to release gas pressure. Failure to do so may block the machine's ability to pump water for subsequent brews.




Figure 11: Releasing gas pressure after brewing.

Troubleshooting

- **Machine not turning on:** Ensure the machine is fully charged. The machine cannot be turned on while charging.
- **Water not pumping:** Check if the coffee powder chamber was opened to release gas pressure after the previous brew. Accumulated gas can prevent water pumping.
- **Capsule compatibility:** This machine is only compatible with Nespresso Original capsules. Other capsule types may not work correctly.

Specifications

| | |
|----------------------------|---|
| Brand | Narcissus |
| Model Name | CM-2599 |
| Capacity | 2.7 ounces (80ml water capacity) |
| Power Source | Battery (7800mAh) |
| Power (Heating) | 86.6 Watts |
| Coffee Input Type | Capsule (Nespresso Original), Ground Coffee (Max 12g) |
| Product Dimensions | 3.74"D x 3.74"W x 12.2"H |
| Item Weight | 1.5 lbs (1.87 pounds listed in specs, using 1.5 lbs from title for consistency) |
| Special Features | Auto Shut-Off, Portable, Timer |
| Included Components | Portable Electric Espresso Machine, USB-C Cable, User Manual |

Warranty and Support

Narcissus offers all customers 12 months of free new item replacement or refund service, and 24 months of after-sales service. For any quality problems or support inquiries, please contact customer service.