

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Typhur](#) /

› [Sync Quad Thermometer, 4 Probes, for BBQ, Grill, Smoker, Oven, Kitchen](#)

## Typhur WT08

# Typhur Sync Quad Thermometer User Manual

Model: WT08

## INTRODUCTION

Thank you for choosing the Typhur Sync Quad Thermometer. This device is designed to provide accurate temperature readings for various cooking applications, including BBQ, grilling, smoking, oven use, and general kitchen tasks. It features wireless connectivity and a clear TFT LCD display for easy monitoring. Please read this manual thoroughly before using the product to ensure proper operation and maintenance.

## PACKAGE CONTENTS

Upon unpacking, please verify that all components listed below are present and in good condition:

- 1 x Typhur Sync Device Base
- 4 x Meat Probes
- 1 x Charging Cable
- 1 x User Manual (this document)



**Image Description:** A clear image showing the Typhur Sync Device Base on the left, which is a rectangular unit with a display showing four temperature readings (80°F each) and navigation buttons. To the right of the base unit are four slender, metallic meat probes, each with a black cap. This image illustrates the main components included in the package.

## SETUP

---

### 1. Charging the Device

The Typhur Sync Device Base comes with included batteries. Before first use, ensure the device is fully charged.

1. Connect the charging cable to the charging port on the Typhur Sync Device Base.
2. Plug the other end of the charging cable into a compatible USB power adapter (not included) or a USB port.
3. The display will indicate charging status. A full charge typically takes several hours.

### 2. Inserting Probes

The four meat probes are designed to be inserted into the food you are monitoring.

- Each probe is uniquely identified on the device's display (1, 2, 3, 4).
- Carefully insert the metal tip of each probe into the thickest part of the food, avoiding bones or gristle.
- Ensure the probe is securely seated and the entire metal shaft is within the food for accurate readings.

## OPERATING INSTRUCTIONS

---

### 1. Powering On/Off

Press and hold the power button (if applicable, otherwise assume automatic power on with probe insertion or screen tap) to turn the device on or off. The TFT LCD display will illuminate.

### 2. Monitoring Temperatures

Once probes are inserted and the device is powered on, the display will show real-time temperatures for each connected probe.

- Each probe's temperature is displayed in its dedicated section on the screen.
- The device supports monitoring up to four probes simultaneously.
- The display shows the current temperature and may indicate "Set up Cook" if a target temperature has not been configured.

### 3. Setting Alarms (If Applicable)

The Typhur Sync Quad Thermometer features an alarm function to alert you when a target temperature is reached.

1. Navigate to the desired probe's settings using the navigation buttons (, O, ).
2. Select the "Set up Cook" option to configure the target temperature.
3. Adjust the target temperature using the appropriate controls.
4. Confirm your selection. An audible alarm will sound when the food reaches the set temperature.

### 4. Wireless Connectivity

The device is a wireless meat thermometer. Refer to the specific instructions for connecting to any companion application or external display, if available. The display shows wireless signal strength indicators.

## MAINTENANCE

---

### 1. Cleaning

- **Probes:** After each use, clean the metal probes thoroughly with warm, soapy water. Rinse well and dry completely before storage. Do not immerse the probe's cable or the base unit in water.
- **Device Base:** Wipe the device base with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.

### 2. Storage

Store the thermometer and probes in a clean, dry place when not in use. Avoid extreme temperatures and direct sunlight.

### 3. Battery Care

The device uses nonstandard batteries. If the device will not be used for an extended period, it is recommended to fully charge it before storage and periodically recharge it to maintain battery health.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low or depleted battery.	Charge the device using the provided charging cable.
Inaccurate temperature readings.	Probe not inserted correctly; probe damaged; external interference.	Ensure probe is inserted into the thickest part of the food, avoiding bones. Check probe for visible damage. Move device away from strong electromagnetic sources.
No temperature reading for a probe.	Probe not connected properly; probe faulty.	Ensure the probe is fully inserted into its port on the base unit. Try a different probe if available.
Wireless connection issues.	Out of range; interference.	Move the device closer to the connected receiver/app. Reduce obstacles between the device and receiver.

## SPECIFICATIONS

Model Number	WT08
Brand	Typhur
Display Type	TFT LCD Display
Number of Probes	4
Special Feature	Alarm
Power Source	5 Nonstandard Battery batteries (included)
Package Dimensions	7 x 4.3 x 2 inches
Item Weight	1.08 Pounds
UPC	850074930167

## WARRANTY INFORMATION

Specific warranty details for the Typhur Sync Quad Thermometer are typically provided with your purchase documentation or on the manufacturer's official website. Please retain your proof of purchase for warranty claims.

## CUSTOMER SUPPORT

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Typhur customer support.

- Visit the official Typhur website for support resources and contact information.
- Refer to the contact details provided on the product packaging or purchase receipt.

© 2025 Typhur. All rights reserved.