



Manuals.plus /

› YTE PRO /

› YTE PRO Handheld Cordless Vacuum VC-D17B1 User Manual

## YTE PRO VC-D17B1

# YTE PRO Handheld Cordless Vacuum VC-D17B1 User Manual

Model: VC-D17B1

## 1. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust bag and/or filters in place.
- Turn off all controls before unplugging.

## 2. PACKAGE CONTENTS

The YTE PRO Handheld Cordless Vacuum VC-D17B1 package includes the following items:

- YTE PRO Handheld Cordless Vacuum Unit
- Multi-surface Brush
- Crevice Nozzle
- Brush Nozzle (Push-in Brush)
- USB A to C Charging Cable
- User Manual



Image: The YTE PRO Handheld Cordless Vacuum with its three multi-functional accessories (multi-surface brush, crevice nozzle, and brush nozzle) and charging cable.

### 3. PRODUCT OVERVIEW

The YTE PRO Handheld Cordless Vacuum VC-D17B1 is a lightweight and portable cleaning device designed for convenience and efficiency. Weighing only 1.15 pounds, its cordless design and ergonomic non-slip handle ensure easy maneuverability for quick cleaning tasks in various environments.



Image: The YTE PRO Handheld Cordless Vacuum, highlighting its ultra-lightweight design (1.12 lb) against a sky background with feathers.

## 4. SETUP AND CHARGING

### 4.1 Initial Charge

Before first use, fully charge the vacuum cleaner. Connect the provided USB A to C charging cable to the vacuum's charging port and a suitable power source (e.g., power bank, car charger, laptop, or wall adapter). A full charge takes approximately 2.5 hours.



Image: The YTE PRO Handheld Cordless Vacuum connected via a USB-C cable, demonstrating multiple charging methods including a power bank, car charger, laptop, and wall adapter. The image indicates a 2.5-hour full charge time.

## Washable Filter

Reusable and washable HEPA filter.  
Make sure the filter is completely dry  
before assembling and using it!

Image: A close-up view of the Type-C charging port on the YTE PRO vacuum, illustrating its compatibility with various charging scenarios.

## 5. OPERATING INSTRUCTIONS

### 5.1 Power On/Off and Suction Modes

Press the power button to turn the vacuum on. The vacuum features two suction power modes:

- **Standard Mode:** Provides 8000 Pa suction for general dust and hair, offering approximately 25 minutes of continuous operation.
- **Max Mode:** Delivers 15000 Pa suction for tougher debris like crumbs and sand, with approximately 13 minutes of continuous operation.

Toggle between modes using the designated button on the handle.

# Two Speed & Powerful Suction

99% efficient dust removal



**8000**  
PA

**Eco Mode**



Dust



Hair

**15000**  
PA

**Max Mode**



Crumbs



Sand

Image: An illustration detailing the two suction modes: Eco Mode (8000 PA for dust, hair) and Max Mode (15000 PA for crumbs, sand), emphasizing 99% efficient dust removal.

# Two Speed & Powerful Suction



**Eco Mode**  
25 Mins



**High Speed Mode**  
13 Mins

Image: A woman using the YTE PRO vacuum in a car, with indicators for Eco Mode (25 Mins) and High Speed Mode (13 Mins) battery endurance.


## 5.2 Attaching Accessories

The vacuum comes with three multi-functional accessories for versatile cleaning:

- **Crevice Nozzle:** Ideal for reaching narrow gaps, crevices, cup holders, and car storage compartments.
- **Brush Nozzle (Push-in Brush):** Suitable for cleaning air vents and other delicate surfaces.
- **Multi-surface Brush:** Effective for picking up pet hair and dust from carpets and upholstery.

To attach an accessory, simply align it with the vacuum's intake opening and push firmly until it clicks into place. To remove, pull the accessory away from the vacuum.

## Multiple Nozzles



Push-in Brush



Multi-surface Brush



Crevice Nozzle

Image: The YTE PRO Handheld Cordless Vacuum demonstrating the use of its multiple nozzles: Push-in Brush for tight spaces, Multi-surface Brush for carpets, and Crevice Nozzle for narrow gaps.



Image: The Crevice Nozzle attachment shown cleaning debris from the edge of a floor, illustrating its precision for tight areas.



Image: The Push-in Brush attachment being used to clean a car's air vent, demonstrating its utility for intricate surfaces.



Image: The Multi-surface Brush attachment cleaning a fluffy rug, highlighting its effectiveness on fabric surfaces.

### 5.3 Cleaning Different Surfaces

The YTE PRO vacuum is versatile for cleaning various areas:

- **Car Interiors:** Use the crevice nozzle for tight spots and the multi-surface brush for floor mats and seats.
- **Home and Office:** Ideal for quick clean-ups of spills, dust on furniture, and pet hair on upholstery.



Image: The YTE PRO Handheld Cordless Vacuum being used to clean various parts of a car interior, including seats, cup holders, air vents, and floor mats, showcasing its multi-functional capabilities.

## 6. MAINTENANCE

### 6.1 Emptying the Dust Cup

The vacuum features a 300ml dust collection box. To empty:

1. Locate the one-touch emptying button.
2. Press the button to automatically open the lid and release debris into a trash receptacle.

This design minimizes direct contact with dirt.



Image: A three-step visual guide showing how to empty the 300ml dust cup: 1) Pressing the release button to empty debris, 2) Removing the filter, and 3) Rinsing the filter under water.

### 6.2 Cleaning the HEPA Filter

The vacuum is equipped with an enhanced HEPA filter that captures 99.97% of fine dust down to 0.3 microns. Regular cleaning extends the life of the vacuum and maintains suction power.

1. Remove the HEPA filter from the dust cup.
2. Rinse the filter under running water until clean.
3. Ensure the filter is completely dry before reassembling and using the vacuum.

## Perfect For All Your Needs



Image: Hands rinsing the washable HEPA filter under a faucet, with text emphasizing the reusability and importance of drying before reassembly.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is low or depleted	Charge the vacuum fully (approx. 2.5 hours).
Reduced suction power	Dust cup is full	Empty the dust cup.
Reduced suction power	HEPA filter is clogged	Clean the HEPA filter. Ensure it is completely dry before reinserting.
Reduced suction power	Nozzle/attachment is blocked	Remove the attachment and clear any obstructions.
Short battery life	Using Max Mode continuously	Switch to Standard Mode for longer battery life (25 mins vs 13 mins).

## 8. SPECIFICATIONS

Feature	Detail
Brand	YTE PRO
Model Name	VC-D17B1
Special Features	Cordless, HEPA Filtration, Lightweight, Portable, Strong suction force
Filter Type	HEPA Filter
Included Components	Adapter, Crevice Tool, Multi-surface Brush, Push-in Brush, User Manual
Form Factor	Handheld
Dust Cup Capacity	300 Milliliters
Suction Power	Standard Mode: 8000 Pa, Max Mode: 15000 Pa
Battery Life	Standard Mode: 25 minutes, Max Mode: 13 minutes
Charging Time	Approx. 2.5 hours
Battery Type	1 Lithium Ion battery (included)
Product Dimensions	2.76"L x 2.76"W x 15.04"H
Item Weight	1.15 pounds
Indoor/Outdoor Usage	Indoor



Image: The YTE PRO Handheld Cordless Vacuum with its dimensions clearly marked: 15.05 inches in length and 2.76 inches in width.

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official YTE PRO website. Keep your purchase receipt as proof of purchase for any warranty claims.