

Fanbulous B0FKG95VDF

Fanbulous 42 Inch Rustic Caged Ceiling Fan with Lights Instruction Manual

Model: B0FKG95VDF

1. SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, install, or operate this product. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always disconnect power at the main circuit breaker before installation or maintenance.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electric Code.
- Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Ensure the installation site can support the fan's weight (approximately 12 lbs).
- Do not operate the fan with damaged blades or housing.

2. PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer service.

- Fan Motor Assembly
- 5 Double-Sided Fan Blades
- Caged Light Kit (with E12 sockets)
- 6-inch Downrod
- Remote Control
- Mounting Hardware Kit
- Installation Instructions



Image 2.1: Overview of the Fanbulous 42 Inch Rustic Caged Ceiling Fan with Lights, including the remote control and double-sided blades.

3. SPECIFICATIONS

Brand	Fanbulous
Model Name	Fanbulous Rustic
Color	Black
Size	42 INCH
Product Dimensions	42"D x 11"W x 5"H
Item Weight	11.97 pounds
Power Source	AC
Wattage	75 watts

Noise Level	35 Decibels
Number of Power Levels	6
Control Method	Remote
Mounting Type	Downrod Mount
Recommended Room Size	Below 10 ft x 10 ft

Fanbulous

11.8"

6"

42 INCH

2×E12 BULBS
(Not Included)

Information

- Blade: **5 BLADES**
- Bulb Length: **TOTAL<10CM**
- Fan Speeds: **6 LEVELS**
- Timer: **1/4/8H**
- Large Room Size: **10FT×10FT**
- Socket Base: **E12**

Image 3.1: Detailed specifications and dimensions of the Fanbulous 42 Inch Ceiling Fan.

4. SETUP AND INSTALLATION

This section provides a general overview of the installation process. Refer to the detailed instructions included in your package for specific steps and diagrams.

4.1 Pre-Installation

- **Power Disconnection:** Before starting, ensure the power supply to the installation area is turned off at the circuit breaker.
- **Site Preparation:** Confirm the ceiling junction box is securely mounted and capable of supporting the fan's weight.
- **Tools Required:** Gather necessary tools such as a screwdriver, wire strippers, and a ladder.

4.2 Mounting the Fan

1. Attach the mounting bracket to the ceiling junction box using the provided screws.
2. Assemble the downrod to the fan motor assembly.
3. Carefully lift the fan assembly and hang it from the mounting bracket.

4.3 Wiring Connections

Connect the electrical wires according to the wiring diagram provided in your package. Ensure all connections are secure and insulated with wire nuts.

- Connect the fan's live (black) wire to the house live wire.
- Connect the fan's neutral (white) wire to the house neutral wire.
- Connect the fan's ground wire to the house ground wire.
- Install the receiver for the remote control as per instructions.

4.4 Attaching Blades and Light Kit

1. Attach the five fan blades to the motor housing using the provided screws. Ensure they are securely fastened.
2. Install the light kit to the bottom of the fan motor assembly.
3. Insert two E12 base bulbs (not included) into the light sockets.

Fanbulous

Farmhouse Ceiling Fan with Light



Famrhouse Style: Light Walnut Color



Industrial Style: Dark Walnut Color



Closed Cage



E12 Base



Vintage Blade

Image 4.1: Details of the fan blades, E12 bulb base, and caged light kit.

Your browser does not support the video tag.

Video 4.1: An official product video demonstrating the features and potentially aspects of installation for the 42 Inch Rustic Caged Ceiling Fan with Lights.

5. OPERATING INSTRUCTIONS

Your Fanbulous ceiling fan is operated using the included remote control.

5.1 Remote Control Functions



Image 5.1: Remote control layout and functions for the Fanbulous ceiling fan.

- **Power Button:** Turns the fan and light on/off.
- **Light Button:** Toggles the light on/off.
- **Fan Speed Buttons (1-6):** Adjusts the fan speed from 1 (lowest) to 6 (highest).
- **Timer Buttons (1H/4H/8H):** Sets the fan to turn off automatically after 1, 4, or 8 hours.
- **Natural Wind Mode:** Simulates natural breeze by varying fan speed.
- **Reversible Mode:** Changes the direction of blade rotation.
- **Mute Button:** Turns off the remote control's beep sound.

5.2 Reversible DC Motor (Summer/Winter Mode)

The fan features a reversible DC motor to optimize air circulation for different seasons.

- **Summer (Forward Rotation):** Blades rotate counter-clockwise, pushing air downwards to create a cooling breeze.
- **Winter (Reverse Rotation):** Blades rotate clockwise, drawing air upwards to circulate warm air near the ceiling throughout the room.



Image 5.2: Visual representation of the reversible DC motor function for seasonal use.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Dust the fan blades and light kit regularly with a soft, damp cloth. Avoid using abrasive cleaners that may damage the finish.
- **Bulb Replacement:** When replacing bulbs, ensure the power is off. Use E12 base bulbs.
- **Tightening Screws:** Periodically check and tighten all screws on the fan blades and mounting hardware to prevent wobbling or noise.

7. TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions. If the problem persists, contact customer service.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; loose wiring; remote control battery low.	Check circuit breaker; ensure all wiring is secure; replace remote battery.
Light does not work	Bulbs not installed correctly; faulty bulbs; loose wiring.	Ensure bulbs are screwed in tightly; replace bulbs; check light kit wiring.
Fan wobbles	Loose blade screws; unbalanced blades; loose mounting bracket.	Tighten all blade screws; ensure blades are balanced; check mounting bracket security.
Excessive noise	Loose screws; motor issue; blades hitting an obstruction.	Check and tighten all screws; ensure no obstructions; contact customer service if motor noise persists.

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact Fanbulous customer service directly. Fanbulous offers 24/7 customer support to assist with installation or after-sales inquiries.

For assistance, please visit the [Fanbulous Store on Amazon](#) or refer to the contact information provided in your product packaging.