

[Manuals.plus](#) /

› [MOOONICHE](#) /

› MOOONICHE 36-Inch Luxury Crystal Ceiling Fan with Light (Model: CFL-9707-36B) Instruction Manual

MOOONICHE CFL-9707-36B

MOOONICHE 36-Inch Luxury Crystal Ceiling Fan with Light Instruction Manual

Model: CFL-9707-36B

IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all instructions before beginning installation. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- Always disconnect power at the main circuit breaker before installation, maintenance, or cleaning.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electric Code (NEC). If you are unfamiliar with proper electrical wiring, consult a qualified electrician.
- Ensure the installation site can support the weight of the fan (approximately 10.5 kg).
- Do not bend the fan blades during installation or cleaning.
- Maintain a minimum clearance of 7 feet from the floor to the bottom of the fan blades.
- Do not operate the fan if any part is damaged.

PRODUCT OVERVIEW

The MOOONICHE 36-inch Luxury Crystal Ceiling Fan with Light (Model CFL-9707-36B) combines the functionality of a ceiling fan with the aesthetic appeal of a crystal chandelier. It features dimmable LED lighting, a 6-speed reversible motor, and retractable fan blades, all controllable via remote or a mobile application.



Image: The MOOONICHE 36-inch Luxury Crystal Ceiling Fan with Light installed in a living room, showcasing its elegant design and key features.



Image: Icons illustrating key features: Color Adjustable, Timing Setting, 6 Wind Speeds, Reverse Wind, Remote Control, APP Control, Sleep Mode, Brightness Adjustable.

Key components include a quiet pure copper motor, sparkling K9 crystals, a dimmable LED light source, and durable ABS retractable fan blades.



Image: Close-up views of the quiet pure copper motor, sparkling K9 crystals, dimmable LED light source, and ABS retractable fan blades.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Ceiling Fan Assembly
- Light Kit (integrated LED)
- Remote Control
- Instruction Manual
- Downrods (4.9 inch and 7.9 inch options)
- Mounting Hardware

SETUP AND INSTALLATION

Professional installation is recommended for safety and optimal performance. Ensure power is disconnected at the circuit

breaker before starting.

Mounting Options

This ceiling fan supports both flat and sloped ceiling installations. For sloped ceilings, ensure the angle is less than 22 degrees.



6 WIND SPEEDS



1-2 LOW WIND
For Sleeping & Resting



3-4 MEDIUM WIND
For Work & Housework



5-6 HIGH WIND
For Sports & Recreation

Image: Diagram showing product dimensions (Diameter 36" extended, 15.4" closed; Max height 25.8" with downrods) and illustrations for flat and sloped ceiling mounting options.

General Installation Steps (Summary)

1. Secure the mounting bracket to the ceiling junction box.
2. Assemble the downrod with the canopy and hang the fan motor assembly.
3. Perform electrical wiring connections (Live, Neutral, Ground).
4. Attach the light kit and crystal components.
5. Restore power and test the fan and light functions.

For a detailed installation guide, please refer to the included instruction manual or contact MOOONICHE customer

support. An installation video may also be available on the [MOOONICHE Store](#).

OPERATING INSTRUCTIONS

Control Methods

The fan and light can be controlled using the included remote control or the 'Fan Lamp Pro' mobile application.

Light Operation

The integrated LED light source is dimmable and offers stepless adjustment of color temperature (3000K Warm White to 6500K Cool White) and brightness (352-3048 lumens). Use the remote control or app to customize your lighting preferences.



Color
Adjustable



Timing
Setting



6 Wind
Speeds



Reverse
Wind



Remote
Control



APP
Control



Sleep
Mode



Brightness
Adjustable

Image: Visual representation of adjustable color temperatures (Warm-3000K, Natural-4500K, White-6500K) and brightness adjustment from 10% to 100%.

Fan Operation

- **6-Speed Adjustment:** Choose from 6 fan speeds to suit your comfort level. The fan also features a natural wind

mode.

- **Reversible Wind:** Change the fan direction for seasonal use. Forward rotation (downdraft) is ideal for cooling in summer, while reverse rotation (updraft) helps circulate warm air in winter.
- **Timer Function:** Set the fan to turn off automatically after a specified period, ideal for sleep.
- **Quiet Operation:** Designed for minimal noise, ensuring a peaceful environment.



Color Temperature

3000K

6500K



Warm-3000K



Natural-4500K



White-6500K

Press "+" "-" to adjust light brightness and color temperature



Brightness

10%

100%



Image: Illustration of 6 wind speeds, categorized for sleeping/resting (1-2 Low Wind), work/housework (3-4 Medium Wind), and sports/recreation (5-6 High Wind).

QUIET OPERATION CEILING FAN







Image: Diagram showing the quiet operation of the fan at 35dB, comparing it to other sound levels like flower sound (10dB) and normal conversation (45dB).

36"

PRODUCT INFORMATION



Mounting Option



Weight:	10.5kg
Max RPM:	270
Light Source:	LED Strip

Image: Comparison of forward rotation (cooling down for hot days) and reverse rotation (promoting airflow in cold weather).

Retractable Blades

The fan features retractable blades that extend when the fan is in operation and retract when turned off, transforming the unit into a chandelier.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Dust the fan blades and crystal components regularly with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth with mild soap, then wipe dry immediately. Do not use abrasive cleaners or solvents.
- **Tightness Check:** Periodically check all screws and connections for tightness. Re-tighten as necessary.
- **Blade Balance:** If the fan wobbles, ensure all blades are securely attached and balanced.

TROUBLESHOOTING GUIDE

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power, loose wiring, remote battery dead.	Check circuit breaker. Verify wiring connections. Replace remote battery.
Light does not work	Loose wiring, LED failure.	Check light kit wiring. Contact customer support if LED is faulty.
Remote control not working	Dead battery, remote not paired.	Replace remote battery. Refer to manual for pairing instructions.
Fan wobbles	Loose mounting, unbalanced blades.	Ensure mounting bracket is secure. Check blade screws and balance.

If the problem persists after attempting these solutions, please contact MOOONICHE customer support.

PRODUCT SPECIFICATIONS

Feature	Specification
Brand	MOOONICHE
Model Name	CFL-9707-36B
ASIN	B0FKGL1PDG
UPC	727376377702
Color	Black
Material	Crystal
Product Dimensions (Closed)	15.4"D x 15.4"W x 20.4"H
Product Diameter (Extended)	36 Inches
Max Height (with downrods)	25.8 Inches
Downrod Lengths Included	4.9 Inches, 7.9 Inches
Weight	10.5 kg
Power Source	AC
Wattage	38 watts (LED)
Number of Speeds	6
Control Method	Remote, App
Special Features	Adjustable Height, Quiet Operation, Remote Controlled, Timer, Dimmable Light, Reversible Wind

Feature	Specification
Room Type	Bedroom, Dining Room, Kitchen, Living Room

WARRANTY AND CUSTOMER SUPPORT

This MOOONICHE ceiling fan comes with a **1-Year Warranty** from the date of purchase, covering manufacturing defects. For any questions, technical assistance, or warranty claims, please contact MOOONICHE customer support. You can find contact information and additional resources on the official [MOOONICHE Store on Amazon](#).

MOOONICHE is committed to providing quality products and excellent service. If you encounter any issues, please reach out via email for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question