

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [LABIGO](#) /

› LABIGO EM-323 Pressurized Handheld Steam Cleaner User Manual

## LABIGO EM-323

# LABIGO EM-323 Pressurized Handheld Steam Cleaner User Manual

Model: EM-323 | Brand: LABIGO

## 1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your LABIGO EM-323 Pressurized Handheld Steam Cleaner. Please read it thoroughly before operation and retain it for future reference.

## 2. IMPORTANT SAFETY INSTRUCTIONS

- Always unplug the appliance when not in use and before cleaning.
- Do not overfill the water tank (maximum 250ml) to prevent leaks or water spray instead of steam.
- Ensure the safety cap is securely tightened before operation.
- Allow the unit to cool down for at least 5 minutes and fully depressurize before refilling water.
- Keep hands and face away from the steam nozzle during operation. Steam is hot (up to 230°F/110°C) and can cause burns.
- Use only clean water. Do not add cleaning solutions, perfumes, or other chemicals to the water tank.
- Keep the appliance out of reach of children and pets.
- Do not immerse the appliance in water or other liquids.
- The appliance features Smart Dry Boil Protection, which automatically stops heating if the water level is too low.

## 3. PACKAGE CONTENTS

Your LABIGO EM-323 Steam Cleaner package includes the following items:

- Handheld Steam Cleaner (1)
- Extended Spray Nozzle (1)
- Long Spray Nozzle (1)

- Fabric/Cloth Cleaning Accessory (1)
- Window/Glass Cleaning Accessory (1)
- Bent Nozzle (1)
- Round Nylon Brush (3)
- Flat Scraper Tool (1)
- Grout Tool (1)
- Cleaning Cloth (1)
- Measuring Cup (1)
- Funnel (1)



Image: The LABIGO Steam Cleaner and its 13 included accessories, including various nozzles, brushes, and cleaning tools.

## 4. SETUP AND WATER FILLING

1. **Attach Desired Accessory:** Select the appropriate nozzle or brush head for your cleaning task. Simply insert the accessory into the main unit and twist to secure it.
2. **Fill Water Tank:** Unscrew the safety cap. Use the provided measuring cup and funnel to add up to 250ml of clean water to the tank. Do not overfill, as this can cause leaks or water spray instead of steam. The measuring cup has gradations at 175ml and 75ml to help measure the total 250ml.
3. **Secure Safety Cap:** Retighten the safety cap securely.
4. **Plug In:** Plug the power cord into a suitable electrical outlet. The indicator light will illuminate.

5. **Heat Up:** Allow the unit to heat up for approximately 3-5 minutes until the indicator light turns off, signaling it's ready for use.

Your browser does not support the video tag.

Video: Demonstrates the correct installation of accessories and water filling procedure for the LABIGO Handheld Steam Cleaner.

Your browser does not support the video tag.

Video: Important tip on water filling: do not exceed 250ml to prevent leaks or water spray instead of steam.

## 5. OPERATING INSTRUCTIONS

---

Once the indicator light turns off, the steam cleaner is ready. Press the steam trigger on the handle to release high-pressure steam. Direct the steam towards the surface you wish to clean. For optimal results, keep the nozzle or brush close to the dirt.

### Cleaning Applications:

- **Kitchen:** Effectively remove grease and grime from stovetops, range hoods, and sinks.
- **Bathroom:** Clean tile grout, remove mold, and sanitize toilets and showers.
- **Windows & Glass:** Use the window/glass cleaning accessory for streak-free results.
- **Upholstery & Fabric:** Refresh and clean upholstery, sofas, and clothing with the fabric/cloth accessory.
- **Automotive:** Clean car interiors, wheels, and other surfaces.



Image: A woman using the LABIGO Steam Cleaner to efficiently clean a greasy stovetop, demonstrating its effectiveness on kitchen surfaces.

Your browser does not support the video tag.

Video: Shows the LABIGO Handheld Steam Cleaner in action, highlighting its cleaning effectiveness on various surfaces.

## 6. MAINTENANCE

- 1. Empty Water After Use:** After each use, unplug the unit and allow it to cool for at least 5 minutes. Fully vent any residual steam by pressing the steam button until the indicator light goes off. Carefully unscrew the safety cap and empty any remaining water from the tank into a bowl or sink.
- 2. Clean Accessories:** Clean all accessories with water and mild soap. Ensure they are dry before storing.
- 3. Storage:** Store the steam cleaner and its accessories in a cool, dry place. Replace the safety cap before storage to prevent dust or insect contamination.



Image: Step-by-step guide on how to safely refill the steam cleaner's water tank after use, emphasizing cooling and venting.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or weak steam.	Water tank is empty or low.	Refill the water tank (max 250ml) and allow to heat up.
Water spraying instead of steam.	Water tank is overfilled.	Empty excess water from the tank (max 250ml).
Unit not heating up.	Not plugged in or power issue.	Ensure the unit is properly plugged into a working outlet. Check the indicator light.
Leaks from the safety cap.	Cap not tightened or overfilled.	Ensure the safety cap is tightly screwed on. Do not overfill the water tank.

## 8. PRODUCT SPECIFICATIONS

- **Brand:** LABIGO
- **Model Name:** EM-323
- **Power:** 1050 Watts
- **Water Tank Capacity:** 350 ml (Recommended fill: Max 250ml)
- **Heat-Up Time:** 3-5 Minutes
- **Maximum Steam Temperature:** 230°F (110°C)
- **Power Cord Length:** 9.8 ft
- **Special Features:** 13-piece accessory set, High-Pressure Steam, Chemical-Free Cleaning, Smart Dry Boil Protection, Lightweight
- **Dimensions:** 9.92 x 5.71 x 9.65 inches
- **Item Weight:** 4.05 pounds (1.84 Kilograms)

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your

purchase or visit the official LABIGO website. Keep your purchase receipt for warranty claims.  
You can visit the [LABIGO Store](#) for more products and information.