Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM FPSC48VDW8-DGY

T4TREAM 48" Fluted Makeup Vanity Desk with Large LED Lighted Mirror

Model: FPSC48VDW8-DGY | **Brand:** T4TREAM

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your T4TREAM 48" Fluted Makeup Vanity Desk. Please read all instructions carefully before assembly and use to ensure safe and proper functionality. Keep this manual for future reference.

Safety Information

- Always assemble the vanity on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use.
- Do not overload drawers or shelves to prevent tipping or damage.
- Keep electrical components (LED mirror, charging station) away from water.
- Supervise children around the vanity to prevent accidents.
- If any parts are missing or damaged, do not proceed with assembly. Contact customer support.

Package Contents

Verify that all components listed below are present before beginning assembly:

- Vanity Desk Frame (various wooden panels)
- LED Lighted Mirror
- 8 Drawers (2 large with dividers, 6 smaller)
- Drawer Slides and Hardware
- Charging Station Unit
- Hair Dryer Stand
- Assembly Hardware (screws, dowels, L-wrench)

- Instruction Manual



Figure 1: Exploded view of vanity desk components and overall dimensions.

Assembly Instructions

Assembly is required for this vanity desk. Please follow the steps below carefully. It is recommended to have two people for assembly.

Assembly Video Guide

Video 1: Step-by-step assembly guide for the T4TREAM Fluted Makeup Vanity Desk. This video demonstrates the assembly process using a Natural Oak colored vanity, but the steps are identical for the Dark Grey model.

Step-by-Step Written Guide

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface. Refer to the parts list and diagrams in your printed manual to identify each piece.

2. **Assemble Drawer Boxes:** Follow the diagrams to assemble the individual drawer boxes. Attach the drawer slides to the sides of each drawer box using the provided screws. Ensure the slides are oriented correctly for smooth operation.
3. **Assemble Drawer Dividers:** For the larger drawers, interlock the wooden dividers to create compartments. Place these assembled dividers into the large drawer boxes.
4. **Construct Vanity Base:** Assemble the main vanity desk frame by connecting the side panels to the central support beams using the provided hardware. Ensure all connections are secure.
5. **Install Drawer Slides on Frame:** Attach the corresponding drawer slides to the interior sides of the vanity desk frame where the drawers will be inserted.
6. **Attach Charging Station and Hair Dryer Stand:** Secure the charging station unit and the hair dryer stand to the designated side panel of the vanity desk using the provided screws.
7. **Install Mirror Support Brackets:** Attach the vertical support brackets to the back of the vanity desk frame, ensuring they are aligned with the mirror mounting points.
8. **Mount the LED Mirror:** Carefully lift and attach the LED lighted mirror to the support brackets on the back of the vanity desk. Secure it with the appropriate fasteners. Connect the mirror's power cable to the charging station.
9. **Insert Drawers:** Gently slide each assembled drawer into its respective slot on the vanity desk frame. Test each drawer for smooth movement.
10. **Final Checks:** Double-check all connections and ensure the vanity is stable. Plug the charging station into a power outlet.

Operating Instructions

LED Lighted Mirror

- **Power On/Off:** Tap the touch sensor button on the mirror surface to turn the LED lights on or off.
- **Change Lighting Modes:** Tap the touch sensor button repeatedly to cycle through three color temperature settings: Warm Light, Cool Light, and Natural Light.
- **Adjust Brightness:** Long-press the touch sensor button to continuously adjust the brightness level from 0% to 100%. Release the button when the desired brightness is reached.



Figure 2: LED mirror touch controls for adjusting light settings.

Integrated Charging Station

- The vanity desk is equipped with a built-in charging station featuring 2 AC outlets (125V/12A) and USB/Type-C ports (5V/2.1A).
- Plug the vanity's main power cord into a wall outlet.
- Connect your electronic devices (e.g., phone, tablet, hair dryer) to the appropriate ports on the charging station for convenient power access.



Figure 3: Built-in charging station and hair dryer stand.

Drawers and Storage

- The vanity features 2 large drawers with detachable dividers and 6 smaller drawers.
- Use the dividers in the large drawers to organize cosmetics, jewelry, and other small items efficiently.
- The transparent glass tabletop allows for easy visibility and access to items stored in the top drawers.



Figure 4: Organized drawers with detachable partitions.

Maintenance

- **Cleaning the Surface:** Wipe the vanity surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Cleaning the Mirror:** Use a glass cleaner and a microfiber cloth to clean the LED mirror. Do not spray cleaner directly onto the mirror to avoid liquid seeping into electrical components.
- **Drawer Care:** Periodically check drawer slides for smooth operation. If needed, clean any dust or debris from the tracks.
- **Electrical Components:** Ensure the charging station and mirror wiring are free from damage. Do not attempt to repair electrical components yourself.

Troubleshooting

Problem	Possible Cause	Solution
LED mirror lights do not turn on.	Power cord not plugged in; loose connection; faulty power outlet.	Check if the vanity's power cord is securely plugged into a working wall outlet. Ensure the mirror's cable is properly connected to the charging station. Try a different outlet.
Drawers are difficult to open or close.	Drawer slides misaligned; debris in tracks; overloaded drawer.	Remove the drawer and inspect the slides for misalignment or obstructions. Clean the tracks. Redistribute items in the drawer to reduce weight.
Charging station is not providing power.	Vanity not plugged in; power surge; device issue.	Verify the vanity's main power cord is plugged in. Check if the wall outlet is functional. Test with a different device. If issues persist, contact customer support.

Specifications

- **Brand:** T4TREAM
- **Model Number:** FPSC48VDW8-DGY
- **Product Dimensions:** 13.7"D x 48"W x 53.6"H
- **Item Weight:** 145 pounds
- **Color:** Dark Grey
- **Frame Material:** Engineered Wood
- **Assembly Required:** Yes
- **Mirror Type:** LED Lighted Mirror with 3 Color Temperatures and Adjustable Brightness
- **Storage:** 2 Large Drawers (with dividers), 6 Small Drawers
- **Charging Station:** 2 AC Outlets (125V/12A), USB/Type-C Ports (5V/2.1A)

Warranty and Support

T4TREAM products are designed for quality and durability. For any questions, missing parts, or issues not covered in this manual, please contact T4TREAM customer service. Please have your model number (FPSC48VDW8-DGY) and purchase information ready when contacting support.

Contact information can typically be found on the product packaging or the retailer's website where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FKGRSSJ1

More documents and user manuals: **https://manuals.plus/**