

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [EUHOMY](#) /

› [EUHOMY Nugget Ice Maker IM017-NBL User Manual](#)

EUHOMY IM017-NBL

EUHOMY Nugget Ice Maker IM017-NBL User Manual

Model: IM017-NBL | Brand: EUHOMY

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance to ensure safe operation and optimal performance. Keep this manual for future reference.

- Ensure the appliance is connected to a grounded power outlet with the correct voltage (115 Volts).
- Do not immerse the power cord, plug, or any part of the appliance in water or other liquids.
- Supervise children when the appliance is in use. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.
- Unplug the ice maker before cleaning, servicing, or when not in use for extended periods.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Place the ice maker on a stable, level surface, away from direct sunlight, heat sources, and corrosive gases.
- Ensure adequate ventilation around the appliance. Maintain at least 5 inches of space around the sides and back.
- Use only potable water in the water reservoir.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

PRODUCT OVERVIEW

The EUHOMY Nugget Ice Maker IM017-NBL is a countertop appliance designed to produce chewable nugget ice efficiently. It features a self-cleaning function and intuitive controls for ease of use.

Included Components

- Ice Maker Machine
- Ice Scoop
- Instruction Manual

What's Included

1 ice shovel, 1 ice basket (2lbs) , 1 water tank(1.8L)



Image Description: This image displays the EUHOMY Nugget Ice Maker with its dimensions (13.8"D x 9.8"W x 14.9"H) and highlights the included accessories: a 2-pound capacity ice basket, an ice scoop, and a 1.8-liter water tank.



Image Description: A front-angle view of the EUHOMY Nugget Ice Maker. The ice collection bin is pulled out, revealing a generous amount of fresh nugget ice. The control panel with 'LIGHT', 'CLEAN', and 'ICE' buttons is visible at the top.

SETUP

1. Unpacking

Carefully remove all packaging materials, including any protective film or tape. Inspect the ice maker for any signs of damage during transit. If any damage is found, do not operate the appliance and contact customer support.

2. Placement

Place the ice maker on a flat, stable, and heat-resistant surface. Ensure there is at least 5 inches (12.7 cm) of clear space around the back and sides for proper ventilation. Avoid placing the unit near heat sources or in direct sunlight.

3. Initial Cleaning

Before first use, it is recommended to clean the ice maker. Refer to the 'Maintenance' section for detailed cleaning instructions, particularly the self-cleaning function.

4. First Use Preparation

After cleaning, ensure the drain plug is securely closed. Fill the water reservoir with potable water up to the 'MAX' fill line. Do not overfill. Allow the unit to sit for at least one hour before plugging it in to allow refrigerants to settle.

Pull-out Water Tank

Easy refill, and simple to clean-ensuring
every ice cube is fresh



Image Description: This image shows a hand pulling out the transparent water tank from the side of the ice maker, positioned under a kitchen faucet, illustrating the easy refill process.

OPERATING INSTRUCTIONS

1. Adding Water

Open the water tank cover and fill the reservoir with clean, potable water. Ensure the water level does not exceed the 'MAX' indicator. Close the cover securely.

2. Making Ice

Plug the ice maker into a grounded electrical outlet. Press the **ICE** button on the control panel. The 'Making Ice' indicator light will illuminate, and the unit will begin the ice-making cycle. The first batch of ice typically takes 7-10 minutes.



Image Description: A close-up view of the ice maker's control panel, showing a finger pressing the 'ICE' button to initiate the ice production cycle.

3. Understanding Indicator Lights

- **Making Ice:** Indicates the unit is actively producing ice.
- **Low Water / Add Water:** Illuminates when the water reservoir needs refilling. The ice maker will pause operation until water is added.



Image Description: A visual representation of the 'Add Water' indicator light on the ice maker's display, signaling that the water reservoir requires refilling.

- **Ice Full:** Illuminates when the ice basket is full. The ice maker will automatically stop producing ice until some ice is removed.




Image Description: A visual representation of the 'Ice Full' indicator light on the ice maker's display, indicating that the ice storage bin is at capacity.

- **Cleaning:** Indicates the unit is performing a self-cleaning cycle.

4. Using the Light Function

Press the **LIGHT** button to turn the internal illumination on or off, allowing you to monitor the ice-making process or simply illuminate the ice bin.

MAINTENANCE

Regular cleaning and maintenance are crucial for the longevity and hygienic operation of your ice maker.

1. Self-Cleaning Function

The ice maker is equipped with an automatic self-cleaning system. To activate:

1. Ensure the water reservoir is filled with clean water.

2. Press the **CLEAN** button on the control panel.
3. The unit will perform a 20-minute cleaning cycle. The 'Cleaning' indicator light will be on.
4. Once the cycle is complete, drain the water from the unit as described below.

Automatic Cleaning

Press **"Clean"** button
to activate **20mins** self-cleaning function




Image Description: An X-ray style illustration of the ice maker's internal components, depicting water actively circulating and splashing during the automatic self-cleaning process.

2. Regular Manual Cleaning

For thorough cleaning, especially if using hard water, perform manual cleaning:

1. Unplug the ice maker from the power outlet.

2. Remove the ice basket and clean it with mild detergent and warm water. Rinse thoroughly.
3. Drain all water from the reservoir (see 'Draining Water' below).
4. Wipe the interior of the water reservoir and ice-making components with a soft cloth dampened with a solution of water and a small amount of vinegar or a food-grade cleaning agent.
5. Rinse the interior thoroughly with clean water to remove any cleaning solution residue.
6. Wipe the exterior of the unit with a soft, damp cloth.
7. Ensure all parts are dry before reassembling and operating the unit.

3. Draining Water

To drain water from the unit:

1. Place the ice maker near a sink or prepare a container to collect the water.
2. Locate the drain plug at the bottom of the unit.
3. Carefully remove the drain plug to allow water to flow out.
4. Once all water has drained, securely reinsert the drain plug.

TROUBLESHOOTING

If you encounter issues with your ice maker, please consult the following table before contacting customer support.

Problem	Possible Cause	Solution
Ice maker not turning on	No power supply; Power cord not plugged in; Fuse blown/circuit breaker tripped.	Check power outlet; Ensure cord is securely plugged in; Reset circuit breaker or replace fuse.
'Add Water' indicator is on	Water reservoir is empty or low.	Fill the water reservoir with potable water up to the 'MAX' line.
'Ice Full' indicator is on	Ice basket is full.	Remove ice from the basket. The unit will resume ice production automatically.
No ice production or very little ice	Insufficient water; Ambient temperature too high; Air vent blocked; Refrigerant issue.	Add water; Ensure unit is in a cool environment; Clear any obstructions from air vents; Contact customer support if issue persists.
Ice melts quickly	High ambient temperature; Ice not transferred to freezer.	Ensure unit is in a cool environment; Transfer ice to a freezer for storage as the ice maker is not a freezer.
Unusual noise during operation	Normal operation sounds (compressor, water pump); Unit not level.	Ensure the unit is on a level surface. If noise is excessive or unusual, contact customer support.

SPECIFICATIONS

Feature	Specification
Brand	EUHOMY
Model Name	IM017-NBL
Product Dimensions (D x W x H)	13.8" x 9.8" x 14.9"
Ice Production per Day	Up to 40 Pounds
Water Tank Capacity	1.8 Liters (approx. 0.48 Gallons)
Ice Basket Capacity	2 Pounds
Wattage	139 Watts
Voltage	115 Volts
Refrigerant	R600a
Material	Stainless Steel
Item Weight	25 pounds
UPC	850077022579




WARRANTY AND SUPPORT

EUHOMY products are manufactured to high-quality standards. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your purchase or visit the official EUHOMY website.

If you require technical assistance, troubleshooting beyond this manual, or have questions about your product, please contact EUHOMY customer support. Contact details can typically be found on the manufacturer's website or on the product packaging. When contacting support, please have your model number (IM017-NBL) and purchase information readily available.

© 2025 EUHOMY. All rights reserved.

Related Documents - IM017-NBL

	<p>User Manual of Product 1: EUHOMY Nugget Ice Maker - IM03S - Day Water Refill, Self Cleaning Nugget Ice Maker Machine with 30L Reserve, Ice Makers Countertop Ideal for Home, Office, Bar, and Party. (Silver)</p> <p><u>Euhomy IM-03S Nugget Ice Maker User Manual & Instructions</u></p> <p>Comprehensive user manual for the Euhomy IM-03S countertop nugget ice maker. Includes setup, operation, cleaning, maintenance, troubleshooting, and warranty information.</p>
	<p><u>Euhomy Portable Nugget Ice Maker Instruction Manual</u></p> <p>Instruction manual for the Euhomy Portable Nugget Ice Maker (SKU: IM002-NBL-USEH), covering safety precautions, operation, maintenance, troubleshooting, and warranty information.</p>
	<p><u>EUHOMY IM021-BGR-EH-HD Grey Countertop Ice Maker - 27 lbs/Day</u></p> <p>Discover the EUHOMY IM021-BGR-EH-HD, a compact and efficient grey countertop ice maker. Produces up to 27 lbs of bullet ice daily with fast 6-minute cycles, self-cleaning, and quiet operation. Includes ice scoop.</p>
	<p><u>Euhomy IM-12S Portable Nugget Ice Maker Instruction Manual</u></p> <p>This instruction manual provides detailed guidance on operating, maintaining, and troubleshooting the Euhomy IM-12S Portable Nugget Ice Maker. Learn about safety precautions, unit components, cleaning procedures, technical specifications, and warranty information.</p>
	<p><u>Euhomy IM-F Ice Maker: Instruction Manual, Operation, and Troubleshooting Guide</u></p> <p>Comprehensive guide for the Euhomy IM-F ice maker, covering safety precautions, operation, installation, maintenance, specifications, warranty, and troubleshooting tips.</p>
	<p><u>Euhomy Portable Nugget Ice Maker User Manual IM023-N</u></p> <p>User manual for the Euhomy Portable Nugget Ice Maker (Model IM023-N). Learn about setup, operation, cleaning, troubleshooting, and warranty information for your Euhomy ice maker.</p>

