VECYS LYCZ629-B

VECYS Bottom Loading Ice Maker Self-Clean Hot Cold Water Dispenser

Model: LYCZ629-B User Manual

1. Introduction

Thank you for choosing the VECYS LYCZ629-B Bottom Loading Ice Maker Self-Clean Hot Cold Water Dispenser. This appliance is designed to provide convenient access to hot, cold, and room temperature water, along with ice cubes, from a single unit. Please read this manual thoroughly before operation to ensure proper use, maintenance, and safety.

2. Important Safety Instructions

- Always plug the dispenser into a grounded electrical outlet. Do not use extension cords.
- Keep the appliance away from direct sunlight and heat sources. Ensure adequate ventilation around the unit.
- Do not immerse the dispenser, cord, or plug in water or other liquids.
- **Child Safety Lock:** The hot water dispenser features a child safety lock. Always engage this lock to prevent accidental hot water dispensing and potential burns.
- Supervise children when they are near the appliance.
- Use only potable water in the dispenser.
- Unplug the unit before cleaning or performing any maintenance.
- Do not operate the appliance with a damaged cord or plug.

3. Product Overview

The VECYS LYCZ629-B is a versatile 4-in-1 appliance, combining a water dispenser with an ice maker. It provides hot, cold, and room temperature water, along with bullet-shaped ice cubes.



Image: The VECYS LYCZ629-B unit demonstrating its 4-in-1 dispensing capabilities: hot water, cold water, fresh (room temperature) water, and ice cubes. The image shows the bottom-loading water bottle compartment.

Key Features:

- **4-in-1 Functionality:** Delivers hot, cold, room temperature water, and ice.
- **Bottom-Loading Design:** Eliminates heavy lifting and spills during water bottle replacement. Compatible with 3 to 5-gallon bottles.
- **Self-Clean Function:** Simplifies maintenance and ensures hygiene.
- **Child Safety Lock:** Prevents accidental hot water dispensing.
- **High-Performance Compressor:** Ensures efficient ice making and stable product performance.



Image: An illustration of the high-quality compressor used in the VECYS dispenser, highlighting its low energy consumption, fast ice making, and low noise operation.

4. Setup

4.1 Unpacking

- Carefully remove the dispenser from its packaging.
- Inspect the unit for any shipping damage. Contact customer support if damage is found.
- Remove all packing materials, including any protective films or tapes.

4.2 Placement

- Place the dispenser on a firm, level surface capable of supporting its weight when full.
- Ensure there is at least 10 cm (4 inches) of clearance from walls on all sides for proper ventilation.
- Avoid placing the unit in direct sunlight or near heat-generating appliances.
- The unit dimensions are approximately 45D x 36.6W x 112H centimetres.



Image: The VECYS water dispenser with its dimensions (12.2in width, 16.54in depth, 40.75in height) and examples of suitable placement in various environments like a kitchen, dormitory, or restaurant.

4.3 Water Bottle Installation

1. Open the lower cabinet door of the dispenser.
2. Remove the cap from a new 3 or 5-gallon water bottle.
3. Insert the probe of the water pump into the opening of the water bottle.
4. Slide the water bottle into the cabinet and close the door.

4.4 Initial Flush

Before first use, or after long periods of inactivity, flush the system:

- Place a large container under the cold water spigot.
- Dispense at least 1 liter (approximately 4 cups) of cold water.
- Repeat for the room temperature water spigot.

- For hot water, dispense until water flows smoothly (ensure the hot water tank is full before activating heating).

4.5 Power Connection

Plug the power cord into a grounded 120V AC electrical outlet. The unit will begin to cool and heat water, and the ice maker will start its cycle.

5. Operating Instructions

5.1 Powering On/Off

Press the ON/OFF button on the control panel to power the unit on or off. Individual heating and cooling functions can also be controlled via dedicated buttons.

5.2 Dispensing Water



Image: The VECYS water dispenser showing the dispensing of cold water into a glass, fresh (room temperature) water, and hot water into a cup for coffee or tea.

- **Cold Water:** Place your cup under the cold water spigot and press the cold water button. Release to stop.
- **Room Temperature Water:** Place your cup under the room temperature water spigot and press the corresponding button. Release to stop.
- **Hot Water:** This spigot has a child safety lock. First, slide or press the safety lock, then press the hot water button. Release both to stop.



Image: A close-up of the VECYS water dispenser highlighting the anti-scald child safety lock switch, with a child reading nearby, emphasizing safety.

5.3 Ice Making Function

The dispenser can produce up to 22 lbs of bullet-shaped ice cubes daily, with 9 pieces per cycle.



Image: The VECYS dispenser showing ice cubes being dispensed into a glass, illustrating its quick ice-making capability of 22 lbs per day and 9 pieces per cycle.

- Ensure the ice-making function is enabled on the control panel.
- The unit will automatically begin producing ice once the water reservoir is filled and the ice function is active.
- Ice is stored in an internal bin. Use the ice dispensing lever or button (if applicable) to retrieve ice.
- Note: The ice storage bin is not a freezer and ice may melt over time if not used. The unit will automatically make more ice as needed.

5.4 Self-Clean Function

The self-clean function helps maintain the hygiene of the water paths.

1. Ensure a water bottle is installed.
2. Press and hold the "Self-Clean" button (refer to your control panel for exact labeling) for a few seconds to activate the cycle.
3. The unit will run a cleaning cycle, typically indicated by a light or display.

4. Once the cycle is complete, dispense and discard a few cups of water from each spigot to flush out any cleaning solution residue.

6. Maintenance

6.1 Exterior Cleaning

- Unplug the dispenser before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Clean the drip tray and grille regularly. These parts are usually removable and can be washed with mild soap and water.

6.2 Internal Cleaning (Self-Clean Function)

Utilize the built-in self-clean function regularly (e.g., once a month or with each new water bottle) to keep the internal water lines clean. Follow the steps outlined in Section 5.4.

6.3 Draining the Unit

If the dispenser will not be used for an extended period, or for deep cleaning, it is recommended to drain the unit.

1. Unplug the dispenser and remove the water bottle.
2. Place a bucket under the drain plug, usually located at the back or bottom of the unit.
3. Remove the drain plug to allow water to flow out.
4. Once drained, replace the plug securely.
5. Allow the unit to air dry completely before storing or refilling.

7. Troubleshooting

Problem	Possible Cause	Solution
No power	Unit unplugged; circuit breaker tripped	Ensure unit is plugged in; reset circuit breaker
No hot/cold water	Heating/cooling switch off; empty water bottle; air lock	Turn on switches; replace water bottle; dispense water until flow is steady
Ice maker not producing ice	Ice making function off; low water level; ambient temperature too high	Ensure ice function is on; replace water bottle; ensure proper ventilation
Water leaking	Water bottle improperly seated; drain plug loose	Re-seat water bottle; tighten drain plug
Unusual noise	Unit not level; compressor cycling; fan obstruction	Ensure unit is level; normal operation; check for obstructions

If problems persist after attempting these solutions, please contact VECYS customer support.

8. Specifications

- **Model Number:** LYCZ629-B
- **Brand:** VECYS
- **Product Dimensions (D x W x H):** 45D x 36.6W x 112H centimetres (17.7D x 14.4W x 44.1H inches)

- **Capacity:** Compatible with 3-5 gallon water bottles
- **Daily Ice Making Capacity:** 22 LBS
- **Ice Production Per Cycle:** 9 pieces
- **Installation Type:** Freestanding
- **Power Source:** Corded Electric
- **Colour:** White
- **Date First Available:** Dec 22 2025

9. Warranty and Customer Support

This VECYS product comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact VECYS customer support through the retailer where the product was purchased or visit the official VECYS website.

No official seller videos were found for embedding in this manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question