

ZWP KY-2020D

ZWP KY-2020D Replacement Remote Control User Manual

For MZEIBO/MORWIN Sound Bar Speaker 2.0 Channels KY-2020D

1. INTRODUCTION

This manual provides instructions for the ZWP KY-2020D Replacement Remote Control. This remote is designed to be a direct replacement for the original remote control of MZEIBO/MORWIN Sound Bar Speaker 2.0 Channels KY-2020D.

The remote control features advanced infrared technology for a stable signal and quick response. It is constructed from durable ABS material for longevity and safety. No programming or complex setup is required for operation.

2. SETUP

2.1 Battery Installation

The ZWP KY-2020D remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Ultra-long standby time

up to 6 months

Requires
Two AAA batteries.

(Batteries are not Included)



Figure 2.1: Battery installation for the ZWP KY-2020D remote control. Ensure correct polarity when inserting AAA batteries.

Note: Batteries are not included with the remote control.

2.2 Initial Use

This replacement remote control is designed for immediate use without any programming or complex setup. Once batteries are installed, it is ready to operate your compatible MZEIBO/MORWIN Sound Bar Speaker 2.0 Channels KY-2020D.



Figure 2.2: The ZWP KY-2020D remote control is ready for use directly after battery installation, requiring no additional setup.

3. OPERATING INSTRUCTIONS

The ZWP KY-2020D remote control provides full functionality for your MZEIBO/MORWIN Sound Bar Speaker. Point the remote control directly towards the sound bar's infrared receiver for optimal performance.

3.1 Button Functions

The remote control features standard buttons for sound bar operation. While specific functions may vary slightly based on your sound bar model, common buttons include:

- **Power Button ():** Turns the sound bar on or off.
- **Volume Up/Down (+ / -):** Adjusts the sound volume.
- **Mute Button ():** Mutes or unmutes the sound.
- **Input/Source Selection:** Cycles through available audio inputs (e.g., Bluetooth, Optical, AUX).
- **Playback Controls (/ / /):** For media playback (Play/Pause, Skip Forward/Backward).
- **Mode Buttons (e.g., MUSIC, MOVIE, NEWS):** Selects different audio modes or equalizers.
- **OPT/AUX/ARC:** Direct selection for specific input sources.



Figure 3.1: Overview of the ZWP KY-2020D remote control buttons.

3.2 Infrared Technology and Range

The remote control utilizes advanced infrared (IR) technology for communication with your sound bar.

This provides a stable and fast response time of approximately 0.2 seconds.

For optimal performance, ensure a clear line of sight between the remote control and the sound bar's IR receiver. The remote supports multi-angle control and can operate effectively up to a distance of 26 feet (approximately 8 meters) without obstruction.

Longer and more stable transmission distance

Multi angle induction



Figure 3.2: The remote control offers multi-angle induction and a transmission distance of up to 26 feet.

4. MAINTENANCE

4.1 Battery Replacement

When the remote control's performance degrades (e.g., reduced range, unresponsive buttons), it is likely time to replace the batteries. Refer to Section 2.1 for battery installation instructions. Always replace both AAA batteries simultaneously with new ones.

The remote control is designed for ultra-long standby time, potentially up to 6 months, depending on usage.

4.2 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's surface or internal components.

5. TROUBLESHOOTING

If you encounter issues with your ZWP KY-2020D remote control, please refer to the following common troubleshooting steps:

- **Remote not responding:**

- Ensure the batteries are correctly installed with the correct polarity.
- Replace old batteries with new AAA batteries.
- Check for any obstructions between the remote control and the sound bar's IR receiver.
- Ensure you are within the effective operating range (up to 26 feet).

- **Reduced operating range:**

- This often indicates low battery power. Replace the batteries.
- Verify there are no strong light sources (like direct sunlight or bright fluorescent lights) interfering with the IR signal.

6. SPECIFICATIONS

Feature	Detail
Model	KY-2020D
Compatibility	MZEIBO/MORWIN Sound Bar Speaker 2.0 Channels KY-2020D
Brand	ZWP
Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Material	High Quality ABS
Color	Black
Special Feature	Ergonomic Design
Item Weight	2.24 ounces (approx. 63.5 grams)
Package Dimensions	7.3 x 2.6 x 1.2 inches (approx. 18.5 x 6.6 x 3 cm)
Max Number of Supported Devices	1 (Soundbar)

Smaller, lighter remote control

Ergonomic design

Product Dimensions

Length: **5.83in**

width: **1.57 in**

height: **0.79 in**



Figure 6.1: Ergonomic design and key dimensions of the ZWP KY-2020D remote control.

7. WARRANTY AND SUPPORT

ZWP provides a 1-year warranty return service for this product. If you have any questions or require assistance with your ZWP KY-2020D Replacement Remote Control, please contact the seller directly through your purchase platform.

Customer inquiries are typically responded to within 12 hours.