

Xgody Gimbal 3

XGODY Gimbal 3 Mini Projector User Manual

Model: Gimbal 3

1. INTRODUCTION

Thank you for purchasing the XGODY Gimbal 3 Mini Projector. This manual provides essential information for setting up, operating, and maintaining your device. Please read it thoroughly before use to ensure optimal performance and safety.

2. SAFETY INFORMATION

- Do not look directly into the projector lens when the lamp is on.
- Ensure proper ventilation around the projector to prevent overheating.
- Keep the projector away from water or other liquids.
- Use only the power adapter supplied with the device.
- Do not attempt to disassemble or repair the projector yourself. Contact qualified service personnel.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- XGODY Gimbal 3 Mini Projector
- Remote Control
- Power Cable
- HD Cable
- User Manual



Image: The XGODY Gimbal 3 Mini Projector shown with its included accessories: user manual, remote control, power cable, and HD cable.

4. PRODUCT OVERVIEW

The XGODY Gimbal 3 is a compact and portable projector designed for versatile use. It features a unique 180-degree rotating stand, allowing for flexible projection angles.



Image: Front-side view of the XGODY Gimbal 3 Mini Projector, highlighting its lens and ventilation grilles.

4.1 Ports and Connections

The projector is equipped with various ports for connecting external devices:

- **HDMI Port:** For connecting laptops, gaming consoles, TV sticks, etc.
- **USB Port:** For connecting USB flash drives, external hard drives, or other USB devices.
- **Power Input:** For connecting the power adapter.

Mini Portable Projector

0.35KG
Weight



Image: Diagram illustrating the various connectivity options of the XGODY Gimbal 3, including USB and HDMI ports, and compatible devices like phones, laptops, and gaming consoles.

5. SETUP

5.1 Placement

Position the projector on a stable, flat surface. The 180-degree rotating stand allows you to adjust the projection angle to ceilings, walls, or floors. The short focal length lens enables clear images even in limited spaces.

180 Degree Adjustable Projector Use only one hand



Image: The XGODY Gimbal 3 Mini Projector demonstrating its 180-degree adjustable projection capability, shown in a serene outdoor setting.



Image: The XGODY Gimbal 3 Mini Projector projecting an image in a bedroom, illustrating its short focus capability for small rooms.

5.2 Power Connection

Connect the power cable to the projector's power input port and then plug the adapter into a power outlet.

5.3 Initial Power On

Press the power button on the projector or the remote control to turn on the device. Follow the on-screen instructions for initial setup, including language selection and network connection.

6. OPERATING INSTRUCTIONS

6.1 Remote Control

Use the included remote control to navigate menus, adjust settings, and control playback. Ensure the remote has batteries installed and is pointed towards the projector.

6.2 Focus Adjustment

The projector features manual focus. Rotate the focus ring near the lens until the projected image is clear and sharp.

6.3 Keystone Correction

The projector supports automatic vertical keystone correction to ensure a rectangular image even when the projector is angled. Manual adjustments may also be available in the settings menu.



Image: A visual representation of the XGODY Gimbal 3's auto keystone correction (vertical) and manual focus features, showing a clear projected image of a dog.

6.4 Connectivity

6.4.1 Wi-Fi 6 Connection

The projector supports dual-band Wi-Fi 6 for faster and more stable wireless connections. Navigate to the network settings to connect to your Wi-Fi network.



Image: A comparison illustrating the improved performance of Dual-Band WiFi 6 on the XGODY Gimbal 3 Mini Projector compared to WiFi 5, showing a football match projected on a screen.

6.4.2 Bluetooth Connection

Connect Bluetooth audio devices like speakers or headphones for an enhanced audio experience. Access Bluetooth settings to pair your devices.

6.4.3 HDMI and USB Connections

Use the HDMI port to connect devices such as laptops, game consoles (PS4/PS5), TV sticks, or set-top boxes. The USB port allows you to play media directly from a USB flash drive.

6.4.4 Screen Mirroring (AirPlay/Miracast)

Wirelessly mirror content from your iPhone/Android phone, tablet, or iPad using AirPlay or Miracast. Ensure both the projector and your device are connected to the same Wi-Fi network.

6.5 Android 11.0 Smart System

The projector runs on Android 11.0, providing access to a wide range of applications. You can download streaming services like YouTube, Prime Video, Netflix, and more directly from the app store.




Image: The XGODY Gimbal 3 Mini Projector displaying its Android TV 11.0 interface, featuring various streaming and social media applications.

6.6 Projection Settings

Adjust the projection size (zoom) from 50% to 100% through the settings menu to fit your screen or wall.

7. MAINTENANCE

7.1 Cleaning

- **Lens:** Use a soft, lint-free cloth specifically designed for optical lenses. Do not use abrasive cleaners.
- **Casing:** Wipe the exterior with a soft, dry cloth. For stubborn marks, use a slightly damp cloth and then dry thoroughly.
- **Ventilation:** Ensure the ventilation openings are clear of dust and debris to prevent overheating.

7.2 Storage

When not in use, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. Its compact size makes it easy to store.



Image: The XGODY Gimbal 3 Mini Projector shown being easily stored in a bag and placed on a shelf, highlighting its portable and compact design.

8. TROUBLESHOOTING

- **No Power:** Check if the power cable is securely connected and the power outlet is functional.
- **No Image:** Ensure the correct input source is selected. Check HDMI/USB cable connections.
- **Blurry Image:** Adjust the manual focus ring. Ensure the projector is within the recommended projection distance.
- **Image Distorted:** The projector has auto vertical keystone correction. If issues persist, check settings for manual keystone adjustments.
- **No Sound:** Check volume settings on both the projector and the connected source device. If using Bluetooth, ensure it's correctly paired.
- **Wi-Fi Connection Issues:** Ensure the Wi-Fi password is correct and the projector is within range of the router. Restart the projector and router.

9. SPECIFICATIONS







Feature	Specification
Brand	Xgody
Model	Gimbal 3
Native Resolution	720P (Supports 1080P)
Brightness	10000 Lumen
Contrast Ratio	10000:1
Operating System	Android 11.0
Wi-Fi	Dual-Band Wi-Fi 6
Bluetooth	Bluetooth 5.0
Keystone Correction	Auto Vertical Correction
Focus	Manual Focus
Projection Size	40-130 inches
Zoom Function	50% - 100%
Ports	HDMI, USB
Item Weight	0.8 kg (1.43 pounds)
Dimensions	17cm (length) x 10cm (diameter) approx.

10. WARRANTY AND SUPPORT

The XGODY Gimbal 3 Mini Projector comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact XGODY customer service through their official website or the retailer where you purchased the product.

Optional protection plans may be available for extended coverage. Please check with your retailer for details.

Related Documents - Gimbal 3

 <p>English</p> <p>XGODY</p> <p>USER MANUAL</p> <p>For more questions, please consult online customer service.</p> <p>Hinweis: Die zweite Hälfte ist auf Deutsch verfügbar</p> <p>Notice Please read this user manual carefully before use.</p>	<p>XGODY X1 Native 1080P Projector User Manual</p> <p>Comprehensive user guide for the XGODY X1 Native 1080P Projector, featuring Android 9.0 TV and Dolby Sound. Learn about setup, operation, features, and troubleshooting for an enhanced home theater experience.</p>
 <p>USER MANUAL</p> <p>Important Safety Notes</p> <p>1. Read this manual carefully before using the projector.</p> <p>2. Do not touch the lens or the lamp cover.</p> <p>3. Do not use the projector in a humid or dusty environment.</p> <p>4. Do not use the projector for long periods of time.</p> <p>5. Do not use the projector for high-contrast images.</p> <p>6. Do not use the projector for high-contrast images.</p> <p>7. Do not use the projector for high-contrast images.</p> <p>8. Do not use the projector for high-contrast images.</p> <p>9. Do not use the projector for high-contrast images.</p> <p>10. Do not use the projector for high-contrast images.</p>	<p>XGODY X1 Projector User Manual: Setup, Operation, and Troubleshooting</p> <p>Comprehensive user manual for the XGODY X1 projector, covering safety guidelines, setup instructions, connectivity options (HDMI, Bluetooth, Wi-Fi, Screen Mirroring), screen adjustments, maintenance, troubleshooting, and warranty information.</p>
 <p>XGODY</p> <p>SMART PROJECTOR</p> <p>Quick Installation Guide</p> <p>Model: Gimbal 5 Pro</p>	<p>XGODY Gimbal 5 Pro Smart Projector Quick Installation Guide</p> <p>This quick installation guide provides essential information for setting up and operating the XGODY Gimbal 5 Pro Smart Projector, including specifications, structure, operation settings, and safety instructions.</p>
 <p>XGODY HY320</p> <p>Portable LCD LED Projector</p> <p>HDTV, 30000h Lamp, Wi-Fi</p>	<p>XGODY HY320 Portable LCD LED Projector - HDTV, 30000h Lamp, Wi-Fi</p> <p>Discover the XGODY HY320, a compact and versatile LCD LED projector with HDTV resolution, 1500:1 contrast, and a 30,000-hour LED lifespan. Features integrated media player, Wi-Fi, Bluetooth, and Android 11.0 for seamless connectivity.</p>
 <p>XGODY</p> <p>SMART PROJECTOR</p> <p>Quick Installation Guide</p> <p>Model: Gimbal 3S</p>	<p>XGODY Gimbal 3S Smart Projector: Quick Installation Guide</p> <p>Comprehensive quick installation guide for the XGODY Gimbal 3S Smart Projector, covering setup, operation, specifications, safety instructions, and connectivity options like HDMI, USB, Miracast, Airplay, and wired projection.</p>
 <p>XGODY</p> <p>FHD AUTO FOCUS SMART PROJECTOR</p> <p>User Guide</p> <p>Please read this user's guide carefully before operating the projector, and save this guide for future use.</p>	<p>XGODY FHD Auto Focus Smart Projector User Guide</p> <p>Comprehensive user guide for the XGODY FHD Auto Focus Smart Projector, detailing setup, safety precautions, features, and operation for an enhanced home entertainment experience.</p>