BIGASUO 101C-digital calendar

BIGASUO 10.1" Digital Calendar Instruction Manual

1. INTRODUCTION

The BIGASUO 10.1" Digital Calendar is a smart touchscreen interactive display designed to simplify family scheduling and organization. This device functions as an electronic organizer for monthly, weekly, and daily agendas, a chore chart, a meal planner, a to-do list, and a digital picture frame. It is intended to be a central hub for managing household activities and displaying cherished memories.

This manual provides detailed instructions for setting up, operating, and maintaining your digital calendar to ensure optimal performance and user experience.

2. SETUP

2.1 Initial Setup

To begin using your BIGASUO Digital Calendar, follow these steps:

1. **Power Connection:** Connect the power adapter to the device and plug it into a wall outlet. The system will start up automatically.

2. **Wi-Fi Connection:** On the device screen, follow the prompts to connect to your home Wi-Fi network. A stable internet connection is required for full functionality and synchronization.

3. **App Download:** Download the "Whale Framely" app on your smartphone or tablet.

   - For Android devices: Google Play Store
   - For iOS devices: Apple App Store

4. **Account Creation & Sync:** Open the "Whale Framely" app, create an account, and follow the in-app instructions to sync your device by scanning the QR code displayed on the calendar or entering a pairing code.

5. **Calendar Integration:** Once synced, you can connect your existing digital calendars (Google Calendar, iCloud, Outlook, Cozi, Yahoo Calendar) through the app or directly on the device. Your events will automatically load and stay updated.

No mounting bracket needed

Instant startup: Just connect to power and the system is ready in seconds.

Image: First-Time Setup Guide illustrating the three main steps: downloading the app, syncing the device, and adding events.

2.2 Placement

The BIGASUO Digital Calendar is designed for desktop use and does not require a mounting bracket. Place it on a stable, flat surface in a central location where it is easily visible to all family members.


Image: Rear view of the digital calendar demonstrating the power connection, emphasizing no mounting bracket is needed.

3. OPERATING INSTRUCTIONS

3.1 Calendar Functionality

The digital calendar provides a clear overview of your schedule. Events from synced calendars are displayed, and you can add new events directly on the device or through the "Whale Framely" app. Tasks can be color-coded and assigned to specific family members for visual organization.

Image: The digital calendar screen showing a detailed schedule with various calendar app icons at the bottom, indicating multi-platform synchronization.

3.2 Chore Chart & Task Management

Utilize the interactive chore chart to assign and track responsibilities. This feature helps in building routines and healthy habits for children. Tasks can be marked as complete, and progress can be monitored.


Image: The digital calendar showing a task list with different users and their assigned chores, promoting good habits.

The device also supports a rewards system to acknowledge completed tasks and encourage participation.

Image: The digital calendar displaying a rewards screen, encouraging positive reinforcement for task completion.

3.3 Meal Planner

Plan and display your weekly meals directly on the calendar. This feature helps streamline meal preparation and informs family members about upcoming menus.


Image: The digital calendar showing a structured meal plan for the week, helping to organize daily meals.

3.4 To-Do Lists

Create and manage various to-do lists, such as grocery lists or errand reminders. These lists can be updated in real-time and shared among family members.

Image: The digital calendar showing a detailed to-do list, useful for managing errands and groceries.

3.5 Photo Frame & Live Screensaver

Transform your digital calendar into a dynamic photo frame. Share photos and videos directly from your phone using the "Whale Framely" app. The device can display a continuous slideshow of your cherished memories.

Image: The digital calendar showcasing a family photo, highlighting its function as a digital photo frame.

3.6 Additional Features

- **Weather System:** The calendar displays current weather conditions and forecasts, keeping you informed.

To-do List
Never Forget a Errand or Grocery.

Image: The digital calendar showing a detailed weather forecast, including temperature and daily conditions.

- **Switchable Alarm:** Set alarms for important reminders, such as medication times or appointments, to ensure no moment is forgotten.

Photo Screensaver
More Than Time, It's Your Story.

Image: The digital calendar showing an alarm pop-up for a reminder, such as medicine time.

- **Sleep Mode:** Configure sleep and wake times based on your family's schedule to optimize power usage and display comfort.

Weather System
Always Ready For Whatever Comes.

Image: The digital calendar showing settings for sleep/wake times, allowing customization based on user preferences.

4. MAINTENANCE

4.1 Cleaning

To clean the screen and exterior of your digital calendar, use a soft, dry, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or aerosol sprays, as these can damage the screen and finish.

4.2 Software Updates

The device is designed to receive automatic software updates, including adjustments for daylight saving time. Ensure your device remains connected to Wi-Fi to receive these updates, which provide performance improvements and new features.

5. TROUBLESHOOTING

If you encounter issues with your BIGASUO Digital Calendar, refer to the following common solutions:

- **No Power/Display:** Ensure the power adapter is securely connected to both the device and a working electrical outlet. Try a different outlet if necessary.

- **Wi-Fi Connectivity Issues:** Check your router and internet connection. Restarting your router and the digital calendar may resolve the issue. Ensure the Wi-Fi password entered is correct.

- **Calendar Sync Problems:** Verify that the "Whale Framely" app is correctly linked to your device and that your external calendars (Google, iCloud, etc.) are properly connected within the app. Ensure the device has a stable internet connection. If issues persist, try unlinking and relinking your calendars in the app.

- **Unresponsive Touchscreen:** Restart the device. If the issue continues, ensure the screen is clean and free of debris.

- **Sound Not Working:** Check the volume settings on the device. Some features may not have audible alerts or sounds. Refer to the app settings for specific sound configurations.

- **Slow Performance:** After initial setup or significant data synchronization, the device may take some time to process. Avoid rapid operations and allow the system sufficient time. Ensure your Wi-Fi connection is strong.

For further assistance, consult the "Whale Framely" app's help section or contact customer support.

6. SPECIFICATIONS

Model Number	101C-digital calendar
Brand	BIGASUO
Screen Size	10.1 inches
Color	White
Material	Plastic
Product Dimensions	30.73 x 30.73 x 25.65 cm
Product Weight	1.33 kg
Connectivity	Wi-Fi enabled

7. Warranty and Support

7.1 Warranty Information

Specific warranty details for your BIGASUO Digital Calendar may vary by region and retailer. Please refer to the documentation included with your purchase or contact the retailer for precise warranty terms and conditions.

7.2 Customer Support

For technical support, troubleshooting assistance, or inquiries regarding your product, please contact BIGASUO customer service. Contact information can typically be found on the manufacturer's official website or within the "Whale Framely" application.