

MEION M-001

MEION Coffee Mug Warmer M-001 Instruction Manual

1. INTRODUCTION

Thank you for choosing the MEION Coffee Mug Warmer M-001. This device is designed to keep your beverages warm at your preferred temperature, enhancing your daily experience. It features multiple temperature settings, a customizable timer, and a smart gravity sensor for safe and convenient operation. Please read this manual thoroughly before use to ensure proper function and safety.



Image: The MEION Coffee Mug Warmer in use, maintaining the temperature of a beverage.

2. SAFETY INSTRUCTIONS

- **Read all instructions:** Before operating the device, carefully read and understand all instructions.
- **Hot Surface:** The heating plate becomes hot during operation. Avoid direct contact with the hot surface to prevent burns.
- **Placement:** Always place the mug warmer on a flat, stable, and heat-resistant surface.
- **Compatible Cups:** Use only flat-bottomed cups made of ceramic, glass, or other heat-resistant materials. Avoid plastic cups, paper cups, or insulated mugs that may not transfer heat effectively or could be damaged.
- **Liquid Spills:** The tempered glass panel is waterproof, but avoid excessive liquid spills. If spills occur, unplug the

device and wipe it dry immediately.

- **Children and Pets:** Keep the device out of reach of children and pets.
- **Unplug When Not in Use:** Always unplug the mug warmer from the power outlet when not in use or before cleaning.
- **Ventilation:** Ensure proper ventilation around the device. Do not cover the mug warmer during operation.
- **Damage:** Do not operate the device if the cord or plug is damaged, or if the device malfunctions or has been dropped. Contact customer support for assistance.

3. PACKAGE CONTENTS

- MEION Coffee Mug Warmer (Model: M-001)
- Instruction Manual

4. SPECIFICATIONS

Model Number	M-001
Brand	MEION
Color	Black
Material	Plastic, Tempered Glass
Wattage	50 watts
Voltage	110 Volts
Maximum Temperature	185°F (85°C)
Item Weight	15.8 ounces (approx. 448g)
Package Dimensions	9.72 x 6.38 x 1.93 inches

5. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the MEION Coffee Mug Warmer on a flat, stable, and dry surface, away from flammable materials.
3. **Power Connection:** Plug the power cord into a standard 110V AC power outlet.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off and Gravity Sensor

- The mug warmer features a **Smart Gravity Sensor**. It will only activate heating when a cup with sufficient weight is placed on the heating panel.
- To turn on, simply place your cup on the heating panel. The device will automatically detect the cup and begin heating.
- To turn off, lift your cup from the heating panel. The device will automatically shut off after 5 minutes of inactivity, preventing overheating.

Features Smart Gravity Sensor



Auto-off 5 minutes after mug removal
Effectively prevents overheating



Image: Illustration of the Smart Gravity Sensor, showing automatic shut-off after mug removal.

6.2 Temperature Settings

The MEION Coffee Mug Warmer offers 4 customizable heat settings:

- 131°F (55°C)
- 145°F (63°C)
- 167°F (75°C)
- 185°F (85°C)

To adjust the temperature, press the power/temperature button (usually indicated by a power symbol or a thermometer icon) on the device. Each press will cycle through the available temperature settings, which will be displayed on the LED screen.

4 Temp | Settings



At 131°F, the temperature maxes out at that setting. For higher heat, turn it up.



Image: The mug warmer showing its four distinct temperature settings.

6.3 Customizable Timer

The mug warmer includes a 1-12 hour timer with an auto shut-off feature. By default, the device is set to automatically turn off after 8 hours.

- To set the timer, press the timer button (usually indicated by a clock icon). Each press will adjust the duration before auto shut-off.
- The selected timer duration will be displayed on the LED screen.

1-12 HOUR Customizable Timer

Auto-shutoff after 8 hours by default



Image: The mug warmer displaying its customizable timer feature.

6.4 General Usage Tips

- For optimal warming, use flat-bottomed mugs.
- Placing a lid on your mug can help drinks heat up faster and maintain temperature more efficiently.
- The 4.7-inch heating panel is designed to fit most standard flat-bottom cups.

7. MAINTENANCE AND CLEANING

The MEION Coffee Mug Warmer is designed for easy maintenance.

- **Unplug First:** Always ensure the device is unplugged and completely cooled down before cleaning.
- **Wipe Clean:** Use a soft, damp cloth to wipe the surface of the heating panel and the body of the warmer.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the tempered glass surface.
- **Do Not Submerge:** Never immerse the device in water or any other liquid.



Image: The tempered glass panel of the mug warmer, highlighting its easy-to-clean surface.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not heating	Not plugged in; No cup on sensor; Cup is too light or not flat-bottomed.	Ensure power cord is securely plugged in. Place a compatible cup with liquid on the heating panel. Use a flat-bottomed cup with sufficient weight.
Beverage not warm enough	Low temperature setting; Cup material/shape not ideal; No lid.	Increase the temperature setting. Use a flat-bottomed ceramic or glass mug. Place a lid on the mug to retain heat.
Device shuts off unexpectedly	Timer expired; Cup removed from sensor.	Check the timer setting and adjust if needed. Ensure the cup remains on the heating panel.

9. ADDITIONAL USES

9.1 Candle Warmer

The MEION Coffee Mug Warmer can also be used as a candle warmer. Place your jar candle directly on the heating plate to melt the wax and release fragrance without an open flame, creating a cozy atmosphere.

Candle warmer

Enjoy a cozy sleeping atmosphere



Image: The mug warmer functioning as a candle warmer, providing a warm glow.

9.2 Official Product Video

Your browser does not support the video tag.

Video: An official product video demonstrating the MEION Coffee Mug Warmer's features and usage.

10. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your purchase or visit the official MEION website. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question