

[Manuals.plus](#) /

> [qimedo](#) /

> qimedo 6000mAh Battery Cordless Electric Mop M1 Pro Instruction Manual

qimedo M1 Pro

qimedo 6000mAh Battery Cordless Electric Mop M1 Pro Instruction Manual

Model: M1 Pro

INTRODUCTION

Thank you for choosing the qimedo 6000mAh Battery Cordless Electric Mop M1 Pro. This 2-in-1 electric mop and scrubber is designed to make your floor cleaning faster, easier, and more efficient. Featuring a powerful 800 RPM motor, a smart display, and a long-lasting battery, it provides a versatile cleaning solution for various surfaces in your home. Please read this manual carefully before using the product to ensure safe and optimal operation.

WHAT'S IN THE BOX

Your qimedo M1 Pro package includes the following items:

- Cordless Electric Mop (main unit) x 1
- 21V Battery x 2
- Charger x 1
- Large Brush Head x 2 (6.5 inch)
- Large Mop Pad x 2 (6 inch)
- Large Hair Mop Pad x 2 (6 inch)
- Measuring Cup x 1
- Hook (for wall mounting) x 1
- User Manual x 1
- Gloves x 1 pair
- Brush Head Bag x 1



Image: All accessories included with the qimedo M1 Pro electric mop, laid out on a surface.

SETUP

Follow these steps to assemble your qimedo M1 Pro electric mop:

1. **Install the Pad/Brush Head:** Select the desired cleaning pad (mop pad or brush head) and attach it to the bottom of the mop head. Ensure it is securely fastened.
2. **Align and Tighten the Extension Handle:** Connect the extension handle sections by aligning the threads and twisting clockwise until secure.
3. **Align and Install the Battery:** Insert a charged 21V battery into the designated slot on the handle until it clicks into place.
4. **Fill the Water Tank:** Open the water tank cap on the mop head. Use the provided measuring cup to pour up to 300ml of

clean water into the tank. You may add a small amount of floor cleaner if desired. Close the cap securely.

5. **Charge Batteries:** Before first use, fully charge both 21V batteries using the provided charger. A full charge takes approximately 2.5 hours.



Image: Step-by-step visual guide for assembling the qimedo M1 Pro electric mop, showing pad installation, handle assembly, water filling, and battery insertion.

OPERATING INSTRUCTIONS

The qimedo M1 Pro is designed for effortless cleaning. Here's how to use it:

1. **Power On:** Press the power button on the handle to turn on the electric mop. The smart display will illuminate.
2. **Select Cleaning Mode:** The smart display shows the remaining battery percentage on the left and different power modes (400 RPM, 600 RPM, 800 RPM) on the right. Single press the power button to cycle through the modes (Low, Mid, Max). The higher the speed, the stronger the cleaning effect.
3. **Adjust Handle Angle:** The telescopic pole extends up to 50 inches, and the brush head can be adjusted 90 degrees, allowing you to clean hard-to-reach areas without bending or stretching.
4. **Activate Water Spray:** To spray water, press the foot pedal located on the mop head. Press again to stop the spray. Avoid long, continuous sprays to prevent uneven distribution or malfunctioning.
5. **Utilize LED Light:** The integrated LED light on the mop head helps illuminate dark corners and hidden dirt, ensuring thorough cleaning.
6. **Self-Propelled Operation:** The mop is self-propelled, making it easy to maneuver across various floor types. For stubborn stains, apply gentle downward pressure.



Image: The mop head with its LED lights activated, shining on the floor to reveal dirt.



Image: The flexible mop head swiveling to clean under furniture, demonstrating its maneuverability.

Video: A demonstration of how to use the qimedo M1 electric mop, including assembly and operation.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your electric mop:

- **Cleaning Pads/Brush Heads:** The cleaning pads and brush heads are removable and washable. After use, detach them and rinse thoroughly or machine wash as needed.
- **Water Tank:** The water tank is removable for easy cleaning. Regularly empty and rinse the tank to prevent residue buildup.
- **Battery Care:** The smart display detects battery health for better protection. When the power is below 25%, recharge the battery. Always use the provided charger.
- **Storage:** Use the included hook to mount the mop on a wall for convenient storage. The telescopic handle can be retracted to save space.




Image: Detachable cleaning pads being rinsed, highlighting their reusability and ease of cleaning.



Image: The electric mop neatly stored on a wall-mounted hook, demonstrating space-saving storage.

TROUBLESHOOTING

- **Mop stops working when pressed too hard:** If the mop stops due to excessive pressure, separate the battery from the

electric mop, then reinstall the battery and turn the mop on again. This is a battery protection feature.

- **Water tank clogs:** Do not put sand or debris into the water tank to avoid clogs in the spray mechanism. Use clean water and appropriate floor cleaning solutions only.
- **Uneven spraying or malfunctioning:** Ensure the water tank is properly seated and the powerful water pump is not obstructed. If issues persist, refer to the support section.

SPECIFICATIONS

Brand	qimedo
Model Number	YD-QJS1804SS-PRO1
Battery Capacity	6000mAh (2 Lithium Ion batteries included)
Max RPM	800 RPM (3 modes: 400/600/800 RPM)
Charging Time	2.5 hours (for full charge)
Continuous Working Time	Up to 420 minutes (low speed mode, with two batteries)
Water Tank Capacity	300ml (removable)
Handle Length	Up to 50 inches (telescopic)
Item Weight	4.55 pounds
Product Dimensions	1 x 1 x 1 inches
Handle Material	Metal, Plastic
Head Material	Cotton
Assembly Required	Yes

SUPPORT

If you encounter any problems with the product, your order, or logistics, please contact the qimedo customer support team for assistance. You can typically find contact information on the product packaging or the retailer's website where you made your purchase.