

[Manuals.plus](#) /

> [BoxWave](#) /

> BoxWave ClearTouch ImpactShield Screen Protector for TOGUARD WR730P - User Manual

## BoxWave ClearTouch ImpactShield

# BoxWave ClearTouch ImpactShield Screen Protector for TOGUARD WR730P - User Manual

## INTRODUCTION

This manual provides detailed instructions for the installation, use, and maintenance of your BoxWave ClearTouch ImpactShield Screen Protector, specifically designed for the TOGUARD WR730P. The ClearTouch ImpactShield offers advanced protection with its 9H hardness rating, shock absorption, and crystal-clear visibility, ensuring your device's screen remains protected and functional.



Image: BoxWave ClearTouch ImpactShield branding and key features like color brilliance, clarity, precision, and reusability.

## SETUP: INSTALLATION GUIDE

Follow these steps carefully to ensure a bubble-free and perfectly aligned installation of your ClearTouch ImpactShield screen protector.

1. **Prepare Your Workspace:** Choose a clean, dust-free environment. Wash your hands thoroughly to avoid transferring oils or dirt to the screen or protector.

2. **Clean the Device Screen:** Use a microfiber cloth to gently wipe the TOGUARD WR730P screen, removing any dust, fingerprints, or smudges. For stubborn marks, a screen cleaning solution can be used sparingly. Ensure the screen is completely dry before proceeding.
3. **Align the Protector:** Carefully peel back a small portion of the protective film (usually labeled "Step 1" or similar) from one end of the ClearTouch ImpactShield. Align the exposed edge of the screen protector with the corresponding edge of your device's screen. Pay close attention to cutouts for cameras or sensors.
4. **Apply the Protector:** Once aligned, slowly and steadily lower the rest of the screen protector onto the device's screen, peeling off the remaining protective film as you go. Use a squeegee (if provided) or a credit card wrapped in a microfiber cloth to gently press down and smooth out the protector, working from the aligned edge outwards. This helps prevent air bubbles.
5. **Remove Air Bubbles:** If air bubbles appear, gently push them towards the nearest edge using the squeegee or cloth. For persistent bubbles, you may carefully lift the nearest edge of the protector slightly and re-apply, smoothing it down again.
6. **Final Touches:** Once the protector is fully applied and free of bubbles, gently peel off the top protective layer (usually labeled "Step 2" or similar). Give the screen a final wipe with the microfiber cloth.



Image: Diagram illustrating the multi-layered structure of a screen protector, showing how it adheres to the device screen.

## OPERATING: KEY FEATURES AND BENEFITS

---

The BoxWave ClearTouch ImpactShield is engineered to provide superior protection and maintain the optimal performance of your TOGUARD WR730P screen.

- **9H Hardness Rating:** This screen protector boasts a 9H hardness rating, offering robust resistance against scratches, scuffs, and impacts from everyday use. It provides a strong barrier against sharp objects like keys and coins.

**BOXWAVE**

# 9H Ultimate Protection

Protect against chipping, spills, and drops




Image: Illustration demonstrating the 9H ultimate protection against impacts from keys and liquid spills.

- **Shock Absorption:** Designed with a thin TPU layer, the ImpactShield absorbs and disperses shock from accidental drops and impacts, significantly reducing the risk of screen damage.

**BOXWAVE**

# Shatterproof Protection



Image: Visual representation of shatterproof protection, showing a screen protector preventing a screen from cracking under impact.

- **Flexible Material:** Unlike brittle glass protectors, the ClearTouch ImpactShield is made from a strong yet flexible material that resists chipping and cracking, ensuring long-lasting protection.

**BOXWAVE**

# Flexible Material

ClearTouch protects your device without chipping and cracking.



\*Image for reference only. The actual product is designed to fit the screen of your device.

Image: A flexible screen protector being applied to a smartphone, highlighting its pliable nature.

- **Crystal Clear Visibility:** Enjoy 99% transparency with the ClearTouch ImpactShield. It maintains the original vibrancy, clarity, and touch sensitivity of your device's display without distortion or loss of resolution.

**BOXWAVE**

# Crystal Clarity

Keep your screen unobscured as ClearTouch maintains the vibrancy and clarity of your device's display.



Image: A diamond next to a tablet screen, symbolizing the crystal clarity and brilliance maintained by the screen protector.

- **Precision Fit:** Each ClearTouch ImpactShield is precisely cut to fit the TOGUARD WR730P, ensuring full accessibility to all ports, buttons, and features without interference.

# Designed to Fit Your Device



Precisely Manufactured




Image: A caliper measuring a blueprint of a device, illustrating the precise manufacturing for a perfect fit.

## MAINTENANCE

To keep your ClearTouch ImpactShield in optimal condition and ensure maximum clarity, follow these simple maintenance tips:

- **Regular Cleaning:** Gently wipe the screen protector with a clean, soft microfiber cloth to remove dust, fingerprints, and smudges.
- **Stubborn Marks:** For more persistent marks, lightly dampen a microfiber cloth with water or a screen-safe cleaning solution. Avoid harsh chemicals, abrasive materials, or excessive moisture, as these can damage the protector or the device.
- **Avoid Sharp Objects:** While the protector offers 9H hardness, prolonged or extreme contact with very sharp objects can still cause damage.

## TROUBLESHOOTING

Here are solutions to common issues you might encounter during or after installation:

- **Air Bubbles:**

- **Small Bubbles:** Most small bubbles will disappear naturally within 24-48 hours.
- **Large Bubbles:** Use a squeegee or a credit card wrapped in a microfiber cloth to gently push large bubbles towards the nearest edge.
- **Persistent Bubbles:** If a bubble is caused by a dust particle, carefully lift the nearest corner of the protector with a piece of tape, use another piece of tape to dab the dust particle off the screen or protector, then re-apply.

- **Dust Under Protector:** This is usually the cause of persistent bubbles. Follow the "Persistent Bubbles" solution above. Ensure your installation environment is as dust-free as possible.

- **Misalignment:** If the protector is significantly misaligned, it may be carefully peeled off and re-applied. The ClearTouch ImpactShield is designed for reusability and installation forgiveness. However, repeated re-application can introduce dust.

- **Edges Not Sticking:** Ensure the screen is thoroughly clean and dry, especially along the edges. Press firmly along the edges with a squeegee or cloth. If the issue persists, the protector might have been damaged during initial application or the screen itself might have a slight curve not fully compatible with flat protectors.

## SPECIFICATIONS

Feature	Detail
Brand	BoxWave
Model	ClearTouch ImpactShield (2-Pack)
Compatibility	TOGUARD WR730P
Material	Polyethylene Terephthalate (PET)
Hardness Rating	9H
Screen Surface	Glossy
Transparency	99%
Item Weight	1.6 ounces

## WARRANTY AND SUPPORT

BoxWave Corporation stands behind the quality of its products. For any questions, concerns, or support regarding your ClearTouch ImpactShield Screen Protector, please contact BoxWave customer service. While specific warranty details are not provided in this manual, please refer to the product packaging or the official BoxWave website for the most current warranty information and support options.

**Manufacturer:** BoxWave

**Seller:** BoxWave Corporation

**Website:** [www.boxwave.com](http://www.boxwave.com) (Note: This is a placeholder link, please verify the official support website)



