

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [SYNOSHI](#) /

› [Synoshi Pro Extension Handle User Manual for Electric Rotary Brush](#)

SYNOSHI Synoshi Pro

Synoshi Pro Extension Handle User Manual

Model: Synoshi Pro | Brand: SYNOSHI

INTRODUCTION

The Synoshi Pro Extension Handle is designed to enhance the reach and versatility of your Synoshi electric rotary brush. Crafted from durable, lightweight aluminum, this adjustable handle allows you to clean high, low, and hard-to-reach surfaces with ease, reducing strain and improving cleaning efficiency. Its telescopic design and secure locking mechanism ensure stable operation for various cleaning tasks.

SAFETY INSTRUCTIONS

- Always ensure the extension handle is securely attached to your Synoshi electric rotary brush before use.
- Do not attempt to force the handle beyond its intended extension limits.
- Keep hands and loose clothing away from moving parts of the electric brush during operation.
- Store the handle in a dry place away from extreme temperatures.
- This product is designed for use with the Synoshi electric rotary brush. Do not attempt to attach it to incompatible devices.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Synoshi Pro Extension Handle



Image: The Synoshi Pro Extension Handle, as included in the package.

SETUP INSTRUCTIONS

1. **Prepare the Electric Rotary Brush:** Ensure your Synoshi electric rotary brush is turned off and disconnected from any power source.
2. **Attach the Extension Handle:** Align the connection point of the extension handle with the base of your Synoshi electric rotary brush. Push firmly until you hear a click, indicating a secure attachment.
3. **Verify Connection:** Gently pull on the handle to ensure it is firmly locked in place and will not detach during use.

Le manche télescopique est-il confortable à utiliser avec tous les accessoires Synoshi ?

Le manche télescopique fonctionne bien avec la plupart des accessoires Synoshi, en particulier les brosses rondes, coniques et en acier. Concernant la Gomme Magique, nous recommandons de l'utiliser sans le manche pour un contrôle plus précis, car elle requiert plus de délicatesse pour des résultats optimaux.

Quel poids le manche télescopique peut-il supporter ?

Fabriqué en aluminium durable, le manche télescopique est conçu pour supporter la pression nécessaire à un nettoyage efficace, même lorsqu'il est entièrement déployé. Il assure la stabilité tout en exerçant une pression sur les taches tenaces.

Puis-je ajuster la longueur pour différentes tâches de nettoyage ?

Absolument ! La conception télescopique permet d'ajuster la longueur du manche jusqu'à 715 mm (28,15 pouces), ce qui le rend idéal pour nettoyer les hauts plafonds et les espaces sous les meubles.

FAQS

Image: A hand demonstrating the instant and reliable attachment of the extension handle to the Synoshi electric rotary brush.

OPERATING INSTRUCTIONS

Adjusting Length

The Synoshi Pro Extension Handle features a telescopic design for adjustable length. To extend or retract the handle:

1. Locate the locking mechanism on the handle.
2. Twist or press the locking mechanism to release the telescopic sections.
3. Extend or retract the handle to your desired length (up to 75 cm / 29.5 inches).
4. Securely engage the locking mechanism to fix the handle at the chosen length. Ensure it is tight to prevent slippage during use.



Image: The Synoshi Pro Extension Handle shown at various lengths, illustrating its adjustable telescopic design.

Adjusting Cleaning Angles

The extension handle allows for three adjustable cleaning angles to provide optimal comfort and access for different surfaces:

- **0-degree angle:** Ideal for flat surfaces and direct scrubbing.
- **36-degree angle:** Suitable for corners, edges, and slightly angled surfaces.
- **72-degree angle:** Best for reaching high corners, baseboards, or cleaning under furniture.

To adjust the angle, locate the pivot joint on the handle and press the release button or mechanism. Adjust to the desired angle and ensure it locks securely into place before operating the electric brush.

Trois angles réglables

Pour une utilisation confortable en toutes situations



Image: A diagram illustrating the three adjustable angles (0°, 36°, 72°) of the Synoshi Pro Extension Handle for versatile cleaning.



Image: The Synoshi Pro Extension Handle being used to clean various areas such as floor corners, windows, high corners, and shower cabins.

MAINTENANCE

To ensure the longevity and optimal performance of your Synoshi Pro Extension Handle, follow these maintenance guidelines:

- **Cleaning:** After each use, wipe down the handle with a damp cloth to remove any dirt or cleaning solution residue. The handle features an IPX5 waterproof design, allowing for rinsing under a tap if necessary, but avoid submerging the entire unit.
- **Drying:** Ensure the handle is completely dry before storing.
- **Storage:** Store the handle in a clean, dry place, preferably in its retracted position to protect the telescopic mechanism.
- **Inspection:** Periodically check the locking mechanisms and connection points for any signs of wear or damage. Do not use if damaged.



Image: Illustration of the Synoshi Pro's IPX5 waterproof design, indicating it is resistant to water splashes.

TROUBLESHOOTING

If you encounter issues with your Synoshi Pro Extension Handle, refer to the following common solutions:

- **Handle feels loose or wobbly:** Ensure the locking mechanism for both the length adjustment and the angle adjustment is fully engaged. Re-check the connection to the electric rotary brush to confirm it is securely clicked into place.
- **Difficulty extending/retracting:** Check for any debris or obstruction in the telescopic sections. Clean the handle thoroughly and try again. Do not force the mechanism.
- **Handle does not attach securely:** Verify that the connection point on both the handle and the electric brush is clean and free from damage. Ensure you are using the correct Synoshi electric rotary brush model.

SPECIFICATIONS

Brand	SYNOSHI
Model Number	Synoshi Pro
Color	Gray

Product Dimensions (L x W x H)	2.79 x 2.79 x 74.68 cm (fully extended)
Item Weight	159 g
Material	Acrylonitrile Butadiene Styrene (ABS), Aluminum
Special Features	Extendable, Lightweight, Grip Handle, Portable, Break-resistant
Included Components	Extension Handle
Surface Recommendation	Walls, ceilings, tiles, baseboards, bathtubs, showers, windows, vehicles
Country of Origin	China

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your main Synoshi electric rotary brush or visit the official SYNOSHI website. Keep your purchase receipt as proof of purchase for any warranty claims.