

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Greesum](#) /

› [Greesum Smart Self-Cleaning Litter Box Instruction Manual \(Model GS-0413-2-shua-CL\)](#)

Greesum GS-0413-2-shua-CL

Greesum Smart Self-Cleaning Litter Box Instruction Manual

Model: GS-0413-2-shua-CL

PRODUCT OVERVIEW

The Greesum Smart Self-Cleaning Litter Box is designed to provide a convenient and hygienic solution for cat owners, especially those with multiple cats. It features advanced smart sensors, automatic cleaning cycles, and app control for remote management. The open-top design aims to ease cat adaptation, while its odor elimination system helps maintain a fresh home environment.



Image: Front view of the Greesum Smart Self-Cleaning Litter Box, showcasing its white and blue spherical design.

SETUP INSTRUCTIONS

- 1. Unboxing:** Carefully remove all components from the packaging. Ensure all parts listed in the packing list are present.
- 2. Placement:** Place the litter box on a flat, stable, and level surface. This is crucial for the proper functioning of the weight sensors and automatic leveling system.
- 3. Power Connection:** Connect the power adapter to the litter box and plug it into a standard electrical outlet.
- 4. Install Trash Bag:** Open the waste collection drawer located at the bottom. Line it with a garbage bag, ensuring it is securely fitted to prevent leaks. Close the drawer.
- 5. Add Litter:** Pour clumping cat litter into the main compartment. Ensure the litter level is between the MIN and MAX lines indicated inside the drum. The device is designed to work with clumping litter.
- 6. App Connection (Optional):** Download the exclusive Greesum app (compatible with 2.4GHz WiFi) from your smartphone's app store. Follow the in-app instructions to connect your device for remote control and monitoring.

OPERATING INSTRUCTIONS

The Greesum Smart Self-Cleaning Litter Box offers both automatic and manual operation modes, along with smart safety features.

- **Automatic Cleaning:** In automatic mode, the litter box detects when your cat enters and exits. After a set delay (adjustable via app), it initiates a cleaning cycle. This delay allows time for litter to clump effectively.
- **Manual Cleaning:** Press the manual cleaning button on the control panel or use the app to initiate a cleaning cycle at any time.
- **Deodorizing Cycle:** The device automatically performs a deodorizing cycle after each cleaning cycle to neutralize odors. This can also be manually activated.
- **App Control:** Use the dedicated app to initiate one-touch cleaning, set scheduled cycles, monitor cat usage statistics (weight, excretion time), and adjust various settings like clumping time and cleaning intervals.
- **Safety Features:** Equipped with advanced infrared and gravity sensors, the cleaning process instantly pauses if a cat approaches or enters the litter box, resuming only after the cat has left.

MAINTENANCE

- **Waste Bag Replacement:** Regularly check the waste collection drawer. When full, unhook the drawstring of the bag, tie it securely, and dispose of it. Replace with a new garbage bag, ensuring it is properly secured.
- **Cleaning the Drum:** The main barrel (drum) is detachable for thorough cleaning. Simply lift it out, empty any remaining litter, and rinse the compartment with water. Ensure the base unit remains dry. Allow the drum to dry completely before reassembling to prevent clumping issues.
- **Base Cleaning:** Wipe the base unit with a damp cloth as needed. Avoid direct water exposure to electronic components.
- **Litter Mat:** If using a litter mat, regularly clean it to prevent tracking.

TROUBLESHOOTING

- **Litter Spillage/Leakage:** Ensure the waste bag is installed correctly and tightly secured around the designated hooks. Check for any holes in the bag.
- **App Connectivity Issues:** Verify that your home WiFi network is 2.4GHz. Ensure the litter box is within range of your router. Restart both the litter box and your router if issues persist.
- **Cleaning Cycle Malfunction:** Check that the main barrel is correctly seated and aligned with the base. Ensure no obstructions are preventing rotation. The safety sensors will pause the cycle if a cat is detected.
- **Odor Persistence:** Ensure waste bags are changed regularly. The deodorizing cycle runs automatically, but frequent waste removal is key to odor control.

SPECIFICATIONS

Brand	Greesum
Model Name	Automatic Self-Cleaning Litter Box for Cats - Closed Design
Item Model Number	GS-0413-2-shua-CL
Product Dimensions	21.7"L x 21.7"W x 20"H
Item Weight	19.62 Pounds
Material	Plastic
Color	White
Target Audience	Cats (2.2–28 lbs)
Included Components	Garbage Bag, litter box, mat

WARRANTY AND SUPPORT

For warranty information, technical support, or any product-related inquiries, please refer to the contact information provided in your product packaging or visit the official Greesum website. Keep your purchase receipt for warranty claims.