Livatro LVCUCM002

Livatro 1700W Carpet and Upholstery Cleaner (Model LVCUCM002) User Manual

Brand: Livatro | Model: LVCUCM002

Introduction

The Livatro 1700W Carpet and Upholstery Cleaner is designed for deep cleaning and sanitizing various fabric surfaces. Featuring powerful steam, strong suction, and a triple-action cleaning system, it effectively removes stubborn stains and dirt from carpets, sofas, car interiors, and more. This manual provides essential information for safe and efficient operation of your appliance.

Important Safety Instructions

Always read and understand all safety warnings and instructions before using the appliance. Keep out of reach of children. Do not immerse the appliance in water. Use only as directed. Ensure the power supply matches the appliance's requirements. Unplug the appliance when not in use or before cleaning.

Package Contents

Verify that all items are present in the package:

- Main Unit
- Standard Spray-Extraction Nozzle
- Crevice Nozzle
- Angled Brush
- Self-Cleaning Brush
- Steam Adapter (for sofas)
- Power Cable
- Flexible Hose

Product Overview

The Livatro cleaner features a compact design with two separate tanks for clean and dirty water, a control panel for various cleaning modes, and a flexible hose with interchangeable nozzles for versatile cleaning tasks.



Image: Livatro cleaner main unit and accessories.

Setup

1. **Fill Clean Water Tank:** Unscrew the cap of the clean water tank. Fill with clean water. For deep cleaning, add detergent solution (recommended 1:30 ratio with water). Securely close the cap.



Image: Filling the clean water tank.



Image: Mixing detergent for deep cleaning.

2. **Attach Hose and Nozzle:** Connect the flexible hose to the main unit. Select the appropriate cleaning nozzle for your task and attach it to the end of the hose.

3. **Power Connection:** Plug the power cable into a suitable electrical outlet.

Operating Instructions

1. **Power On:** Press the power button on the control panel to turn on the appliance.
2. **Select Cleaning Mode:** Press the 'Mode' button to cycle through cleaning options: Cold Water, Hot Water (60°C), or Steam (100°C). The appliance heats up quickly (60°C in 15 seconds, 100°C in 30 seconds).



Image: Control panel for mode selection.

3. **Select Power Level:** Choose between Standard and Turbo suction power levels using the corresponding button.
4. **Cleaning Process:** Hold the selected nozzle firmly against the surface to be cleaned. Press the trigger to spray water/steam and simultaneously move the nozzle slowly over the stained area to brush and vacuum the dirt. For stubborn stains, repeat the process.



Image: Steam penetration for deep cleaning.



Image: Powerful suction removing stains from carpet.

5. **Dirty Water Tank Full Alert:** When the dirty water tank reaches its maximum level, the suction power will automatically reduce to alert you. Empty the dirty water tank immediately to prevent overflow.



Image: Dual water tanks with dirty water level indicator.

Maintenance

1. **Empty and Clean Dirty Water Tank:** Remove the dirty water tank and empty its contents. Rinse thoroughly with clean water.
2. **Self-Cleaning Function:** Utilize the one-touch self-cleaning function to flush residues from the internal conduits, preventing odors and blockages.



Image: Self-cleaning hose in action.

3. **Clean Nozzles and Brushes:** Detach all nozzles and brushes and rinse them under running water. Ensure no debris remains.
4. **Storage:** Store the appliance and accessories in a dry, cool place.

Troubleshooting

- **No Power:** Check if the power cable is securely plugged in. Ensure the power outlet is functional.
- **No Suction:** Check if the dirty water tank is full and needs emptying. Ensure the hose and nozzles are correctly attached and not blocked.
- **No Water/Steam Spray:** Check if the clean water tank is filled. Ensure the selected mode is active and the trigger is pressed.
- **Poor Cleaning Performance:** Ensure the correct cleaning mode and power level are selected for the type of stain. Pre-treat stubborn stains if necessary. Clean nozzles and brushes.

Specifications

Feature	Specification
Brand	Livatro
Model Name	LVCUCM002
Power	1700W
Suction Power	15 KPa
Clean Water Tank Capacity	1.6 Liters
Dirty Water Tank Capacity	1.2 Liters
Product Weight	3.7 Kilograms
Product Dimensions (D x W x H)	22D x 29.5W x 33.4H cm
Power Source	Corded Electric
Hose Length	1.6 m

Power Cable Length	5 m

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or contact Livatro customer service through their official website or the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question