Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GYMAX GM2253/4/5/6

GYMAX 55-inch 6-in-1 Kids Trampoline Instruction Manual

Model: GM2253/4/5/6

1. Product Overview

The GYMAX 55-inch 6-in-1 Kids Trampoline is a versatile activity center designed for children aged 3 and above, supporting a maximum weight capacity of 440 lbs. This product combines a trampoline with multiple play accessories, including a swing, basketball hoop, punching bag, two gymnastic rings, and an adjustable gymnastic bar, offering a comprehensive play experience. Key features include a no-gap jumping mat for enhanced safety, a 360-degree safety net with a zippered entry, and a robust galvanized metal frame. The jumping mat is constructed from thickened PP material, providing excellent elasticity and durability. Non-slip feet ensure stability during use, protecting floor surfaces.



Image 1.1: The GYMAX 55-inch 6-in-1 Kids Trampoline, showcasing the main unit with its integrated swing, basketball hoop, punching bag,

and gymnastic rings.



Image 1.2: Visual representation of the trampoline's six integrated play modes: Hammock, Gymnastic Rings, Basketball Hoop, Boxing, Gymnastic Bar, and Bouncing.

2. Safety Information

Adherence to safety guidelines is crucial for preventing injuries. This product is designed with several safety features, including a no-gap mat and a 360-degree safety net, and complies with ASTM & CPSIA standards.

2.1 General Safety Precautions

- Adult supervision is required at all times when children are using the trampoline.
- Ensure only one child uses the trampoline at a time to prevent collisions.
- Do not attempt somersaults or other dangerous maneuvers.
- Keep the area around the trampoline clear of obstacles.
- Inspect the trampoline regularly for any damaged or loose parts before each use.

- Ensure the safety net zipper is fully closed during use.
- Do not allow pets on or near the trampoline.
- The trampoline is suitable for children aged 3 years and older.

2.2 Product-Specific Safety Features

- **No-Gap Mat Design:** Eliminates gaps between the jumping mat and the frame, reducing the risk of limbs getting caught.
- **360° Safety Net:** Encloses the jumping area, preventing falls off the trampoline. Features a dual-sided zipper for secure entry and exit.
- **Thick Foam Pole Covers:** Padded poles protect against accidental bumps and impacts.
- **Non-Slip Rubber Feet:** Enhance stability and prevent the trampoline from shifting during use, also protecting floor surfaces.

3. Setup and Assembly

The GYMAX 6-in-1 Kids Trampoline features a snap-together assembly for straightforward setup. It is recommended to assemble the trampoline with at least two adults.

3.1 Unpacking and Component Check

Carefully unpack all components and verify against the included parts list in your user guide. Ensure all items are present and undamaged before proceeding with assembly.

- 1 x Kids Trampoline Frame and Mat
- 1 x Basketball Hoop
- 1 x Basketball
- 1 x Air Pump
- 1 x Hammock
- 2 x Gymnastic Rings
- 1 x Gloves
- 1 x Punching Bag
- 2 x Adhesive Non-slip Bands
- 1 x User Guide (this document)

3.2 Assembly Steps (General Guidelines)

1. Assemble the base frame by connecting the galvanized metal tubes using the snap-in-place mechanism. Ensure all connections are secure.
2. Attach the non-slip rubber feet to the bottom of the frame legs.
3. Carefully unroll and position the jumping mat onto the frame. Attach the 36 heavy-duty springs to the mat and frame as per the detailed instructions in the included user guide.
4. Install the safety net poles, ensuring the thick foam covers are correctly positioned. Secure the safety net around the poles and attach it to the trampoline frame.
5. Attach the adjustable gymnastic bar to the top of the safety net poles.
6. Install the various accessories: the basketball hoop, punching bag, hammock, and gymnastic rings, following the specific instructions for each. Use the hook-and-loop fasteners where indicated for secure attachment.
7. Inflate the basketball using the provided air pump.
8. Perform a final check to ensure all parts are correctly assembled and securely fastened before first use.



Image 3.1: Close-up view of assembly components, including the detachable and adjustable gymnastic bar, hook-and-loop fasteners, snap-in-place assembly points, anti-slip rubber grip, and 36 heavy-duty springs.

4. Operating Instructions

The GYMAX 6-in-1 Kids Trampoline offers multiple ways for children to engage in active play.

4.1 Trampoline Use

- Ensure the safety net zipper is closed before jumping.
- Jump in the center of the mat for optimal bounce and stability.
- Avoid jumping too high or attempting stunts that could lead to loss of balance.

4.2 Accessory Use

- **Basketball Hoop:** Use the provided basketball to practice shooting. Ensure the hoop is securely attached.
- **Punching Bag:** Attach the punching bag and use the gloves for boxing practice. Ensure the bag is securely hung and does

not interfere with jumping.

- **Hammock:** The hammock can be used for resting or gentle swinging. Ensure it is securely fastened to the gymnastic bar.
- **Gymnastic Rings:** Use the rings for hanging and developing upper body strength. Ensure they are securely attached to the bar.
- **Gymnastic Bar:** The bar can be used for hanging or other gymnastic exercises. It is detachable and adjustable in height (3 inches) to suit different activities and child heights.



Image 4.1: A child actively jumping on the trampoline, demonstrating its primary function.

5. Maintenance

Regular maintenance ensures the longevity and safe operation of your GYMAX trampoline.

- **Daily Inspection:** Before each use, check for any loose bolts, worn springs, tears in the jumping mat or safety net, or damaged foam padding. Tighten or replace components as necessary.
- **Cleaning:** Wipe down the jumping mat, safety net, and frame with a damp cloth and mild soap. Avoid harsh chemicals that could damage materials. Ensure all parts are dry before storage or next use.

- **Weather Protection:** While the jumping mat is waterproof and wear-resistant, prolonged exposure to extreme weather conditions (heavy rain, snow, intense sun) can reduce product lifespan. Consider covering the trampoline or disassembling and storing it indoors during adverse weather.
- **Spring Care:** Periodically check springs for rust or deformation. Replace any damaged springs immediately.
- **Accessory Check:** Ensure all accessories (basketball hoop, punching bag, hammock, rings) are securely attached and in good condition.

6. Troubleshooting

This section addresses common issues you might encounter with your trampoline.

- **Trampoline feels unstable:** Ensure all frame connections are fully engaged and tightened. Check that the non-slip feet are properly installed and making full contact with the ground. Verify the trampoline is placed on a flat, level surface.
- **Reduced bounce:** Inspect all springs for damage, stretching, or detachment. Replace any faulty springs. Ensure the jumping mat is correctly installed and tensioned.
- **Safety net sagging or torn:** Check the attachment points of the safety net to the poles and frame. If the net is torn, it must be replaced immediately to maintain safety.
- **Accessories not staying in place:** Verify that all hook-and-loop fasteners and attachment mechanisms for accessories are securely fastened. Adjust as needed.
- **Squeaking noises:** Apply a small amount of lubricant (e.g., silicone spray) to spring connection points or frame joints if persistent squeaking occurs.

7. Specifications

Feature	Detail
Brand	GYMAX
Model Name	6 in 1 Kids Trampoline
Model Number	GM2253/4/5/6
Overall Dimension	55" Diameter x 67.5"-70.5" Height
Jump Mat Diameter	42"
Jumping Mat Height	15.5"
Door Dimension	17.5" Width x 23.5" Height
Weight Capacity	440 lbs
Suitable Age	3+ Years
Net Weight	47.5 lbs
Materials	Metal, PP, PVC, EPE Foam, PE Fabric, Rubber, Mesh Fabric
Frame Material	Galvanized Steel
Springs	36 Heavy-duty Springs
Certifications	ASTM & CPSIA Compliant



Image 7.1: Detailed dimensions of the 55-inch Kids Trampoline, including overall height, jumping mat diameter, and door opening size.

8. Warranty Information

This GYMAX 55-inch 6-in-1 Kids Trampoline comes with a **90-day warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use and service. It does not cover damage resulting from misuse, abuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for any warranty claims.

9. Customer Support

For any questions, concerns, or assistance with your GYMAX 55-inch 6-in-1 Kids Trampoline, please refer to the contact information provided with your purchase documentation or visit the official GYMAX website. Our customer support team is available to help with assembly, troubleshooting, and parts replacement.

For additional resources and product information, you may visit the GYMAX Store on Amazon.

© 2025 GYMAX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FKT1P88Q

More documents and user manuals: **https://manuals.plus/**