

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Cecotec](#) /

› [Cecotec CeramicCare Single Peach Volumizing Hot Air Brush A01_EU01_112752 Instruction Manual](#)

Cecotec A01_EU01_112752

Cecotec CeramicCare Single Peach Volumizing Hot Air Brush

Model: A01_EU01_112752

1. INTRODUCTION AND PRODUCT OVERVIEW

Thank you for choosing the Cecotec CeramicCare Single Peach Volumizing Hot Air Brush. This instruction manual provides important information for the safe and effective use of your appliance. Please read it thoroughly before first use and keep it for future reference.

This 2-in-1 styling tool combines the power of a hairdryer with the volume of a curling iron. It is designed to detangle, dry, add volume, straighten, and wave hair, helping you achieve voluminous roots, smooth hair, and wavy ends.



Image 1.1: The Cecotec CeramicCare Single Peach Volumizing Hot Air Brush and its retail packaging.

2. SAFETY INSTRUCTIONS

To ensure safe operation, please observe the following precautions:

- Do not use this appliance near water, in bathrooms, or over basins containing water.
- Always unplug the appliance immediately after use.
- Do not use if the cord or plug is damaged. Contact customer service for repair.
- Keep the appliance away from children.

- Do not block the air vents during use.
- Allow the appliance to cool down completely before storing.
- This appliance is equipped with an overheating protection system. If it overheats, it will automatically shut off. Unplug and allow it to cool before resuming use.

3. PRODUCT COMPONENTS AND FEATURES

The Cecotec CeramicCare Single Peach Volumizing Hot Air Brush features:

- **Advanced Ceramic Plate:** For ultra-smooth gliding and improved heat transmission, reducing hair damage.
- **Keratin and Argan Oil Infusion:** Ceramic coating infused with keratin and argan oil for enhanced hair care.
- **1200W Power:** Provides fast and controlled drying.
- **3 Operating Modes:** Adapts to various styling needs.
- **Low-Temperature Air Function:** To set hairstyles and seal cuticles.
- **Cool Tip:** For comfortable and safe handling during styling.
- **360° Swivel Cord:** 1.65m long for flexible and comfortable use.
- **Hanging Loop:** For convenient storage.



Image 3.1: Detail of the brush head with bristles and ceramic barrel.

4. SETUP

Before first use, ensure the appliance is clean and free from any packaging materials.

1. Unpack the hot air brush and all its components.
2. Inspect the appliance for any visible damage. Do not use if damaged.
3. Plug the appliance into a suitable electrical outlet. Ensure the voltage matches the specifications of the appliance.

5. OPERATING INSTRUCTIONS

Follow these steps for optimal styling results:

1. Ensure your hair is towel-dried and detangled before use.
2. Plug in the appliance.
3. Select the desired mode using the rotating dial at the base of the brush handle.



Image 5.1: Adjusting the operating mode using the dial.

- **Mode 1 (Low Temperature):** For setting hairstyles and sealing cuticles.
- **Mode 2 (Medium Temperature):** For gentle drying and styling.
- **Mode 3 (High Temperature):** For fast drying and more intense styling.

4. Divide your hair into manageable sections.
5. Place the brush near the roots and glide it downwards towards the ends. For added volume, lift hair at the roots.
6. To create waves or curls, wrap a section of hair around the barrel and hold for a few seconds before releasing.



Image 5.2: Demonstrating hair styling with the hot air brush.

7. After styling, switch off the appliance and unplug it from the power outlet.
8. Allow the brush to cool down completely before storing.

6. MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your appliance.

1. Always unplug the appliance and ensure it is completely cool before cleaning.
2. Use a soft, damp cloth to wipe the exterior of the brush. Do not use abrasive cleaners or solvents.
3. Carefully remove any hair tangled in the bristles using your fingers or a small comb.
4. Do not immerse the appliance in water or any other liquid.
5. Store the appliance in a dry place, away from direct sunlight and moisture. Use the hanging loop for convenient storage.

7. TROUBLESHOOTING

If you encounter any issues, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in correctly; Power outlet malfunction; Damaged cord.	Ensure plug is fully inserted. Test with another outlet. Do not use if cord is damaged; contact customer service.
Appliance stops working during use.	Overheating protection activated.	Unplug the appliance and allow it to cool down for at least 15-20 minutes before resuming use. Ensure air vents are not blocked.
Hair gets tangled in the brush.	Hair not properly detangled; Too much hair taken at once.	Ensure hair is fully detangled before styling. Work with smaller sections of hair.

If the problem persists, please contact Cecotec customer support.

8. SPECIFICATIONS

- Brand:** Cecotec
- Model Number:** A01_EU01_112752
- Color:** Peach
- Wattage:** 1200 Watts
- Power Source:** Corded Electric
- Product Dimensions (LxWxH):** 8 x 10.5 x 37.5 cm
- Product Weight:** 530 grams
- Cable Length:** 1.65 m
- Recommended Uses:** Volumizing, Drying, Straightening, Waving

9. WHAT'S IN THE Box

Upon opening the product packaging, you should find the following items:

- 1 x Cecotec CeramicCare Single Peach Volumizing Hot Air Brush
- 1 x Instruction Manual

10. WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or technical support, please refer to the warranty card included with your product or visit the official Cecotec website. Keep your proof of purchase for any warranty claims.

Amazon Return Policy: This product is eligible for a return/replacement within 31 days of receipt, as per Amazon's return policy.